

**TOSHIBA**



---

---

# **W7 Adjustable Speed Drive Installation and Operation Manual**

---

---



---

---

# W7 Adjustable Speed Drive

---

---

## Installation and Operation Manual

Document Number: 57442-001

Date: November, 2006



# Introduction

Congratulations on the purchase of the new **W7 Adjustable Speed Drive (ASD)**. The **W7 ASD** is an 18-pulse PWM drive designed for use with 3-phase AC induction motors. This 18 pulse design includes an 18 pulse input diode bridge rectifier combined with and an integral phase shifting transformer.

U.S. Patent 6396723.

Japan Patent pending 2000-179543.

The drive has been designed with an 18-pulse front end to assist in the compliance of the harmonic distortion limits of standard IEEE 519 1992 at the point of common coupling.

The **W7 ASD** is ideally suited to drive variable torque loads. Toshiba's technology, quality, and reliability enables the motor to develop high torque and provide compensation for motor slip, which results in smooth, quick starts and highly efficient operation. The **W7 ASD** uses digitally-controlled pulse width modulation. The programmable functions may be accessed via the easy-to-use menu. These features, combined with Toshiba's high-performance software, delivers unparalleled motor control and reliability.

The **W7 ASD** is a very powerful tool, yet surprisingly simple to operate. The **W7 ASD** has an easy-to-read LCD screen that provides easy access to the many monitoring and programming features of the **W7 ASD**. The motor control software is menu-driven, which allows for easy access to the motor control parameters and quick changes when required.

To maximize the abilities of your new **W7 ASD**, a working familiarity with this manual will be required. This manual has been prepared for the **W7 ASD** installer, operator, and maintenance personnel.

The **W7 ASD** is truly **Reliability in motion**.

## Important Notice

The instructions contained in this manual are not intended to cover all details or variations in equipment types, nor may it provide for every possible contingency concerning the installation, operation, or maintenance of this equipment. Should additional information be required contact your Toshiba representative.

The contents of this manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Toshiba International Corporation. The warranty contained in the contract between the parties is the sole warranty of Toshiba International Corporation and any statements contained herein do not create new warranties or modify the existing warranty.

**Any electrical or mechanical modifications to this equipment without prior written consent of Toshiba International Corporation will void all warranties and may void the UL/CUL listing or other safety certifications. Unauthorized modifications may also result in a safety hazard or equipment damage.**

**Misuse of this equipment could result in injury and equipment damage. In no event will Toshiba Corporation be responsible or liable for direct, indirect, special, or consequential damage or injury that may result from the misuse of this equipment.**

# About This Manual

This manual was written by the Toshiba Technical Publications Group. This group is tasked with providing technical documentation for the **W7 Adjustable Speed Drive**. Every effort has been made to provide accurate and concise information to you, our customer.

At Toshiba we're continuously searching for better ways to meet the constantly changing needs of our customers. E-mail your comments, questions, or concerns about this publication to the [Technical-Publications-Dept@TIC.TOSHIBA.COM](mailto:Technical-Publications-Dept@TIC.TOSHIBA.COM).

## Manual's Purpose and Scope

This manual provides information on how to safely install, operate, maintain, and dispose of your **W7 Adjustable Speed Drive**. The information provided in this manual is applicable to the **W7 Adjustable Speed Drive** only.

This operation manual provides information on the various features and functions of this powerful cost-saving device, including

- Installation,
- System operation,
- Configuration and menu options, and
- Mechanical and electrical specifications.

Included is a section on general safety instructions that describe the warning labels and symbols that are used. Read the manual completely before installing, operating, performing maintenance, or disposing of this equipment.

This manual and the accompanying drawings should be considered a permanent part of the equipment and should be readily available for reference and review.

Dimensions shown in the manual are in metric and/or the English equivalent.

Because of our commitment to continuous improvement, Toshiba International Corporation reserves the right, without prior notice, to update information, make product changes, or to discontinue any product or service identified in this publication.

**Toshiba International Corporation (TIC) shall not be liable for direct, indirect, special, or consequential damages resulting from the use of the information contained within this manual.**

This manual is copyrighted. No part of this manual may be photocopied or reproduced in any form without the prior written consent of Toshiba International Corporation.

© Copyright 2006 Toshiba International Corporation.

TOSHIBA® is a registered trademark of the Toshiba Corporation. All other product or trade references appearing in this manual are registered trademarks of their respective owners.

**Reliability in motion™** is a trademark of the Toshiba International Corporation.

All rights reserved.

Printed in the U.S.A.

# Contacting Toshiba's Customer Support Center

Toshiba's Customer Support Center can be contacted to obtain help in resolving any **Adjustable Speed Drive** system problem that you may experience or to provide application information.

The center is open from 8 a.m. to 5 p.m. (CST), Monday through Friday. The Support Center's toll free number is US (800) 231-1412/Fax (713) 466-8773 — Canada (800) 527-1204.

After-hours support is available by calling the number listed above and following the instructions for after-hours support.

You may also contact Toshiba by writing to:

Toshiba International Corporation

13131 West Little York Road

Houston, Texas 77041-9990

Attn: ASD Product Manager.

For further information on Toshiba's products and services, please visit our website at [WWW.TIC.TOSHIBA.COM](http://WWW.TIC.TOSHIBA.COM).

## TOSHIBA INTERNATIONAL CORPORATION

### W7 Adjustable Speed Drive

Please complete the Warranty Card supplied with the ASD and return it to Toshiba by prepaid mail. This will activate the 12 month warranty from the date of installation; but, shall not exceed 18 months from the shipping date.

Complete the following information and retain for your records.

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Project Number (if applicable): \_\_\_\_\_

Date of Installation: \_\_\_\_\_

Inspected By: \_\_\_\_\_

Name of Application: \_\_\_\_\_

# Table of Contents

<b>General Safety Information .....</b>	<b>1</b>
Safety Alert Symbol .....	1
Signal Words .....	1
Special Symbols .....	2
Electrical Hazard Symbol .....	2
Explosion Hazard Symbol .....	2
Equipment Warning Labels .....	2
Qualified Personnel .....	3
Equipment Inspection .....	3
Handling and Storage .....	3
Disposal .....	4
Installation Precautions .....	5
Location and Ambient Requirements .....	5
Mounting Requirements .....	5
Conductor Requirements and Grounding .....	6
Power Connections .....	6
Protection .....	7
System Integration Precautions .....	8
Personnel Protection .....	8
System Setup Requirements .....	9
Operational and Maintenance Precautions .....	10
Service Life Information .....	10
<b>Motor Characteristics .....</b>	<b>11</b>
Pulse Width Modulation Operation .....	11
Overload Protection Adjustment .....	11
Power Factor Correction .....	11
Light Load Conditions .....	11
Load-produced Negative Torque .....	11
Motor Braking .....	12
<b>ASD Characteristics .....</b>	<b>12</b>
Over-current Protection .....	12
ASD Capacity .....	12
<b>Installation and Connections .....</b>	<b>13</b>
Installation Notes .....	13
Mounting the ASD .....	14
Connecting the ASD .....	15
System Grounding .....	15
Power Connections .....	15
Lead Length Specifications .....	16
Startup and Test .....	16
I/O and Control .....	17
I/O Terminal Descriptions .....	19

W7 ASD Control .....	23
CNU1/1A and CNU2/2A Pinout .....	24
CN3 Pinout .....	24
CN7 Pinout .....	24
I/O Circuit Configurations .....	25
Typical Connection Diagram .....	26
<b>Electronic Operator Interface .....</b>	<b>27</b>
EOI Features .....	27
EOI Operation .....	28
EOI Remote Mounting .....	30
Remote EOI Required Hardware .....	30
EOI Installation Precautions .....	31
EOI Remote Mounting w/o the ASD-MTG-KIT .....	31
EOI Remote Mounting using the ASD-MTG-KIT .....	32
<b>System Operation .....</b>	<b>33</b>
Operation (Local) .....	33
Default Setting Changes .....	33
<b>System Configuration and Menu Options .....</b>	<b>35</b>
Root Menus .....	35
Frequency Command Screen .....	35
Monitor Screen .....	36
Program Screen .....	38
Program Menu Navigation .....	39
<b>W7 ASD Direct Access/Communication Numbers .....</b>	<b>51</b>
<b>W7 ASD Parameter Descriptions .....</b>	<b>57</b>
<b>Enclosure Dimensions and Conduit Plate Information .....</b>	<b>173</b>
Enclosure Dimensions/Weight .....	174
<b>Alarms, Trips, and Troubleshooting .....</b>	<b>176</b>
Alarms and Trips .....	176
Alarms .....	177
User Notification Codes .....	179
Trips/Faults .....	180
Viewing Trip Information .....	184
Clearing a Trip .....	184
<b>Cable/Terminal Specifications .....</b>	<b>185</b>
<b>Current/Voltage Specifications .....</b>	<b>186</b>
<b>W7 ASD Spare Parts Listing .....</b>	<b>187</b>



# General Safety Information

**DO NOT** attempt to install, operate, maintain or dispose of this equipment until you have read and understood all of the product safety information and directions that are contained in this manual.

## Safety Alert Symbol

The **Safety Alert Symbol** indicates that a potential personal injury hazard exists. The symbol is comprised of an equilateral triangle enclosing an exclamation mark.



## Signal Words

Listed below are the signal words that are used throughout this manual followed by their descriptions and associated symbols. When the words **DANGER**, **WARNING** and **CAUTION** are used in this manual they will be followed by important safety information that must be carefully adhered to.

The word **DANGER** preceded by the safety alert symbol indicates that an imminently hazardous situation exists that, if not avoided, will result in death or serious injury to personnel.



The word **WARNING** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided, could result in death or serious injury to personnel.



The word **CAUTION** preceded by the safety alert symbol indicates that a potentially hazardous situation exists which, if not avoided, may result in minor or moderate injury.



The word **CAUTION** without the safety alert symbol indicates a potentially hazardous situation exists which, if not avoided, may result in equipment and property damage.

**CAUTION**

# Special Symbols

To identify special hazards, other symbols may appear in conjunction with the **DANGER, WARNING** and **CAUTION** signal words. These symbols indicate areas that require special and/or strict adherence to the procedures to prevent serious injury to personnel or death.

## Electrical Hazard Symbol

A symbol which indicates a hazard of injury from electrical shock or burn. It is comprised of an equilateral triangle enclosing a lightning bolt.



## Explosion Hazard Symbol

A symbol which indicates a hazard of injury from exploding parts. It is comprised of an equilateral triangle enclosing an explosion image.



## Equipment Warning Labels

**DO NOT** attempt to install, operate, perform maintenance, or dispose of this equipment until you have read and understood all of the product labels and user directions that are contained in this guide.

**DO NOT** remove or cover any of the labels. If the labels are damaged or if additional labels are required, contact your Toshiba sales representative for additional labels.

Labels attached to the equipment are there to provide useful information or to indicate an imminently hazardous situation that may result in serious injury, severe property and equipment damage, or death if the instructions are not followed.

# Qualified Personnel

Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**. A **Qualified Person** is one that has the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and has received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements).

**Qualified Personnel** shall:

- Have carefully read the entire operation manual.
- Be familiar with the construction and function of the ASD, the equipment being driven, and the hazards involved.
- Able to recognize and properly address hazards associated with the application of motor-driven equipment.
- Be trained and authorized to safely energize, de-energize, ground, lockout/tagout circuits and equipment, and clear faults in accordance with established safety practices.
- Be trained in the proper care and use of protective equipment such as safety shoes, rubber gloves, hard hats, safety glasses, face shields, flash clothing, etc., in accordance with established safety practices.
- Be trained in rendering first aid.

For further information on workplace safety visit [www.osha.gov](http://www.osha.gov).

# Equipment Inspection

- Upon receipt of the equipment inspect the packaging and equipment for shipping damage.
- Carefully unpack the equipment and check for parts that may have been damaged during shipping, missing parts, or concealed damage. If any discrepancies are discovered, it should be noted with the carrier prior to accepting the shipment, if possible. File a claim with the carrier if necessary and immediately notify your Toshiba sales representative.
- **DO NOT** install or energize equipment that has been damaged. Damaged equipment may fail during operation resulting in equipment damage or personal injury.
- Check to see that the rated capacity and the model number specified on the nameplate conform to the order specifications.
- Modification of this equipment is dangerous and must not be performed except by factory trained representatives. When modifications are required contact your Toshiba sales representative.
- Inspections may be required before and after moving installed equipment.
- Keep the equipment in an upright position.
- Contact your Toshiba sales representative to report discrepancies or for assistance if required.

# Handling and Storage

- Use proper lifting techniques when moving the ASD; including properly sizing up the load, getting assistance, and using a forklift if required.
- Store in a well-ventilated covered location and preferably in the original carton if the equipment will not be used upon receipt.
- Store in a cool, clean, and dry location. Avoid storage locations with extreme temperatures, rapid temperature changes, high humidity, moisture, dust, corrosive gases, or metal particles.

- The storage temperature range of the **W7 ASD** is 14 to 104° F (-10 to 40° C).
- Do not store the unit in places that are exposed to outside weather conditions (i.e., wind, rain, snow, etc.).
- Store in an upright position.

## **Disposal**

Never dispose of electrical components via incineration. Contact your state environmental agency for details on disposal of electrical components and packaging in your area.

# Installation Precautions

## Location and Ambient Requirements

- The Toshiba ASD is intended for permanent installations only.
- Installation should conform to the **2005 National Electrical Code — Article 110** (*Requirements For Electrical Installations*), all regulations of the **Occupational Safety and Health Administration**, and any other applicable national, regional, or industry codes and standards.
- Select a mounting location that is easily accessible, has adequate personnel working space, and adequate illumination for adjustment, inspection, and maintenance of the equipment (refer to 2005 NEC Article 110-13).
- A noncombustible insulating floor or mat should be provided in the area immediately surrounding the electrical system.
- **Do Not** mount the ASD in a location that would produce catastrophic results if it were to fall from its mounting location (equipment damage or injury).
- **Do Not** mount the ASD in a location that would allow it to be exposed to flammable chemicals or gasses, water, solvents, or other fluids.
- Avoid installation in areas where vibration, heat, humidity, dust, fibers, metal particles, explosive/corrosive mists or gases, or sources of electrical noise are present.
- The installation location shall not be exposed to direct sunlight.
- Allow proper clearance spaces for installation. Do not obstruct the ventilation openings. Refer to the section titled [Installation and Connections on pg. 13](#) for further information on ventilation requirements.
- The ambient operating temperature range of the **W7 ASD** is 14 to 104° F (-10 to 40° C).
- See the section titled [Installation and Connections on pg. 13](#) for additional information on installing the drive.

## Mounting Requirements

- Only **Qualified Personnel** should install this equipment.
- Install the unit in a secure and upright position in a well-ventilated area.
- A noncombustible insulating floor or mat should be provided in the area immediately surrounding the electrical system at the place where maintenance operations are to be performed.
- As a minimum, the installation of the equipment should conform to the 2005 NEC Article 110 Requirements For Electrical Installations, OSHA, as well as any other applicable national, regional, or industry codes and standards.
- Installation practices should conform to the latest revision of NFPA 70E Electrical Safety Requirements for Employee Workplaces.
- It is the responsibility of the person installing the ASD or the electrical maintenance personnel to ensure that the unit is installed into an enclosure that will protect personnel against electric shock.

# Conductor Requirements and Grounding



- Use separate metal conduits for routing the input power, output power, and control circuits and each shall have its own ground cable.
- A separate ground cable should be run inside the conduit with the input power, output power, and control circuits.
- **DO NOT** connect the control terminal strip return marked CC to earth ground.
- Always ground the unit to prevent electrical shock and to help reduce electrical noise.
- It is the responsibility of the person installing the ASD or the electrical maintenance personnel to provide proper grounding and branch circuit protection in accordance with the **2005 NEC** and any applicable local codes.

**The Metal Of Conduit Is Not An Acceptable Ground.**

## Power Connections



**Contact With Energized Wiring Will Cause Severe Injury Or Death.**

- Turn off, lockout, and tagout all power sources before proceeding to connect the power wiring to the equipment.
- After ensuring that all power sources are turned off and isolated in accordance with established lockout/tagout procedures, connect three-phase power source wiring of the correct voltage to the correct input terminals and connect the output terminals to a motor of the correct voltage and type for the application (refer to 2005 NEC Article 300 – Wiring Methods and Article 310 – Conductors For General Wiring). Size the branch circuit conductors in accordance with 2005 NEC Table 310.16.
- Adhere to the recommended conductor sizes listed in the section titled [Cable/Terminal Specifications on pg. 185](#). If multiple conductors are used in parallel for the input or output power, each branch of the parallel set shall have its own conduit and not share its conduit with other parallel sets (i.e., place U1, V1, and W1 in one conduit and U2, V2, and W2 in another) (refer to 2005 NEC Article 300.20 and Article 310.4). National and local electrical codes should be referenced if three or more power conductors are run in the same conduit (refer to 2005 NEC Article 310 adjustment factors).

***Note:** National and local codes should be referenced when running more than three conductors in the same conduit.*

- Ensure that the 3-phase input power is **Not** connected to the output of the ASD. This will damage the ASD and may cause injury to personnel.
- Do not install the ASD if it is damaged or if it is missing any component(s).
- **Do Not** connect resistors across terminals PA – PC or PO – PC. This may cause a fire.
- Ensure the correct phase sequence and the desired direction of motor rotation in the **Bypass** mode (if applicable).
- Turn the power on only after attaching and/or closing the front cover.

# Protection

- Ensure that primary protection exists for the input wiring to the equipment. This protection must be able to interrupt the available fault current from the power line. The equipment may or may not be equipped with an input disconnect (option).
- All cable entry openings must be sealed to reduce the risk of entry by vermin and to allow for maximum cooling efficiency.
- Follow all warnings and precautions and do not exceed equipment ratings.
- If using multiple motors provide separate overload protection for each motor and use V/f control.
- External dynamic braking resistors must be thermally protected.
- It is the responsibility of the person installing the ASD or the electrical maintenance personnel to setup the **Emergency Off** braking system of the ASD. The function of the **Emergency Off** braking function is to remove output power from the drive in the event of an emergency. A supplemental braking system may also be engaged in the event of an emergency. For further information on braking systems, see [DC Injection Braking Current on pg. 75](#) and [Dynamic Braking Enable on pg. 81](#).

***Note:** A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.*

- Follow all warnings and precautions and do not exceed equipment ratings.

# System Integration Precautions

The following precautions are provided as general guidelines for the setup of the ASD within the system.

- The Toshiba ASD is a general-purpose product. It is a system component only and the system design should take this into consideration. Please contact your Toshiba sales representative for application-specific information or for training support.
- The Toshiba ASD is part of a larger system and the safe operation of the ASD will depend on observing certain precautions and performing proper system integration.
- A detailed system analysis and job safety analysis should be performed by the systems designer and/or systems integrator before the installation of the ASD component. Contact your Toshiba sales representative for options availability and for application-specific system integration information if required.

## Personnel Protection

- Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**.
- A thorough understanding of the ASD will be required before the installation, operation, or maintenance of the ASD.



- Rotating machinery and live conductors can be hazardous and shall not come into contact with humans. Personnel should be protected from all rotating machinery and electrical hazards at all times.
- Insulators, machine guards, and electrical safeguards may fail or be defeated by the purposeful or inadvertent actions of workers. Insulators, machine guards, and electrical safeguards are to be inspected (and tested where possible) at installation and periodically after installation for potential hazardous conditions.
- Do not allow personnel near rotating machinery. Warning signs to this effect shall be posted at or near the machinery.
- Do not allow personnel near exposed electrical conductors. Human contact with electrical conductors can be fatal. Warning signs to this effect shall be posted at or near the hazard.
- Personal protection equipment shall be provided and used to protect employees from any hazards inherent to system operation.
- Follow all warnings and precautions and do not exceed equipment ratings.



# System Setup Requirements



- When using the ASD as an integral part of a larger system, it is the responsibility of the ASD installer or maintenance personnel to ensure that there is a fail-safe in place, i.e., an arrangement designed to switch the system to a safe condition if there is a fault or failure.
- System safety features should be employed and designed into the integrated system in a manner such that system operation, even in the event of system failure, will not cause harm or result in personnel injury or system damage (i.e., E-Off, Auto-Restart settings, System Interlocks, etc.).
- The programming setup and system configuration of the ASD may allow it to start the motor unexpectedly. A familiarity with the Auto-restart and the Remote/Local settings and function is a requirement to use this product.
- Improperly designed or improperly installed system interlocks may render the motor unable to start or stop on command.
- The failure of external or ancillary components may cause intermittent system operation (i.e., the system may start the motor without warning).
- There may be thermal or physical properties, or ancillary devices integrated into the overall system that may allow for the ASD to start the motor without warning. Signs to this effect must be posted at the equipment installation site and near the driven equipment.
- If a secondary magnetic contactor (MC) is used between the ASD output and the load, it should be interlocked to halt the ASD before the secondary contact opens. If the output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the ASD output terminals (U, V, W).
- Power factor improvement capacitors or surge absorbers must not be installed on the output of the ASD.
- Use of the built-in system protective features is highly recommended (i.e., E-Off, Overload Protection, etc.).
- The operating controls and system status indicators should be clearly readable and positioned where the operator can see them without obstruction.
- Additional warnings and notifications shall be posted at the equipment installation location as deemed required by **Qualified Personnel**.
- Follow all warnings and precautions and do not exceed equipment ratings.

# Operational and Maintenance Precautions



- Turn off, lockout, and tagout the main power, the control power, and instrumentation connections before inspecting or servicing the drive, or opening the door of the enclosure.
- Turn off, lockout, and tagout the main power, the control power, and instrumentation connections before proceeding to disconnect or connect the power wiring to the equipment.
- The capacitors of the ASD maintain a residual charge for a period of time after turning the ASD off. The required time for each ASD typeform is indicated with a cabinet label and a **Charge LED**. Wait for at least the minimum time indicated on the enclosure-mounted label and ensure that the **Charge LED** has gone out before opening the door of the ASD once the ASD power has been turned off.
- Turn the power on only after attaching (or closing) the front cover and **Do Not** remove the front cover of the ASD when the power is on.
- **Do Not** attempt to disassemble, modify, or repair the ASD. Call your Toshiba sales representative for repair information.
- Do not place any objects inside of the ASD.
- If the ASD should emit smoke or an unusual odor or sound, turn the power off immediately.
- The heat sink and other components may become extremely hot to the touch. Allow the unit to cool before coming in contact with these items.
- Remove power from the ASD during extended periods of non-use.
- The system should be inspected periodically for damaged or improperly functioning parts, cleanliness, and to ensure that the connectors are tightened securely.
- Ensure that the **Run** functions (**F**, **R**, **Preset Speed**, etc.) of the ASD are off before performing a **Reset**. The post-reset settings may allow the ASD to start unexpectedly.
- **Retry** or **Reset** settings may allow the motor to start unexpectedly. Warnings to this effect should be clearly posted near the ASD and the motor.
- In the event of a power failure, the motor may restart after power is restored.
- Follow all warnings and precautions and do not exceed equipment ratings.

**DO NOT** install, operate, perform maintenance, or dispose of this equipment until you have read and understood all of the product warnings and user directions. Failure to do so may result in equipment damage, operator injury, or loss of life.

## Service Life Information

Part Name	Service Life	Remarks
Large Capacity Electrolytic Capacitor	5 Years	When not used for long periods, charge semi-annually.
Cooling Fan	26,000 Hours	
CN Connectors	100 Connects/Disconnects	
On-board Relays	500,000 Actuations	

# Motor Characteristics

Listed below are some variable speed AC motor control concepts with which the user of the **W7 Adjustable Speed Drive** should become familiar.

## Pulse Width Modulation Operation

The **W7 ASD** uses a sinusoidal **Pulse Width Modulation** (PWM) control system. The output current waveform generated by the ASD approaches that of a perfect sine wave; however, the output waveform is slightly distorted. For this reason, the motor may produce more heat, noise, and vibration when operated by an ASD, rather than directly from commercial power.

## Overload Protection Adjustment

The **W7 ASD** software monitors the output current of the system and determines when an overload condition occurs. The overload current level is a percentage of the rating of the motor. This function protects the motor from overload.

The default setting for the overload detection circuit is set to the maximum rated current of the ASD at the factory. This setting will have to be adjusted to match the rating of the motor with which the ASD is to be used. To change the overload reference level, see [Electronic Thermal Protection #1 on pg. 83](#).

## Power Factor Correction

**DO NOT** connect a power factor correction capacitor or surge absorber to the output of the ASD.

If the ASD is used with a motor that is equipped with a capacitor for power factor correction, remove the capacitor from the motor.

Connecting either of these devices to the output of the ASD may cause the ASD to malfunction and trip, or the output device may cause an over-current condition resulting in damage to the device or the ASD.

## Light Load Conditions

When a motor is operated under a continuous light load (i.e., at a load of less than 50% of its rated capacity) or it drives a load which produces a very small amount of inertia, it may become unstable and produce abnormal vibration or trips because of an over-current condition. In such a case, the carrier frequency may be lowered to compensate for this undesirable condition (see Program ⇒ Special Control ⇒ [PWM Carrier Frequency](#)).

***Note:** For proper operation, the carrier frequency must be 2.2 kHz or above except when operating in the **Constant Torque** or **Variable Torque** modes.*

## Load-produced Negative Torque

When the ASD is used with a load that produces negative torque (an overhauling load), the over-voltage or over-current protective functions of the ASD may cause nuisance tripping.

To minimize the undesirable effects of negative torque the dynamic braking system may be used. The dynamic braking system converts the regenerated energy into heat that is dissipated using a braking

resistor. The braking resistor must be suitably matched to the load. Dynamic braking is also effective in reducing the DC bus voltage during a momentary over-voltage condition.

## CAUTION

If under extreme conditions the dynamic braking system or a component of this system were to fail, the dynamic braking resistor may experience an extended over-current condition. The DBR circuit was designed to dissipate excessive amounts of heat and if the extended over-current condition were allowed to exceed the circuit parameters, this condition could result in a fire hazard.

To combat this condition, the 3-phase input may be connected using contactors that are configured to open in the event of an extended DBR over-current condition or an internal circuit failure. Using a thermal sensor and/or overload protection as the 3-phase input contactor drive signal, the contactors will open and remove the 3-phase input power in the event of an extended DBR over-current or system over-voltage condition.

## Motor Braking

The motor may continue to rotate and coast to a stop after being shut off due to the inertia of the load. If an immediate stop is required, a braking system should be used. The two most common types of motor braking systems used with the **W7 ASD** are **DC Injection Braking** and **Dynamic Braking**.

For further information on braking systems, see [DC Injection Braking Current on pg. 75](#) and [Dynamic Braking Enable on pg. 81](#).

## ASD Characteristics

### Over-current Protection

Each **W7 ASD** model was designed for a specified operating power range. The ASD will incur a trip if the design specifications are exceeded.

However, the ASD may be operated at 100% of the specified output-current range continuously or at 110% for a limited time as indicated in the section titled [Current/Voltage Specifications on pg. 186](#). Also, the [Overcurrent Stall Level](#) setting may be adjusted to help with nuisance over-current trips.

When using the ASD for an application that controls a motor which is rated significantly less than the maximum current rating of the ASD, the over-current limit (Thermal Overload Protection) setting will have to be changed to match the application. For further information on this parameter, see [Electronic Thermal Protection #1 on pg. 83](#).

### ASD Capacity

The **W7 ASD** must not be used with a motor that has a significantly larger capacity, even if the motor is operated under a small load. An ASD being used in this way will be susceptible to a high-output peak current which may result in nuisance tripping.

Do not apply a level of input voltage to an ASD that is beyond that which the ASD is rated. The input voltage may be stepped down if required with the use of a step-down transformer or some other type of voltage-reduction system.

# Installation and Connections

The **W7 Adjustable Speed Drive** may be set up initially by performing a few simple configuration settings. To operate properly, the ASD must be securely mounted and connected to a power source (3-phase AC input at the **L1/R**, **L2/S**, and **L3/T** terminals). The control terminals of the ASD may be used by connecting the terminals of the **Control Terminal Strip** to the proper sensors or signal input sources (see the section titled **I/O and Control** on pg. 17).

The output terminals of the ASD (**T1/U**, **T2/V**, and **T3/W**) must be connected to the motor that is to be controlled (see **Figure 16** on pg. 24).

As a minimum, the installation of the ASD shall conform to **Article 110** of the **2005 NEC**, the **Occupational Safety and Health Administration** requirements, and to any other local and regional industry codes and standards.

## Installation Notes

When a brake-equipped motor is connected to the ASD, it is possible that the brake may not release at startup because of insufficient voltage. To avoid this, **Do Not** connect the brake or the brake contactor to the output of the ASD.

If an output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the output terminals of the ASD (**T1/U**, **T2/V**, or **T3/W**).


If a secondary magnetic contactor (MC) is used between the output of the ASD and the motor, it should be interlocked such that the **ST – CC** connection is disconnected before the output contactor is opened.

**Do Not** open and then close a secondary magnetic contactor between the ASD and the motor unless the ASD is off and the motor is not rotating.

**Note:** *Re-application of power via a secondary contact while the ASD is on or while the motor is still turning may cause ASD damage.*

On some devices the **ST-to-CC** connection is further enhanced by the operation of the **MS1 AUX** relay circuit. The **MS1 AUX** relay circuit is normally open and closes the **ST-to-CC** connection (via **ST1**) only after normal system power is available. The **MS1 AUX** relay circuit prohibits the **ST-to-CC** connection in the event that the **MS1** contactor fails to close during start up or if **MS1** opens while the ASD is running. For the 460 volt ASD this feature is available on the 75 HP and above systems.

Figure 1. Alternative ST activation using the MS1 AUX circuit configuration.



The ASD input voltage should remain within 10% of the specified input voltage range. Input voltages approaching the upper or lower limit settings may require that the overvoltage and undervoltage stall protection level parameters be adjusted. Voltages outside of the permissible tolerance should be avoided.

The frequency of the input power should be  $\pm 2$  Hz of the specified input frequency.

Do not use an ASD with a motor that has a power rating that is higher than the rated output of the ASD.

The ASD is designed to operate NEMA B motors. Consult with your sales representative before using the ASD for special applications such as with an explosion-proof motor or applications with a piston load.

**Do Not** apply commercial power to the output terminals **T1/U**, **T2/V**, or **T3/W**.

Disconnect the ASD from the motor before megging or applying a bypass voltage to the motor.

Interface problems may occur when an ASD is used in conjunction with some types of process controllers. Signal isolation may be required to prevent controller and/or ASD malfunction (contact your Toshiba sales representative or the process controller manufacturer for additional information about compatibility and signal isolation).

Use caution when setting the output frequency. Over speeding a motor decreases its ability to deliver torque and may result in damage to the motor and/or the driven equipment.

All **W7 ASDs** are equipped with internal DC bus fuses. However, not all **W7 ASDs** are equipped with internal primary power input fuses (HP-dependent).

## Mounting the ASD



Install the unit securely in a well ventilated area that is out of direct sunlight using the mounting holes on the rear of the ASD.

The ambient temperature rating for the **W7 ASD** is from 14 to 104° F (-10 to 40° C). The process of converting AC to DC, and then back to AC produces heat. During normal ASD operation, up to 5% of the input energy to the ASD may be dissipated as heat. If installing the ASD in a cabinet, ensure that there is adequate ventilation.

**Do Not** operate the ASD with the enclosure door open or removed and ensure that the ventilation openings are not obstructed.

ASDs produce high-frequency noise — steps must be taken during installation to avoid the negative effects of noise. Listed below are some examples of measures that will help to combat noise problems.

- Separate the input and output power conductors of the main circuit. Do not install the input and output wires in the same duct or in parallel with each other, and do not bind them together.
- Do not install the input or output power conductors of the main circuit and the wires of the control circuit in the same duct or in parallel with each other, and do not bind them together.
- Use shielded wires or twisted wires for the control circuits.
- Ensure that the grounding terminals (G/E) of the ASD are securely connected to ground.
- Connect a surge suppressor to every electromagnetic contactor and every relay installed near the ASD.
- Install noise filters as required.

# Connecting the ASD



Refer to the section titled [Installation Precautions](#) on pg. 5 and the section titled [Lead Length Specifications](#) on pg. 16 before attempting to connect the ASD and the motor to electrical power.

## System Grounding

Proper grounding helps to prevent electrical shock and to reduce electrical noise. The ASD is designed to be grounded in accordance with **Article 250** of the **2005 NEC** or **Section 10/Part One** of the **Canadian Electrical Code (CEC)**.

The grounding conductor shall be sized in accordance with **Article 250-122** of the **2005 NEC** or **Part One-Table 6** of the **CEC**.

*Note:* The metal of conduit is not an acceptable ground.

The input power, output power, and control lines of the system shall be run in separate metal conduits and each shall have its own ground conductor.

## Power Connections



Connect the 3-phase input power to the input terminals of the **W7 ASD** at **L1/R**, **L2/S**, and **L3/T**. Connect the output terminals **T1/U**, **T2/V**, and **T3/W** of the **W7 ASD** to the motor.

The input and output conductors and terminal lugs used shall be in accordance with the specifications listed in the section titled [Cable/Terminal Specifications](#) on pg. 185.


An inductor may be connected across terminals **PA** and **PO** to provide additional filtering. When not used, a jumper must be connected across these terminals (see [Figure 16](#) on pg. 24).

Connect the input and output power lines of the **W7 ASD** as shown in [Figure 2](#).

Install a molded case circuit breaker (MCCB) or fuse between the 3-phase power source and the **W7 ASD** in accordance with the fault current setting of the ASD and **2005 NEC Article 430**.

*Note:* In the event that the motor rotates in the wrong direction when powered up, reverse any two of the three ASD output power leads connected to the motor.

Figure 2. ASD/Motor connection diagram.



# Lead Length Specifications

Adhere to the 2005 NEC and any local codes during the installation of ASD/Motor systems. Excessive lead lengths may adversely effect the performance of the motor. Special cables are not required. Lead lengths from the ASD to the motor in excess of those listed in [Table 1](#) may require filters to be added to the output of the ASD. [Table 1](#) lists the suggested maximum lead lengths for the listed motor voltages.

Table 1. Suggested maximum lead lengths.

Model	PWM Carrier Frequency	NEMA MG-1-1998 Section IV Part 31 Compliant Motors <sup>2</sup>
230 Volt	All	1000 feet
460 Volt	< 5 kHz	600 feet
	≥ 5 kHz	300 feet
600 Volt	< 5 kHz	200 feet
	≥ 5 kHz	100 feet

**Note:** *Contact Toshiba for application assistance when using lead lengths in excess of those listed.*

*Exceeding the peak voltage rating or the allowable thermal rise time of the motor insulation will reduce the life expectancy of the motor.*

*For proper operation, the carrier frequency must be 2.2 kHz or above except when operating in the **Constant Torque** or **Variable Torque** modes.*

## Startup and Test

Perform the following checks before turning on the unit:

- **L1/R, L2/S, and L3/T** are connected to the 3-phase input power.
- **T1/U, T2/V, and T3/W** are connected to the motor.
- The 3-phase input voltage is within the specified tolerance.
- There are no shorts and all grounds are secured.



# I/O and Control

The W7 ASD can be controlled by several input types and combinations thereof, as well as operate within a wide range of output frequency and voltage levels. This section describes the ASD control methods and supported I/O functions. Expanded descriptions of the I/O terminals may be found on pg. 18.

The **Control Terminal Strip Board** (P/N 48570) supports discrete and analog I/O functions.

The **Control Terminal Strip** is shown in [Figure 4 on pg. 20](#). [Table 2](#) and lists the names, the default settings (where applicable), and the descriptions of the input and output terminals.

[Figure 16 on pg. 24](#) shows the basic connection diagram for the **W7 ASD** system.

**Table 2. Control Terminal Strip** default assignment terminal names and functions.

Terminal Name	Input/Output	Terminal Function (default setting if programmable)	Circuit Config.
ST	Discrete Input	<b>Standby</b> (jumper to <b>CC</b> to operate the unit) — Multifunctional programmable discrete input (see <a href="#">Installation Notes on pg. 13</a> for further information on this terminal).	<a href="#">Figure 6 on pg. 23.</a>
RES	Discrete Input	<b>Reset</b> — Multifunctional programmable discrete input.	
F	Discrete Input	<b>Forward</b> — Multifunctional programmable discrete input.	
R	Discrete Input	<b>Reverse</b> — Multifunctional programmable discrete input.	
S1	Discrete Input	<b>Preset Speed 1</b> — Multifunctional programmable discrete input.	
S2	Discrete Input	<b>Preset Speed 2</b> — Multifunctional programmable discrete input.	
S3	Discrete Input	<b>Preset Speed 3</b> — Multifunctional programmable discrete input.	
S4	Discrete Input	<b>Emergency Off</b> — Multifunctional programmable discrete input.	
RR	Analog Input	<b>Frequency Mode 1</b> — Multifunction programmable analog input (0.0 to 10 volt input — 0 to 80 Hz output). <b>Reference CC.</b>	<a href="#">Figure 7 on pg. 23.</a>
RX	Analog Input	<b>Unassigned</b> — Multifunctional programmable analog input (-10 to +10 VDC input). <b>Reference CC.</b>	<a href="#">Figure 8 on pg. 23.</a>
II	Analog Input	<b>Frequency Mode 2</b> — Multifunctional programmable analog input (4 [0] to 20 mADC input) (see <a href="#">Figure 4 on pg. 20</a> for the location of the <b>II</b> terminal). <b>Reference CC.</b>	<a href="#">Figure 9 on pg. 23.</a>
VI	Analog Input	<b>Frequency Mode 2</b> — Multifunctional programmable analog input (0 to 10 VDC input). <b>Reference CC.</b>	
P24	DC Output	24 VDC @ 50 mA output.	<a href="#">Figure 10 on pg. 23.</a>
PP	DC Output	<b>PP</b> — 10.0 VDC voltage source for the external potentiometer.	<a href="#">Figure 11 on pg. 23.</a>
OUT1	Discrete Output	<b>Low Speed</b> — Multifunctional programmable discrete output.	<a href="#">Figure 12 on pg. 23.</a>
OUT2	Discrete Output	<b>Acc/Dec Complete</b> — Multifunctional programmable discrete output.	
FP	Output	<b>Output Frequency</b> — an output pulse train that has a frequency which is based on the output frequency of the ASD.	<a href="#">Figure 13 on pg. 23.</a>
AM	Output	<b>Output Current</b> — Produces an output current that is proportional to the magnitude of the function assigned to this terminal (see <a href="#">Table 8 on page 172</a> ).	<a href="#">Figure 14 on pg. 23</a>
FM	Output	<b>Output Frequency</b> — Same as AM terminal.	
FLC	Output	<b>Fault All</b> — Common.	<a href="#">Figure 15 on pg. 23.</a>
FLB	Output	<b>Fault All</b> — Normally closed contact.	
FLA	Output	<b>Fault All</b> — Normally open contact.	
CC	—	Control common ( <b>Do Not</b> connect to <b>Earth Gnd</b> ).	
<b>Discrete Input Terminals</b> ⇒ <b>On</b> = connected to <b>CC</b> .			
<b>Analog Input</b> terminals reference <b>CC</b> .			

# I/O Terminal Descriptions

**Note:** *The programmable terminal assignments of the discrete input terminals may be accessed and changed from their default settings as mapped on pg. 47 (see Input Terminals).*

**ST** — The default setting for this terminal is **ST**. The function of this input as **ST** is a **Standby** mode controller (system is in **Standby** when on). As the default setting, this terminal must be connected to **CC** for normal operation. If not connected to **CC**, **Off** is displayed on the LCD screen. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [ST Terminal Assignment on pg. 151](#) for more information on this terminal.

**RES** — The default setting for this terminal is **RES**. The function of this input as **RES** is a system **Reset**. A momentary connection to **CC** resets the ASD and any fault indications from the display. This input terminal may be programmed to any 1 of the 69 possible functions that are listed in [Table 6 on page 167](#). **Reset** is effective when faulted only. See [RES Terminal Assignment on pg. 126](#) for more information on this terminal.

**F** — The default setting for this terminal is **Forward Run**. **Forward Run** runs the motor in the **Forward** direction when it is on. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [F Terminal Assignment on pg. 90](#) for more information on this terminal.

**R** — The default setting for this terminal is **Reverse Run**. **Reverse Run** runs the motor in the **Reverse** direction when it is on. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [R Terminal Assignment on pg. 132](#) for more information on this terminal.

**S1** — The default setting for this terminal is **S1**. The function of this input as **S1** is to run the motor at **Preset Speed #1** (see [Preset Speed #1 on pg. 119](#)) when it is on. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [S1 Terminal Assignment on pg. 142](#) for more information on this terminal.

**S2** — The default setting for this terminal is **S2**. The function of this input as **S2** is to run the motor at **Preset Speed #2** (see [Preset Speed #2 on pg. 119](#)) when it is on. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [S2 Terminal Assignment on pg. 142](#) for more information on this terminal.

**S3** — The default setting for this terminal is **S3**. The function of this input as **S3** is to run the motor at **Preset Speed #3** (see [Preset Speed #3 on pg. 120](#)) when it is on. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [S3 Terminal Assignment on pg. 142](#) for more information on this terminal.

**S4** — The default setting for this terminal is **Emergency Off** (normally closed). The function of this input as **Emergency Off** is to remove power from the output of the ASD and may apply a supplemental braking system using the method selected at the **Emg Off Mode** selection parameter. This input terminal may be programmed to any 1 of the 69 functions that are listed in [Table 6 on page 167](#). See [S4 Terminal Assignment on pg. 142](#) for more information on this terminal.

**RR** — The default function assigned to this terminal is to carry out the **Frequency Mode #1** speed control. The **RR** terminal accepts a 0 – 10 VDC input signal and controls the function assigned to this terminal. This input terminal may be programmed to control the speed or torque of the motor. It may also be used to regulate (limit) the speed or torque of the motor. The gain and bias of this terminal may be adjusted for application-specific suitability. See [RR Speed Frequency Setpoint #1 \(Hz\) on pg. 128](#) for more information on this terminal.

**RX** — This terminal has no default assignment. The **RX** terminal accepts a  $\pm 10$  VDC input signal and controls the function assigned to this terminal. This input terminal may be programmed to control the speed, torque, or direction of the motor. It may also be used to regulate (limit) the speed or torque of the motor. The gain and bias of this terminal may be adjusted for application-specific suitability. See [RX Speed Frequency Setpoint #1 \(Hz\) on pg. 138](#) for more information on this terminal.

**II** — The default function assigned to this terminal is to carry out the **Frequency Mode #2** speed control. The function of the **II** input is to receive a 4 – 20 mA input signal that controls a 0 – 80 Hz output. This input terminal may be programmed to control the speed or torque of the motor and may not be used when using the **VI** input. The gain and bias of this terminal may be adjusted separately. See [VI/II Speed Frequency Setpoint #1 \(Hz\) on pg. 163](#) for more information on this terminal.

**VI** — The default function assigned to this terminal is to carry out the **Frequency Mode #2** speed control. The function of the **VI** input terminal is to receive a 0 – 10 VDC input signal that controls a 0 – 80 Hz output. This input terminal may be programmed to control the speed or torque of the motor and may not be used when using the **II** input. The gain and bias of this terminal may be adjusted separately. See [VI/II Speed Frequency Setpoint #1 \(Hz\) on pg. 163](#) for more information on this terminal.

**P24** — +24 VDC @ 50 mA power supply for customer use.

**PP** — The function of output **PP** is to provide a 10 VDC output that may be divided using a potentiometer. The tapped voltage is applied to the **RR** input to provide manual control of the **RR** programmed function.

**OUT1** — The default setting for this output terminal is **Low Speed** (activates upon the output speed falling below the setting of parameter **F100**). This output terminal may be programmed to provide an indication that 1 of the 77 possible events listed in the *W7 ASD Operation Manual* has taken place. This function may be used to signal external equipment or to activate the brake. The **OUT1** contact is rated at 2A/250 VAC. See [OUT1 Terminal Assignment on pg. 106](#) for more information on this terminal.

**OUT2** — The default setting for this output terminal is **ACC/DEC Complete**. This output terminal may be programmed to provide an indication that 1 of 77 possible events has taken place. This function may be used to signal external equipment or to activate the brake. The **OUT2** contact is rated at 2A/250 VAC. See [OUT2 Terminal Assignment on pg. 107](#) for more information on this terminal.

**FP** — The function of this terminal is to output a series of pulses at a rate that is a function of the magnitude of the assigned parameter. The default assignment of this terminal is **Output Frequency**. As the output frequency of the ASD goes up so does the **FP** output pulse rate. This terminal may be programmed to provide output pulses at a rate that is a function of the output frequency or the magnitude of any 1 of the 33 the functions listed in [Table 8 on page 172](#). See [FP Terminal Assignment on pg. 88](#) for more information on this terminal.

**AM** — The default assignment of this terminal is **Output Current**. This output terminal produces an output current that is proportional to the output current of the ASD or of the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 8 on page 172](#). See [AM Terminal Assignment on pg. 63](#) for more information on this terminal.

**FM** — The default assignment of this terminal is **Output Frequency**. This output terminal produces an output current that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 8 on page 172](#). See [FM Terminal Assignment on pg. 87](#) for more information on this terminal.

**FLC** — The default function assigned to this terminal is **Fault All**. **FLC** is the middle leg of a single-pole double-throw (relay) switch. The **FLC** contact of the relay is switched between **FLB** and **FLA** as a function of the assigned event. This contact may be programmed to provide an indication that 1 of the 77 possible events listed in [Table 7 on page 171](#) has taken place by switching the **FLC** contact to **FLB** or **FLA**.

**FLB** — One of two contacts that, under user-defined conditions, connect to **FLC** (see [Figure 3](#)).

**FLA** — One of two contacts that, under user-defined conditions, connect to **FLC** (see [Figure 3](#)).

**Note:** *The **FLA** and **FLC** contacts are rated at 2A/250 VAC. The **FLB** contact is rated at 1A/250 VAC.*

**CC** — Control common (**Do Not** connect to **Earth Gnd**).

Figure 3. FLA, FLB, and FLC switching contacts shown in the de-energized state.

**Note:** *The relay is shown in the **Faulted** or de-energized condition. During normal system operation the relay connection is **FLC-to-FLA**.*







Figure 4. Control Terminal Strip Board.



SW1 and SW2 may be switched to change the full-scale reading of the AM and FM output terminals. See F005 and F670 for more information on the AM and FM terminals.

II Terminals

Shown below are the TB1 input and output terminals of the Control Terminal Strip Board. For further information on these terminals see pg. 17.





# W7 ASD Control

The Control Board (P/N 56000) serves as the primary control source for the W7 ASD and receives input from the Control Terminal Board, an Option Card, RS232/RS485 Communications, or the W7 EOI.

The Control Board has been enhanced to support two new functions: Multiple Protocol Communications and the ability to communicate in either half- or full-duplex modes.

Using the optional multiple-protocol communications interface: the ASD-NANOCOM, the Control Board may be configured for the type of communications protocol being received and respond appropriately to the sending device. The ASD-NANOCOM connects to the J4 and J5 connectors (see Figure 5). A jumper board (P/N 55365) is required at the J4 connector if not using the ASD-NANOCOM.


The **ASD-NANOCOM** must be setup to support the desired communications protocol via Program ⇒ **Comm Settings**. Consult the **ASD-NANOCOM User's Manual** (P/N 10572-1.000-000) for a complete listing of the setup requirements.

Half or Full duplex communications is available when using RS232/RS485 communications. The jumpers at the JP1 and the JP2 connectors may be moved from one position to the other to facilitate either half- or full-duplex operation. If no jumpers are used the system will operate in the full duplex mode.

For more information on the W7 ASD communication requirements, please visit [WWW.TIC.TOSHIBA.COM](http://WWW.TIC.TOSHIBA.COM) to acquire a copy of the **7-Series Serial Communications User Manual** (P/N 53840) (see Drives ⇒ G7 Severe Duty Industrial ⇒ **Manuals**) and [WWW.ICCDESIGNS.COM](http://WWW.ICCDESIGNS.COM) to acquire a copy of the **ASD-NANOCOM User Manual**.

Contact your Toshiba representative if more information is required on the ASD-NANOCOM.

Figure 5. Control Board of the **W7 ASD** (P/N 56000).



# CNU1/1A and CNU2/2A Pinout

Control Board CNU1/1A and CNU2/2A pinout (RJ-45 connectors).

Pin #	CNU1 Pinout (Control Board)	CNU1A Pinout (EOI)	Pin #	CNU2 Pinout (Control Board)	CNU2A Pinout (EOI)
1	P24	P24	1	P24	P24
2	Gnd	Gnd	2	Gnd	Gnd
3	Tx (-)	RXA	3	Rx	Tx
4	Rx (+)	TXA	4	Gnd	Gnd
5	Rx (-)	TXB	5	Tx	Rx
6	Tx (+)	RXB	6	Gnd	Gnd
7	RS232/RS485	CNU3 Pin-7	7	Open	Open
8	Gnd	Gnd	8	Gnd	Gnd

## CN3 Pinout

CN3 of the Control Board is used for 2-wire RS485 serial communications.

Pin Number	CN3 Pinout (Controller PCBA)
1	RS485 Signal +
2	RS485 Signal -
3	RS485 Signal Gnd.
4	Shield

*Note:* CNU2 or CNU3 may be used for RS485 communication — Cannot use both.

## CN7 Pinout











CN7 of the Control Board connects to CN7A of the Control Terminal Strip PCBA.

**Table 3.** CN7 pinout assignments. Programmable terminals are listed as their default settings.

Pin Number	Function	Pin Number	Function
1	PP	14	II
2	FL	15	S1
3	VI	16	R
4	RR	17	S3
5	FM	18	S2
6	RX	19	N15
7	FP	20	S4
8	AM	21	P15
9	*OUT1	22	P24
10	*OUT2	23	CC
11	ST	24	CC
12	RES	25	CC
13	F	—	—

*Note:* \* Open collector outputs.


# I/O Circuit Configurations

<p><b>Figure 6. Discrete Input.</b></p>  <p>Configured Sink (may be configured Source)</p>	<p><b>Figure 7. RR Input.</b></p>  <p>33k Input Impedance</p>
<p><b>Figure 8. RX Input.</b></p>  <p>69k Input Impedance</p>	<p><b>Figure 9. VI/II Input.</b></p>  <p>33k Input Impedance</p> <p>VI and II inputs may not be used simultaneously.</p>
<p><b>Figure 10. P24 Output.</b></p>  <p>24 VDC 50 mA Max.</p> <p>100 mA</p> <p>0.1 μF</p> <p>Fuse resets after high current is removed.</p>	<p><b>Figure 11. PP Output.</b></p>  <p>10 VDC (output)</p> <p>10 VDC 10 mA Max.</p> <p>4.7 μF</p>
<p><b>Figure 12. OUT1/OUT2 Output.</b></p>  <p>2A/250VAC</p> <p>Programmable Input</p>	<p><b>Figure 13. FP Output.</b></p>  <p>1 to 43.2 KHz 50 mA max.</p> <p>3.9k</p> <p>10k</p> <p>Programmable Input</p>
<p><b>Figure 14. FM/AM Output.</b></p>  <p>10 VDC Max. 20 mA Max.</p> <p>0.1 μF</p> <p>4.7k</p> <p>Programmable</p>	<p><b>Figure 15. Fault Relay (active fault).</b></p>  <p>2A/250VAC</p> <p>1A/250VAC</p> <p>2A/250VAC</p> <p>Programmable Input</p>

# Typical Connection Diagram

Figure 16. W7 ASD typical connection diagram.

**Note:** When connecting multiple wires to the PA, PB, PC, or PO terminals, do not connect a solid wire and a stranded wire to the same terminal.



DO NOT CONNECT CC TO EARTH GROUND.



# Electronic Operator Interface

The **W7 ASD Electronic Operator Interface (EOI)** is comprised of an LCD display, two LEDs, a rotary encoder, and eight keys. These items are described below and their locations are provided in [Figure 17 on pg. 28](#).

The **EOI** can be mounted remotely from the ASD as described in the section titled [EOI Remote Mounting on pg. 30](#). The dimensional requirements for remote mounting may also be found there. Using a screw length that exceeds the specified dimensions may cause deformation of the outer surface of the bezel as shown in [Figure 20 on pg. 32](#) and should be avoided.

The interface can operate up to distances of 15 feet from the ASD via the Common Serial (TTL) Port. For distances beyond 15 feet, the RS232/RS485 port is recommended.

## EOI Features

**LCD Display** — Displays configuration information, performance data (e.g., motor frequency, bus voltage, output power, etc.), and diagnostic information.

**Local|Remote Key** — Toggles the system to and from the **Local** and **Remote** modes. The LED is on when the system is in the **Local Command** mode.

The **Local Command** mode enables the **Command** and **Frequency** control functions to be carried out via the **EOI**.

The **Remote** mode enables the **Command** and **Frequency** control functions to be carried out via any one of the following methods:

- Pulse Input,
- Motorized Pot,
- Communication Card,
- RS232/RS485,
- Common TTL,
- Binary/BCD,
- LED Keypad,
- Option Card RX2,
- RX,
- RR, or
- VI/II.

The input channel selection may be made via Program ⇒ Utilities ⇒ **CMD, FRQ, & Carrier**.

**Enter Key** — Selects a menu item to be changed or accepts and records the changed data of the selected field (same as pressing the **Rotary Encoder**).

**Esc Key** — Returns to the previous level of the menu tree, toggles between the **Panel** screen and the **Frequency Command** screens, or cancels changes made to a field if pressed while still in the reverse video mode (dark background/light text). The 3 functions are menu-specific.

**Run Key** — Issues the **Run** command while in the **Local** mode. A **Run** command issued from the **EOI** while in the **Remote** mode will be activated once the **Local** mode is selected and the motor will run at the commanded speed.

**Run Key Status LED** — Illuminates green while stopped or red while running.

**Stop Key** — If pressed once while in the **Local** mode issues the **Off** command and decelerates the motor at the programmed rate until it stops. If pressed twice in rapid succession initiates an **Emergency Off** (terminates the ASD output and applies the brake if so configured) from the **Local** or **Remote** modes.


**Up Key** — Increases the value of the selected parameter or scrolls up the menu listing (continues during press-and-hold).

**Down Key** — Decreases the value of the selected parameter or scrolls down the menu listing (continues during press-and-hold).

**Rotary Encoder** — Functions as the **Up** key, the **Down** key, and the **Enter** key. Turn the **Rotary Encoder** either clockwise or counterclockwise to perform the **Up** or **Down** key functions. Press the **Rotary Encoder** to perform the **Enter** function. Press the **Rotary Encoder** while turning to increase the effectiveness of the **Rotary Encoder**. The Up/Down-Clockwise/Counter Clockwise **Rotary Encoder** relationship to menu changes may be changed via Program ⇒ EOI Options ⇒ Encoder Action ⇒ **Encoder Direction (UP)** (Up may be set to clockwise or counter clockwise).

**MON/PRG Key** (Monitor/Program) — Provides a means to access the three root menus. Pressing the **MON/PRG** key repeatedly loops the system through the three root menus (see [Figure 23 on pg. 35](#)). While looping through the root menus, the **Program** menu will display the last menu screen or sub-menu item being accessed at the time that the **MON/PRG** key was pressed.

Figure 17. The W7 ASD Electronic Operator Interface.



## EOI Operation

The **EOI** is the primary input/output device for the user. The **EOI** may be used to monitor system functions, input data into the system, or perform diagnostics.

*Note: The Up/Down arrow keys and the Enter key may be used to perform the functions of the Rotary Encoder. The Rotary Encoder will be used in this explanation and throughout this manual for the Up, Down, and Enter key functions.*

The software used with the **W7 ASD** is menu driven; thus, making it a select and click environment. The operating parameters of a motor may be selected and viewed or changed using the **EOI**.

To change a parameter setting, go to the **Program** mode by pressing the **MON/PRG** key until the **Program** menu is displayed. Turn the **Rotary Encoder** until the desired parameter group is within the cursor block. Press the **Rotary Encoder** (repeat if there is a submenu).

The selection will take on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the value of the parameter. Press the **Esc** key while the display is in the reverse video mode to exit the menu without saving the change or press the **Rotary Encoder** to accept the new setting.

Repeated **ESC** key entries takes the menu back one level each time the **ESC** key is pressed until the root level is reached. After reaching the root level, continued **ESC** entries will toggle the system to and from the **Frequency Command** screen and the **Panel** screen.

*Note:* **Panel** menu changes entered here will affect *EOI-controlled ASD operation only*.

# EOI Remote Mounting

The **W7 ASD** may be controlled from a remotely-mounted **EOI**. For safety and application-specific reasons, some ASD installations will warrant that the operator not be in the vicinity during operation or that the **EOI** not be attached to the ASD housing. The **EOI** may be mounted either with or without the optional W7 ASD Remote Mounting Kit (P/N ASD-MTG-KIT). The ease of installation is enhanced by the W7 ASD Remote Mounting Kit which allows for easier cable routing and **EOI** placement.

The **EOI** can operate up to distances of 15 feet from the ASD via the Common Serial (TTL) Port. For distances beyond 15 feet, the RS232/RS485 port is recommended.

Remote mounting will also allow for multiple **EOI** mountings at one location if controlling and monitoring several ASDs from a central location is required.

The optional dust cover (P/N ASD-BPC) may be used to cover the front panel opening of the ASD housing after removing the **EOI**. An **EOI** extender cable is required for remote mounting. **EOI** extender cables are available in lengths of 7, 10, or 15 feet and may be ordered through your sales representative.

## Remote EOI Required Hardware

### EOI Mounting Hardware

- 6-32 x 5/16" Pan Head Screw — P/N 50595 (4 ea.)
- #6 Split-Lock Washer — P/N 01884 (4 ea.)
- #6 Flat Washer — P/N 01885 (4 ea.)

### Bezel Plate Mounting Hardware

- Bezel Plate — P/N 52291
- 10-32 Hex Nut — P/N 01922 (4 ea.)
- #10 Split-Lock Washer — P/N 01923 (4 ea.)
- #10 Flat Washer — P/N 01924 (4 ea.)
- Dust Cover — P/N ASD-BPC (Optional)

### Extender Cables

- ASD-CAB7F: Cable, RJ45, 7 ft.
- ASD-CAB10F: Cable, RJ45, 10 ft.
- ASD-CAB15F: Cable, RJ45, 15 ft.

# EOI Installation Precautions

Install the unit securely in a well ventilated area that is out of direct sunlight using the four mounting holes of the **EOI**. The ambient temperature rating for the **EOI** is 14 to 104° F (-10 to 40° C).

- Select a mounting location that is easily accessible by the user.
- Avoid installation in areas where vibration, heat, humidity, dust, metal particles, or high levels of electrical noise (EMI) are present.
- Do not install the **EOI** where it may be exposed to flammable chemicals or gasses, water, solvents, or other fluids.
- Turn the power on only after securing the front cover to the ASD.


# EOI Remote Mounting w/o the ASD-MTG-KIT

*Note:* See [Figure 18](#) for the dimensions and the item locations referenced in steps 1 through 5.

1. At the **EOI** mounting location, identify and mark the location of the 3.80" by 3.29" hole and the 7/32" screw holes.
2. Cut the 3.80" by 3.29" rectangular hole.
3. Drill the four 0.22" screw holes.
4. Attach and secure the **EOI** to the front side of the mounting location using the four 6-32 x 5/16" pan head screws, the #6 flat washers, and the #6 split lock washers.
5. Connect the RJ-45 extension cable(s).

# EOI Dimensions (mounting)

Figure 18. EOI Mounting Dimensions.



# EOI Remote Mounting using the ASD-MTG-KIT

**Note:** See Figures 19 and 20 for the dimensions and the item locations referenced in steps 1 through 6.

1. At the **EOI** mounting location, identify and mark the locations of the 5.00" by 4.60" hole and the four 11/32" screw holes.
2. Cut the 5.00" by 4.60" rectangular hole.
3. Drill the four 11/32" holes.
4. Attach and secure the Bezel plate to the front side of the mounting location using the four 10-32 hex nuts, #10 split lock washers, and the #10 flat washers.
5. Attach and secure the **EOI** to the front side of the Bezel plate using the four 6-32 x 5/16" pan head screws, the #6 flat washers, and the #6 split lock washers.
6. Connect the RJ-45 extension cable(s).

## EOI ASD-MTG-KIT Dimensions (mounting)

Figure 19. EOI Bezel Plate Mounting Dimensions.





Figure 20. Screw Length Precaution.

**CAUTION:** Failure to use the correct hardware may result in damage to the outer surface of the EOI panel and/or improper seating of the panel to the bezel plate. Use caution when mounting the EOI assembly to ensure that the internal thread clearance is maintained.



# System Operation

## Operation (Local)

**Read and understand all safety warnings before operating this equipment!**

To run the motor perform the following steps:

1. Press the **MON/PROG** key until the **Frequency Command** screen is displayed (see [Figure 23 on pg. 35](#)).
2. Place the system in the **Local** mode (green **Local** LED illuminated) by pressing the **Local|Remote** key.
3. Ensure that there are no personnel around or near the motor or the motor-driven equipment.
4. Using the **Rotary Encoder** dial in a speed setting at the **Set** field and press the **Rotary Encoder**.
5. Press the **Run** key (illuminated green **RUN** LED turns red) and the motor accelerates to the set speed at the (default) programmed rate. The speed may be changed while running.
6. Press the **Stop|Reset** key to stop the motor.

## Default Setting Changes

To change a parameter setting using the EOI, press the **MON/PRG** key until the **Program** menu is displayed.

From the **Program** menu scroll to the desired parameter group and press the **Rotary Encoder** — Repeat for sub-menu items. Once reaching the lowest level of a parameter group, scroll to the parameter to be changed and press the **Rotary Encoder**.


The parameter takes on the reverse video format (dark background/light text). Use the **Rotary Encoder** to scroll to the new value or setting. Press the **ESC** key to exit without saving the parameter change while still in the reverse video mode or press the **Rotary Encoder** to accept and save the change.

For a complete listing of the **Program** menu items, see the section titled [Program Menu Navigation on pg. 39](#). The menu items are mapped for convenience. The **Direct Access Numbers** are listed where applicable. The Direct Access numbers are also listed chronologically in the section titled [W7 ASD Direct Access/Communication Numbers on pg. 51](#).

The default settings may also be changed by entering the **Parameter Number** of the setting to be changed at the **Direct Access** menu (Program ⇒ Direct Access ⇒ *Applicable Parameter Number*). A listing of all parameters that have been changed from the default setting may be viewed sequentially by accessing the **Changed From Default** screen (Program ⇒ **Changed From Default**).

*Note:* Parameter **009** was changed to create the example shown in [Figure 21](#).

**Figure 21.** Changed From Default screen.



The **Changed From Default** feature allows the user to view (or change) the parameters that are different from the default or the post-reset settings. Once the **Changed From Default** screen is displayed, the system scrolls through all of the system parameters and halts once reaching a changed parameter.

The **Rotary Encoder** may be clicked once clockwise to continue scrolling forward or clicked once counterclockwise to begin scrolling in reverse. With each click of the **Rotary Encoder** from a stop, the system scrolls through the parameters and stops at the next parameter that has been changed.

Pressing the **Rotary Encoder** while a changed parameter is displayed accesses the settings of the changed parameter for viewing or changing.

Pressing **ESC** while the system is performing a **Changed From Default** search terminates the search. Pressing **ESC** when done searching (or halted at a changed parameter) returns the system to the **Program** menu.

Parameter settings may also be changed via **Communications**. See the *7-Series Serial Communications Manual* (P/N 53840) for further information on using communications to change parameter settings. *The 7-Series Serial Communications Manual* may be acquired from the TIC.TOSHIBA.COM website at Drives ⇒ G7 Severe Duty Industrial ⇒ **Manuals** or from your Toshiba Sales Representative.




# System Configuration and Menu Options

## Root Menus

The **MON/PRG** key is used to access the three root menus of the **W7 ASD**: the **Frequency Command** screen, the **Monitor** screen, and the **Program** screen. From either mode, press the **MON/PRG** key to loop through to the other modes (see [Figure 22](#)).

In the event of a fault, the **W7 ASD** displays the fault screen and provides an on-screen indication of the fault type. The **Fault** screen remains in the **MON/PRG** screen rotation (see [Figure 22](#)) until the source of the fault is removed and the ASD is reset.

**Figure 22.** Root Menu Mapping.




## Frequency Command Screen

### Frequency Setting

While operating in the **Local** mode (**Local** LED is illuminated on the EOI), the running frequency of the motor may be set from the **Frequency Command** screen. Using the **Rotary Encoder**, enter the desired **Frequency Command** value, press the **Enter** key and then press the **Run** key. The motor will run at the **Frequency Command** speed and may be changed while running. The **Frequency Command** screen is not displayed during an active trip.

**Figure 23.** Frequency Command Screen.



The **Panel Menu** screen provides easy-access to the most common setup parameters. **Panel Menu** changes will affect EOI-controlled ASD operation only and is accessed by pressing the **ESC** key from the **Frequency Command** screen.

# Monitor Screen

The **Monitor** screen reports the status of motor performance variables, control settings, and configuration data during motor operation. There are 37 monitored items that may be viewed from this screen. The items are listed and described below.

The monitored items listed may be selected and displayed at the **Frequency Command** screen while the ASD is running. See Program ⇒ System Information and Setup ⇒ **Scrolling Monitor** to select the monitored items to be displayed.

*Note: The **Monitor** screen lists the read-only running status and the at-trip status of the listed parameters.*

**Run Frequency** — If tripped, this field records the at-trip frequency. Otherwise, the current output frequency is displayed.

**Frequency Reference** — Displays the current frequency command.

**Output Current** — Shows the instantaneous output current as a percentage of the rating of the ASD or as a current.

**Bus Voltage** — Shows the instantaneous DC bus voltage as a percentage of the rating of the ASD or as a voltage.

**Output Voltage** — Shows the instantaneous output voltage as a percentage of the rating of the ASD or as a voltage.

**Input Terminals** — Shows the status of the discrete input terminals.

**Output Terminals** — Shows the status of the discrete output terminals.

**Timer** — Displays the accumulated run-time since the last reset or power up of the ASD.

**Post Compensation Frequency** — Displays the output frequency of the ASD after the application of the waveform adjustment compensation for changes in the input voltage.

**Feedback Instantaneous** — Displays the instantaneous PID feedback value.

**Feedback 1-Second** — Displays the filtered PID feedback value.

**Torque** — Displays the torque output.

**Torque Reference** — Displays the commanded torque.

**Torque Current** — Displays the torque current.

**Excitation Current** — Displays the excitation current.

**PID Value** — Displays the instantaneous PID feedback value.

**Motor Overload** — Displays the relationship of time to the magnitude of the motor overload as a ratio. A higher overload means a shorter run-time in this condition.

**ASD Overload** — Displays the relationship of time to the magnitude of the ASD overload as a ratio. A higher overload means a shorter run-time in this condition.

**DBR Overload** — Displays the relationship of time to the magnitude of the DBR overload as a ratio. A higher overload means a shorter run-time in this condition.

**Motor Load** — Shows the instantaneous motor load requirements.

**ASD Load** — Shows the instantaneous load placed on the ASD.

**DBR Load** — Shows the instantaneous load placed on the DBR.

**Input Power** — Shows the instantaneous input power level to the ASD.

**Output Power** — Shows the instantaneous output power level of the ASD.

**Peak Current** — Shows the highest current level achieved since the last startup or reset. This value is displayed as a percentage of the full rating of the ASD or as an amperage.

**Peak Voltage** — Shows the highest voltage level achieved since the last startup or reset. This value is displayed as a percentage of the full rating of the ASD or as an amperage.

**PG Speed** — Shows the instantaneous speed as detected by the shaft-mounted encoder.

**Direction** — Shows the direction of the motor rotation.

**PG Position** — Shows the instantaneous PG position as detected by the shaft-mounted encoder.

**RR** — Displays the RR input as a percentage of its full range.

**\*VI/II** — Displays the VI/II input as a percentage of the full range of the VI/II value.

*Note: The VI/II input represents two analog inputs. The VI input is used for a 0 – 10 VDC analog signal and the II input is used for current loop applications, such as with a 4-20 mA signal. Either may be used as a frequency or torque command source; however, the two cannot function simultaneously.*

**RX** — Displays the RX input as a percentage of its full range.

**RX2** — Displays the RX2 input as a percentage of its full range.

**FM** — Displays the FM output as a percentage of its full range.

**AM** — Displays the AM output as a percentage of its full range.

**Option Type** — TBD.

**Option Terminal A** — TBD.

**Option Terminal B** — TBD.

**Option Terminal O** — TBD.

**Option Terminal P** — TBD.

**Maximum Output** — TBD.

**Direction** — Displays the ASD Forward/Reverse status (not available at the Scrolling Monitor).

## Program Screen

The **Program Menu** allows the user access to parameters that setup the input and output specifications of the **W7 ASD**. Many of these settings are application-specific and may require user input.

See the section titled [Program Menu Navigation on pg. 39](#) for a complete listing of the W7 ASD parameters and for menu navigation assistance.

# Program Menu Navigation

Table 4 lists the menu items of the **Program** mode and maps the flow of the menu selections. The **Parameter Numbers** for the listed functions are provided where applicable. The functions listed may be accessed (and changed) as mapped below or via the **Direct Access** method: Program ⇒ Direct Access ⇒ *Applicable Parameter Number*.

See the *W7 Operation Manual* for more in-depth information on the menu items listed.

**Table 4. Program mode mapping.**

<b>Program Menu Navigation</b>			
<b>Primary Menu</b>	<b>Sub Menu</b>	<b>Parameter Name</b>	<b>Parameter Number</b>
<b>FUNDAMENTALS</b>	<b>Fundamentals #1</b>	Maximum Output Frequency	0011
		#1 Base Frequency	0014
		Supply Voltage Compensation	0307
		Maximum Output Voltage #1	0306
		Disable Forward Run	0311
		Disable Reverse Run	
		Upper Limit Frequency	0012
		Lower Limit Frequency	0013
		V/f Pattern	0015
		Torque Boost #1	0016
		Acceleration Time #1	0009
		Deceleration Time #1	0010
		Acceleration/Deceleration Pattern #1	0502
		S-Pattern Lower Limit Adjustment	0506
		S-Pattern Upper Limit Adjustment	0507
	<b>Fundamentals #2</b>	Base Frequency #2	0170
		Maximum Output Voltage #2	0171
		Torque Boost #2	0172
		Electronic Thermal Protection #2	0173
		Acceleration Time #2	0500
		Deceleration Time #2	0501
		Acceleration/Deceleration Pattern #2	0503
	Acceleration/Deceleration #1/#2 Switching Frequency	0505	
<b>SYSTEM INFO &amp; SETUP</b>	<b>Setup</b>	Acceleration Time #1	0009
		Deceleration Time #1	0010
		Upper Limit Frequency	0012
		Lower Limit Frequency	0013
		VI/II Speed Reference Setpoint #1	0201
		VI/II Speed Frequency Setpoint #1	0202
		VI/II Speed Reference Setpoint #2	0203
		VI/II Speed Frequency Setpoint #2	0204
		Type Reset	0007

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>SYSTEM INFO &amp; SETUP</b>	<b>Setup</b>	V/f Pattern	0015
		Switch-on-the-Fly	0961
		Electronic Thermal Protection #1	0600
	<b>PID Setup</b>	Feedback Input	0360
		Delay Filter	0361
		Proportional (P) Gain	0362
		Integral (I) Gain	0363
		Deviation Upper Limit	0364
		Deviation Lower Limit	0365
		Differential (D) Gain	0366
		Upper Limit Frequency	0012
		Lower Limit Frequency	0013
		Acceleration Time #1	0009
		Deceleration Time #1	0010
		Low-output Disable	0731
		Low-output Disable Start Level	0732
		Low-output Disable Delay Time	0733
		Low-output Disable Boost Level	0734
		Low-output Disable Boost Time	0735
		Low-output Disable Feedback Level	0736
		Low-output Disable Restart Delay	0737
		4–20 mA Loss	0962
		4–20 mA Speed Reference	0964
	PID Feedback Value	N/A	
	<b>Trip History</b>	Trip Number	N/A
		Trip Type	
		Trip Time and Date	
		Frequency	
		Output Current	
		Output Voltage	
		Direction	
		Frequency Reference	
		DC Bus Voltage	
Discrete Input Terminals			
Discrete Output Terminals			
Run Timer			
Post-compensation Frequency			
Speed Feedback (realtime)			
Speed feedback (filtered)			

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>SYSTEM INFO &amp; SETUP</b>	<b>Trip History</b>	Torque Feedback	N/A
		Torque Reference	
		Torque Current	
		Excitation Current	
		PID Feedback Value	
		Motor Overload Ratio	
		ASD Overload Ratio	
		DBR Overload Ratio	
		Motor Load	
		ASD Load	
		DBR Load	
		Input Power	
		Output Power	
		Peak Output Current	
		Peak DC Voltage	
		PG Speed	
	PG Position		
	<b>Scrolling Monitor</b>	Display Seconds	N/A
		Parameter Display Selections	
	<b>Password Control</b>	Enter Password	N/A
		Password Enable	
	<b>Local/Remote Key</b>	Command	N/A
		Frequency	
	<b>Contrast</b>	Lighter	N/A
		Darker	
	<b>Realtime Clock Setup</b>	Set Realtime Clock Time and Date	N/A
	<b>CHANGED FROM DEFAULT</b>		(See the section titled <a href="#">Default Setting Changes on pg. 33.</a> )
<b>DIRECT ACCESS</b>		Parameter Number Input	N/A
		Enable Unknown Numbers	
<b>UTILITIES</b>	<b>Version</b>	ASD Type	N/A
		CPU Version	
		CPU Revision	
		Control Board EEPROM Version	
		EOI Version	
	<b>Display Attributes</b>	Hz per User-defined Unit	0702
		Frequency Display Resolution	0703
		Acc/Dec Special Display Resolution	0704
		Units for Voltage and Current	0701

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>UTILITIES</b>	<b>Display Attributes</b>	User -defined Units	N/A
	<b>Type Reset</b>	Auto Setup for 50 Hz Operation	0007
		Auto Setup for 60 Hz Operation	
		Restore Factory Defaults	
		Clear Past Trips	
		Clear Run Timer	
		New Base Drive Board	
		Save User Settings	
		Restore User Settings	
		Upgrade EOI Firmware	
	Set EOI Memory to Default		
	<b>Command, Frequency, and Carrier Frequency</b>	Command Mode	0003
		Frequency Mode #1	0004
		PWM Carrier Frequency	0300
Ramped PWM		0963	
<b>FREQUENCY SETTINGS</b>	<b>Speed Reference Setpoints</b>	VI/II Speed Reference Setpoint #1	0201
		VI/II Speed Frequency Setpoint #1	0202
		VI/II Speed Reference Setpoint #2	0203
		VI/II Speed Frequency Setpoint #2	0204
		VI/II Bias	N/A
		VI/II Gain	
		RR Speed Reference Setpoint #1	0210
		RR Speed Frequency Setpoint #1	0211
		RR Speed Reference Setpoint #2	0212
		RR Speed Frequency Setpoint #2	0213
		RR Bias	N/A
		RR Gain	
		RX Speed Reference Setpoint #1	0216
		RX Speed Frequency Setpoint #1	0217
		RX Speed Reference Setpoint #2	0218
		RX Speed Frequency Setpoint #2	0219
		RX Bias	N/A
		RX Gain	
		RX2 Speed Reference Setpoint #1	0222
		RX2 Speed Frequency Setpoint #1	0223
		RX2 Speed Reference Setpoint #2	0224
		RX2 Speed Frequency Setpoint #2	0225
		RX2 Bias	N/A
		RX2 Gain	



<b>Program Menu Navigation</b>			
<b>Primary Menu</b>	<b>Sub Menu</b>	<b>Parameter Name</b>	<b>Parameter Number</b>
<b>FREQUENCY SETTINGS</b>	<b>Speed Reference Setpoints</b>	BIN Speed Reference Setpoint #1	0228
		BIN Speed Frequency Setpoint #1	0229
		BIN Speed Reference Setpoint #2	0230
		BIN Speed Frequency Setpoint #2	0231
		PG Speed Reference Setpoint #1	0234
		PG Speed Frequency Setpoint #1	0235
		PG Speed Reference Setpoint #2	0236
		PG Speed Frequency Setpoint #2	0237
	<b>Reference Priority</b>	Reference Priority	0200
		Frequency Mode #2	0207
		Mode #1/#2 Switching Frequency	0208
	<b>Jog Settings</b>	Jog Run Frequency	0260
		Jog Stop Control	0261
		Enable Jog Window	N/A
	<b>TORQUE SETTINGS</b>	<b>Torque Reference Setpoints</b>	VI/II Output-Torque Reference Setpoint #1
VI/II-Input Torque Setpoint #1			0201
VI/II Output-Torque Reference Setpoint #2			0206
VI/II-Input Torque Setpoint #2			0203
RR Output-Torque Reference Setpoint #1			0214
RR-Input Torque Setpoint #1			0210
RR Output-Torque Reference Setpoint #2			0215
RR-Input Torque Setpoint #2			0212
RX Output-Torque Reference Setpoint #1			0220
RX-Input Torque Setpoint #1			0216
RX Output-Torque Reference Setpoint #2			0221
RX-Input Torque Setpoint #2			0218
RX2 Output-Torque Reference Setpoint #1			0226
RX2-Input Torque Setpoint #1			0222
RX2 Output-Torque Reference Setpoint #2			0227
RX2-Input Torque Setpoint #2			0224
BIN Output-Torque Reference Setpoint #1			0232
BIN-Input Torque Setpoint #1			0228
BIN Output-Torque Reference Setpoint #2			0233
BIN-Input Torque Setpoint #2			0230
<b>Torque Control</b>		Torque Command	0420
		Torque Command Filter	0421
		Synchronized Torque Bias Input	0422
		Tension Torque Bias Input	0423
		Load Sharing Gain Input	0424

Program Menu Navigation				
Primary Menu	Sub Menu	Parameter Name	Parameter Number	
<b>TORQUE SETTINGS</b>	<b>Torque Limit</b>	Power Running Torque Limit #1	0440	
		Regenerative Torque Limit #1	0442	
		Torque Limit Mode	0450	
		Torque Limit Mode (speed-dependent)	0451	
	<b>Manual Torque Limit</b>	Manual Torque Limit #1	0441	
		Manual Torque Limit #2	0444	
		Manual Torque Limit #3	0446	
		Manual Torque Limit #4	0448	
	<b>Torque Speed Limit</b>	Torque Command Mode	0429	
		Forward Speed Limit Input	0425	
		Forward Speed Limit Level	0426	
		Reverse Speed Limit Input	0427	
		Reverse Speed Limit Level	0428	
		Speed Limit Reference	0430	
		Speed Limit Level	0431	
		Speed Limit Band	0432	
	Speed Limit Recovery Time	0433		
	<b>MOTOR SETTINGS</b>	<b>Motor Set #1</b>	Base Frequency #1	0014
			Maximum Output Voltage #1	0306
Torque Boost #1			0016	
Electronic Thermal Protection #1			0600	
<b>Motor Set #2</b>		Base Frequency #2	0170	
		Maximum Output Voltage #2	0171	
		Torque Boost #2	0172	
		Electronic Thermal Protection #2	0173	
<b>Motor Set #3</b>		Base Frequency #3	0174	
		Maximum Output Voltage #3	0175	
		Torque Boost #3	0176	
		Electronic Thermal Protection #3	0177	
<b>Motor Set #4</b>		Base Frequency #4	0178	
		Maximum Output Voltage #4	0179	
		Torque Boost #4	0180	
		Electronic Thermal Protection #4	0181	
<b>Vector Motor Model</b>		Autotune Control	0400	
		Slip Frequency Gain	0401	
		Motor Constant #1 (primary resistance)	0402	
		Motor Constant #2 (secondary resistance)	0403	
	Motor Constant #3 (exciting inductance)	0404		
	Motor Constant #4 (load inertia moment)	0405		
Motor Constant #5 (leak inductance)	0410			

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>MOTOR SETTINGS</b>	<b>Motor Settings</b>	Number of Motor Poles	0411
		Rated Capacity of Motor	0412
		Motor Type	0413
	<b>Autotune Enable</b>	Autotune Enable	0414
<b>COMMUNICATION</b>	<b>Communication Settings</b>	ASD Number	0802
		Communication Baud Rate (TTL)	0800
		Communication Baud Rate (RS232/RS485)	0820
		Parity	0801
		Communication Time-Out	0803
		Communication Time-Out Action (TTL)	0804
		Communication Time-Out Action (RS232/RS485)	
		Communication Interval (TTL)	0805
		RS232/RS485 Wire Count	0821
		RS232/RS485 Delay Time	0825
		TTL Master Output for Follower	0806
		RS232/RS485 Master Output for Follower	0826
	<b>Communication Reference Adjust</b>	Frequency Reference Point	0810
		Communication Reference Setpoint #1	0811
		Communication Frequency Reference Setpoint #1	0812
		Communication Reference Setpoint #2	0813
		Communication Frequency Reference Setpoint #2	0814
	<b>S20 Settings</b>	S20 feature is unavailable at the time of this release	N/A
	<b>Scan Settings</b>	Scan feature is unavailable at the time of this release	N/A
	<b>External Settings</b> (used with optional Nanocomm – see ASD Nanocomm Manual)	External Communication Configuration #1	N/A
		External Communication Configuration #2	
		External Communication Configuration #3	
		External Communication Configuration #4	
External Communication Configuration #5			
External Communication Configuration #6			
External Communication Configuration #7			
External Communication Configuration #8		N/A	
<b>FEEDBACK SETTINGS</b>	Feedback Input (PID Enable)	0360	
	Proportional (P) Gain	0362	
	Integral (I) Gain	0363	
	Differential (D) Gain	0366	

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>FEEDBACK SETTINGS</b>		Delay Filter	0361
		Upper Deviation Limit	0364
		Lower Deviation Limit	0365
		4–20 mA Loss	0962
		4–20 mA Speed Reference	0964
		Number of PG Input Pulses	0367
		PG Input Phases	0368
		PG Disconnect Detection	0369
<b>PROTECTION SETTINGS</b>	<b>Dynamic Braking</b>	Dynamic Braking Enable	0304
		Dynamic Braking Resistance	0308
		Dynamic Braking Resistance Capacity	0309
	<b>Stall</b>	Overcurrent Stall Level	0601
		Overvoltage Stall	0305
		Overvoltage Stall Level	0626
		Overvoltage Stall Level (fast)	0625
		Continuing Stall Period	0452
		Stall Prevention During Regeneration	0453
		<b>DC Injection Braking</b>	Start Frequency
	Start Current Level		0251
	DC Injection Braking Time		0252
	DC Injection Braking During Direction Change		0253
	Motor Shaft Stationary Control		0254
	<b>Retry/Ridethrough</b>	Emergency Off (EOFF) Mode	0603
		DC Injection EOFF Mode Time	0604
		Number of Retries	0303
		Restart Conditions	0301
		Scan Rate	0312
		Lock On Rate	0313
		Search Method	0314
		Search Inertia	0315
		Ridethrough Mode	0302
		Ridethrough Time	0310
	<b>Undervoltage</b>	Undervoltage Stall Level	0629
		Undervoltage Trip	0627
		Undervoltage Detection Time	0628
	<b>Overload</b>	Overload Reduction Starting frequency	0606
		Motor 150% Overload Time Limit	0607
		Soft Stall Selection	0017
	<b>Trip/Fan/Timer</b>	Trip Settings	0602

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>PROTECTION SETTINGS</b>	<b>Trip/Fan/Timer</b>	Fan Control Mode	0620
		Cumulative Run Timer Alarm	0621
	<b>Phase Loss</b>	Output Phase Loss Detection	0605
	<b>Low Current</b>	Low Current Trip	0610
		Low Current Trip Threshold Level	0611
		Low Current Trip Threshold Time	0612
	<b>Abnormal Speed</b>	Abnormal Speed Detection Filter	0622
		Overspeed Detection Frequency Range	0623
		Speed Drop Detection Frequency Range	0624
	<b>Short Circuit Test</b>	Output Short Circuit Test	0613
		Output Short Circuit Test Duration	0614
	<b>Overtorque</b>	Overtorque Trip	0615
		Overtorque Trip/Alarm Level (Positive Torque)	0616
		Overtorque Trip/Alarm Level (Negative Torque)	0617
		Overtorque Detection Time	0618
		Braking Fault Internal Timer	0630
		Brake Release After Run Timer	0632
		Inrush Current Suppression Time (relay delay)	0608
		Interlock Inrush Relay With ST Terminal	0609
		Adding Input Selection	0660
		Multiplying Input Selection	0661
	<b>Earth Fault</b>	Earth Fault Alarm Level	0640
		Earth Fault Alarm Time	0641
		Earth Fault Trip Level	0642
Earth Fault Trip Time		0643	
<b>TERMINAL SETTINGS</b>	<b>Input Terminals</b>	F	0111
		R	0112
		ST	0113
		RES	0114
		S1	0115
		S2	0116
		S3	0117
		S4	0118
		S5	0119
		S6	0120
		S7	0121
		S8	0122
		S9	0123
		S10	0124

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>TERMINAL SETTINGS</b>	<b>Input Terminals</b>	S11	0125
		S12	0126
		ON	0110
	<b>Input Other</b>	ST Signal Selection	0103
		F/F Priority Selection	0105
		Input Terminal Priority	0106
		Extended Terminal Function	0107
	<b>Output Terminals</b>	OUT1	0130
		OUT2	0131
		FL	0132
		OUT4	0133
		OUT5	0134
		OUT6	0135
		OUT7	0136
	<b>Speed Reach</b>	Low Speed Signal Output Frequency	0100
		Speed Reach Frequency	0101
		Speed Reach Band Width	0102
	<b>FP Terminal</b>	FP Terminal Assignment	0676
		FP Terminal Adjustment	0677
	<b>Input Terminal Delay</b>	F	0140
		R	0141
		ST	0142
		RES	0143
		S1-S4	0144
		S5-S16	0145
	<b>Output Terminal Delays</b>	OUT1 On Delay	0150
		OUT1 Off Delay	0160
		OUT2 On Delay	0151
		OUT2 Off Delay	0161
		FL On Delay	0152
		FL Off Delay	0162
		OUT4 On Delay	0153
		OUT4 Off Delay	0163
OUT5 On Delay		0154	
OUT5 Off Delay		0164	
OUT6 On Delay		0155	
OUT6 Off Delay		0165	
OUT7 On Delay		0156	
OUT7 Off Delay		0166	

<b>Program Menu Navigation</b>			
<b>Primary Menu</b>	<b>Sub Menu</b>	<b>Parameter Name</b>	<b>Parameter Number</b>
<b>TERMINAL SETTINGS</b>	<b>FM/AM</b>	FM Terminal Assignment	0005
		FM Terminal Adjustment	0006
		AM Terminal Assignment	0670
		AM Terminal Adjustment	0671
		Analog 1 Terminal Assignment	0672
		Analog 1 Terminal Adjustment	0673
		Analog 2 Terminal Assignment	0674
		Analog 2 Terminal Adjustment	0675
<b>PRESET SPEEDS</b>	<b>Preset Speed Mode</b>	Preset Speed Mode Enable	0380
	<b>Preset Speeds</b>	Preset Speed 1 Settings	0018
		Preset Speed 2 Settings	0019
		Preset Speed 3 Settings	0020
		Preset Speed 4 Settings	0021
		Preset Speed 5 Settings	0022
		Preset Speed 6 Settings	0023
		Preset Speed 7 Settings	0024
		Preset Speed 8 Settings	0287
		Preset Speed 9 Settings	0288
		Preset Speed 10 Settings	0289
		Preset Speed 11 Settings	0290
		Preset Speed 12 Settings	0291
		Preset Speed 13Settings	0292
		Preset Speed 14 Settings	0293
Preset Speed 15 Settings	0294		
<b>SPECIAL CONTROL</b>	<b>Frequency Control</b>	Startup Frequency	0240
		End Frequency	0243
		Run Frequency	0241
		Run Frequency Hysteresis	0242
	<b>Jump Frequencies</b>	Jump Frequency #1	0270
		Jump Frequency #1 Band Width	0271
		Jump Frequency #2	0272
		Jump Frequency #2 Band Width	0273
		Jump Frequency #3	0274
		Jump Frequency #3 Band Width	0275
		Jump Frequency Processing Selection	0276
	<b>Carrier Frequency</b>	Carrier Frequency	0300
	<b>Miscellany</b>	Switch-on-the-fly	0961
		4–20 mA Loss Selection	0962
4–20 mA Speed Reference		0964	

Program Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
<b>SPECIAL CONTROL</b>	<b>Miscellany</b>	At-Trip Line Power Switching	0354
		At-Frequency Line Power Switching	0355
		ASD Switching Wait Time	0356
		Commercial-Power Switching Wait-Time	0357
		Commercial-Power Switching Hold-Time	0358
	<b>Low Output Disable</b>	Low Output Disable On/Off	0731
		Low Output Disable Start Level	0732
		Low Output Disable Start Time	0733
		Low Output Disable Setpoint Boost	0734
		Low Output Disable Boost Time	0735
		Low Output Disable Feedback Level	0736
		Low Output Disable Restart Delay Time	0737
	<b>Earth Fault</b>	Earth Fault Alarm Level	0640
		Earth Fault Alarm Time	0641
		Earth Fault Trip Level	0642
		Earth Fault Trip Time	0643
<b>EOI OPTIONS</b>	<b>Contrast</b>	Lighter	N/A
		Darker	
	<b>Local/Remote Key</b>	Command	
		Frequency	
	<b>Realtime Clock Setup</b>	Time and Date Setting	
	<b>Encoder Action</b>	Rotary Encoder Up/Down Response	
	<b>Alarm Popups</b>	Parameter Selection for Alarm Popup	
<b>Lockout</b>	Parameter Selection for Lockout		
<b>Review Splash Screen</b>	Displays the Splash Screen		



# W7 ASD Direct Access/Communication Numbers

The **W7 ASD** has the ability to allow the user direct access to the motor control functions. The functions listed below have an associated **Parameter Number** which accesses its setting. There are three ways in which the motor-control parameters may be accessed for modification: Program ⇒ *applicable menu path*, Program ⇒ Direct Access ⇒ *applicable parameter number*, or via Communications (see the 7-Series Serial Communications User Manual for further information on communications protocol). Once accessed, the parameter may be viewed or changed.

The **Program** mode allows the user to develop an application-specific motor control profile. Motor control functions may be set to accommodate specific power and timing requirements for a given application. The configurable parameters of the **Program** mode that have user-accessible **Parameter Numbers** are listed and described below.

*Note: The setup procedures included within this section may require a **Reset** before performing the procedure. Application-specific settings may then be performed. The pre-Reset conditions may be saved (see *Save User Parameters*).*

**Table 5.** W7 ASD Direct Access/Communication Numbers.

Parameter Name	No.	Parameter Name	No.	
Automatic Accel/Decel	0000	Preset Speed #3	0020	
Command Mode	0003	Preset Speed #4	0021	
Frequency Mode #1	0004	Preset Speed #5	0022	
FM Terminal Assignment	0005	Preset Speed #6	0023	
FM Terminal Adjustment	0006	Preset Speed #7	0024	
Auto Setup for 50 Hz	0007	Low Speed Signal Output Frequency	0100	
Auto Setup for 60 Hz		Speed Reach Frequency	0101	
Restore Factory Defaults		Speed Reach Bandwidth	0102	
Clear Past Trips		ST Signal Selection	0103	
Clear Run Timer		Priority Selection (F and R On)	0105	
New Base Drive Board		Input Terminal Priority Enable	0106	
Save User Parameters		Extended Terminal Function	0107	
Restore User Settings		Motorized Pot Frequency at Power Down	0108	
Upgrade Firmware		ON Terminal Assignment Assignment	0110	
Set EOI Memory to Default		F Terminal Assignment Assignment	0111	
Panel Direction		0008	R Terminal Assignment Assignment	0112
Accel Time #1		0009	ST Terminal Assignment Assignment	0113
Decel Time #1		0010	RES Terminal Assignment Assignment	0114
Maximum Output Frequency	0011	S1 Terminal Assignment Assignment	0115	
Upper Limit Frequency	0012	S2 Terminal Assignment Assignment	0116	
Lower Limit Frequency	0013	S3 Terminal Assignment Assignment	0117	
Base Frequency #1	0014	S4 Terminal Assignment Assignment	0118	
V/f Pattern	0015	S5 Terminal Assignment Assignment	0119	
Torque Boost #1	0016	S6 Terminal Assignment Assignment	0120	
Soft Stall Enable	0017	S7 Terminal Assignment Assignment	0121	
Preset Speed #1	0018	S8 Terminal Assignment Assignment	0122	
Preset Speed #2	0019	S9 Terminal Assignment Assignment	0123	

<b>Parameter Name</b>	<b>No.</b>	<b>Parameter Name</b>	<b>No.</b>
S10 Terminal Assignment Assignment	<b>0124</b>	Electronic Thermal Protection #4	<b>0181</b>
S11 Terminal Assignment Assignment	<b>0125</b>	V/f Adjustment Coefficient	<b>0183</b>
S12 Terminal Assignment Assignment	<b>0126</b>	V/f Five-Point Setting #1 Frequency	<b>0190</b>
OUT1 Terminal Assignment Assignment	<b>0130</b>	V/f Five-Point Setting #1 Voltage	<b>0191</b>
OUT2 Terminal Assignment Assignment	<b>0131</b>	V/f Five-Point Setting #2 Frequency	<b>0192</b>
FL Terminal Assignment Assignment	<b>0132</b>	V/f Five-Point Setting #2 Voltage	<b>0193</b>
OUT4 Terminal Assignment Assignment	<b>0133</b>	V/f Five-Point Setting #3 Frequency	<b>0194</b>
OUT5 Terminal Assignment Assignment	<b>0134</b>	V/f Five-Point Setting #3 Voltage	<b>0195</b>
OUT6 Terminal Assignment Assignment	<b>0135</b>	V/f Five-Point Setting #4 Frequency	<b>0196</b>
OUT7 Terminal Assignment Assignment	<b>0136</b>	V/f Five-Point Setting #4 Voltage	<b>0197</b>
F Terminal Delay	<b>0140</b>	V/f Five-Point Setting #5 Frequency	<b>0198</b>
R Terminal Delay	<b>0141</b>	V/f Five-Point Setting #5 Voltage	<b>0199</b>
ST Terminal Delay	<b>0142</b>	Reference Priority Selection	<b>0200</b>
RES Terminal Delay	<b>0143</b>	VI/II Speed Reference Setpoint #1 (%)	<b>0201</b>
S1–S4 Terminal Delay	<b>0144</b>	VI/II Speed Frequency Setpoint #1 (Hz)	<b>0202</b>
S5–S16 Terminal Delay	<b>0145</b>	VI/II Speed Reference Setpoint #2 (%)	<b>0203</b>
OUT1 On Delay	<b>0150</b>	VI/II Speed Frequency Setpoint #2 (Hz)	<b>0204</b>
OUT2 On Delay	<b>0151</b>	VI/II Torque Reference Setpoint #1 (%)	<b>0205</b>
FL On Delay	<b>0152</b>	VI/II Torque Reference Setpoint #2 (%)	<b>0206</b>
OUT4 On Delay	<b>0153</b>	Frequency Mode #2	<b>0207</b>
OUT5 On Delay	<b>0154</b>	Mode 1/2 Switching Frequency	<b>0208</b>
OUT6 On Delay	<b>0155</b>	Analog Input Filter	<b>0209</b>
OUT7 On Delay	<b>0156</b>	RR Speed Reference Setpoint #1 (%)	<b>0210</b>
OUT1 Off Delay	<b>0160</b>	RR Speed Frequency Setpoint #1 (Hz)	<b>0211</b>
OUT2 Off Delay	<b>0161</b>	RR Speed Reference Setpoint #2 (%)	<b>0212</b>
FL Off Delay	<b>0162</b>	RR Speed Frequency Setpoint #2 (Hz)	<b>0213</b>
OUT4 Off Delay	<b>0163</b>	RR Torque Reference Setpoint #1 (%)	<b>0214</b>
OUT5 Off Delay	<b>0164</b>	RR Torque Reference Setpoint #2 (%)	<b>0215</b>
OUT6 Off Delay	<b>0165</b>	RX Speed Reference Setpoint #1 (%)	<b>0216</b>
OUT7 Off Delay	<b>0166</b>	RX Speed Frequency Setpoint #1 (Hz)	<b>0217</b>
Base Frequency #2	<b>0170</b>	RX Speed Reference Setpoint #2 (%)	<b>0218</b>
Maximum Output Voltage #2	<b>0171</b>	RX Speed Frequency Setpoint #2 (Hz)	<b>0219</b>
Torque Boost #2	<b>0172</b>	RX Torque Reference Setpoint #1 (%)	<b>0220</b>
Electronic Thermal Protection #2	<b>0173</b>	RX Torque Reference Setpoint #2 (%)	<b>0221</b>
Base Frequency #3	<b>0174</b>	RX2 Speed Reference Setpoint #1 (%)	<b>0222</b>
Maximum Output Voltage #3	<b>0175</b>	RX2 Speed Frequency Setpoint #1 (Hz)	<b>0223</b>
Torque Boost #3	<b>0176</b>	RX2 Speed Reference Setpoint #2 (%)	<b>0224</b>
Electronic Thermal Protection #3	<b>0177</b>	RX2 Speed Frequency Setpoint #2 (Hz)	<b>0225</b>
Base Frequency #4	<b>0178</b>	RX2 Torque Reference Setpoint #1 (%)	<b>0226</b>
Maximum Output Voltage #4	<b>0179</b>	RX2 Torque Reference Setpoint #2 (%)	<b>0227</b>
Torque Boost #4	<b>0180</b>	BIN Speed Reference Setpoint #1(%)	<b>0228</b>

Parameter Name	No.	Parameter Name	No.
BIN Speed Frequency Setpoint #1 (Hz)	0229	PWM Carrier Frequency	0300
BIN Speed Reference Setpoint #2 (%)	0230	Break/Make ST	0301
BIN Speed Frequency Setpoint #2 (Hz)	0231	Ridethrough Mode	0302
BIN Torque Reference Setpoint #1	0232	Number of Retries	0303
BIN Torque Reference Setpoint #2	0233	Dynamic Braking Enable	0304
PG Speed Reference Setpoint #1 (%)	0234	Overvoltage Stall	0305
PG Speed Frequency Setpoint #1 (Hz)	0235	Maximum Output Voltage #1	0306
PG Speed Reference Setpoint #2 (%)	0236	Supply Voltage Compensation	0307
PG Speed Frequency Setpoint #2 (Hz)	0237	Dynamic Braking Resistance	0308
Startup Frequency	0240	Dynamic Braking Resistance Capacity	0309
Run Frequency	0241	Ridethrough Time	0310
Run Frequency Hysteresis	0242	Disable Forward Run/Disable Reverse Run	0311
End Frequency	0243	Scan Rate	0312
0 Hz Dead Band Signal	0244	Lock-on Rate	0313
DC Injection Braking Start Frequency	0250	Search Method	0314
DC Injection Braking Current	0251	Search Inertia	0315
DC Injection Braking Time	0252	Drooping Gain 100%	0320
DC Injection On During Direction Change	0253	Speed at 0% Drooping Gain	0321
Motor Shaft Stationary Control	0254	Speed at 100% Drooping Gain	0322
0 Hz Command Function	0255	Drooping Insensitive Torque Band	0323
Jog Run Frequency	0260	Drooping Output Filter	0324
Jog Stop Control	0261	Load Inertia (Acc/Dec Torque)	0325
Jump Frequency #1	0270	Load Torque Filter (Acc/Dec Torque)	0326
Jump Frequency #1 Bandwidth	0271	Drooping Reference	0327
Jump Frequency #2	0272	Light-load High-speed Operation Selection	0330
Jump Frequency #2 Bandwidth	0273	Light-Load High-Speed Operation Switching Lower-Limit Frequency	0331
Jump Frequency #3	0274	Light-Load High-Speed Operation Load Wait Time	0332
Jump Frequency #3 Bandwidth	0275	Light-Load High-Speed Operation Load Detection Time	0333
Jump Frequency Processing	0276	Light-Load High-Speed Operation Heavy-Load Detection Time	0334
Preset Speed #8	0287	Switching Load Torque During Forward-Run	0335
Preset Speed #9	0288	Heavy-Load Torque During Forward Acceleration	0336
Preset Speed #10	0289	Heavy-Load Torque During Fixed-Speed Forward Run	0337
Preset Speed #11	0290	Switching Load Torque During Reverse-Run	0338
Preset Speed #12	0291	Heavy-Load Torque During Reverse Acceleration	0339
Preset Speed #13	0292	Heavy-Load Torque During Fixed-Speed Reverse Run	0340
Preset Speed #14	0293	Frequency for Automatic High-Speed Operation at Light-Load	0341
Preset Speed #15	0294	Powerline Switching At-Trip Selection	0354

Parameter Name	No.	Parameter Name	No.
Power-Line Switching At-Trip Selection Frequency	0355	Vector Motor Model Slip Frequency Gain	0401
ASD-to-Power Line Switching Wait Time	0356	Motor Constant #1	0402
Commercial Power Wait Time	0357	Motor Constant #2	0403
Commercial Power Hold Time	0358	Motor Constant #3	0404
PID Feedback Input	0360	Motor Constant #4	0405
Delay Filter	0361	Motor Constant #5	0410
Proportional (P) Gain	0362	Number of Motor Poles	0411
Integral (I) Gain	0363	Motor Capacity (kW)	0412
Upper Deviation Limit	0364	Motor Type	0413
Lower Deviation Limit	0365	Autotune Enable	0414
Differential (D) Gain	0366	Torque Command	0420
PG Number of Pulses	0367	Torque Command Filter	0421
PG Input Phases	0368	Synchronized Torque Bias Input	0422
PG Disconnect Detection Selection	0369	Tension Torque Bias Input	0423
Electronic Gear Setting	0370	Load Sharing Gain Input	0424
Position Loop Gain	0371	Forward Speed Limit Input	0425
Position Completion Range	0372	Forward Speed Limit Level	0426
Frequency Limit at Position	0373	Reverse Speed Limit Input	0427
Current Control Proportional Gain	0374	Reverse Speed Limit Level	0428
Current Control Integral Gain	0375	Torque Command Mode	0429
Speed Loop Proportional Gain	0376	Speed Limit Torque Reference	0430
Current Control Integral Gain	0377	Speed Limit Torque Level	0431
Motor Counter Data	0378	Speed Limit Torque Band	0432
Speed Loop Parameter Ratio	0379	Speed Limit Torque Recovery Time	0433
Preset Speed Mode Control	0380	Power Running Torque Limit #1	0440
Preset Speed #1 Direction (see Preset Speed #1)	0381	Driving Torque Limit #1	0441
Preset Speed #2 Direction (see Preset Speed #1)	0382	Regeneration Torque Limit #1	0442
Preset Speed #3 Direction (see Preset Speed #1)	0383	Regeneration Torque Limit #1 Setting	0443
Preset Speed #4 Direction (see Preset Speed #1)	0384	Driving Torque Limit #2	0444
Preset Speed #5 Direction (see Preset Speed #1)	0385	Regeneration Torque Limit #2	0445
Preset Speed #6 Direction (see Preset Speed #1)	0386	Driving Torque Limit #3	0446
Preset Speed #7 Direction (see Preset Speed #1)	0387	Regeneration Torque Limit #3	0447
Preset Speed #8 Direction (see Preset Speed #1)	0388	Driving Torque Limit #4	0448
Preset Speed #9 Direction (see Preset Speed #1)	0389	Regeneration Torque Limit #4	0449
Preset Speed #10 Direction (see Preset Speed #1)	0390	Torque Limit Mode	0450
Preset Speed #11 Direction (see Preset Speed #1)	0391	Torque Limit Mode (Speed Dependent)	0451
Preset Speed #12 Direction (see Preset Speed #1)	0392	Continuing Stall Period	0452
Preset Speed #13 Direction (see Preset Speed #1)	0393	Stall Prevention During Regeneration	0453
Preset Speed #14 Direction (see Preset Speed #1)	0394	Current Differential Gain	0454
Preset Speed #15 Direction (see Preset Speed #1)	0395	VI/II Bias Adjust	0470
Autotune Control	0400	VI/II Gain Adjust	0471

Parameter Name	No.	Parameter Name	No.
RR Bias Adjust	0472	Overload Reduction Starting Frequency	0606
RR Gain Adjust	0473	Motor 150% Overload Time Limit	0607
RX Bias Adjust	0474	Inrush Current Suppression Time (MS Relay Delay)	0608
RX Gain Adjust	0475	Interlock Inrush Relay With ST	0609
RX2 Bias Adjust	0476	Low Current Trip	0610
RX2 Gain Adjust	0477	Low Current Trip Threshold	0611
Exciting Strengthening Coefficient	0480	Low Current Trip Threshold Time	0612
Over Exciting Cooperation	0481	Output Short Circuit Test	0613
Control Margin Modulation	0482	Short Circuit Pulse Duration	0614
Voltage Vector Control	0483	Overtorque Trip	0615
Constant Vector Control	0484	Overtorque Trip/Alarm Level (positive torque)	0616
Stall Cooperation Gain at Field Weakening Zone	0485	Overtorque Trip/Alarm Level (negative torque)	0617
Excitation Starting Rate	0486	Overtorque Detection Time	0618
Compensation Coefficient for Iron Loss	0487	Fan Control Mode Selection	0620
Voltage Compensation Coefficient for Dead Time	0488	Cumulative Run-timer Alarm Setting	0621
Dead Time Compensation (Enable)	0489	Abnormal Speed Detection Filter	0622
Dead-time Compensation Bias	0490	Overspeed Detection Frequency Range	0623
Current/Voltage Control Switching Frequency	0491	Speed Drop Detection Frequency Range	0624
Accel Time #2	0500	Overvoltage Stall Level (fast)	0625
Decel Time #2	0501	Overvoltage Stall Level	0626
Accel/Decel Pattern #1	0502	Undervoltage Trip	0627
Accel/Decel Pattern #2	0503	Undervoltage Detection Time	0628
Panel Acceleration/Deceleration Select	0504	Undervoltage Stall Level	0629
Accel/Decel Switching Frequency #1	0505	Brake Fault Internal Timer	0630
S-Pattern Lower Limit Adjustment	0506	Release (brake) After Run Timer	0632
S-Pattern Upper Limit Adjustment	0507	Earth Fault Alarm Level	0640
Accel/Decel Time Lower-Limit	0508	Earth Fault Alarm Time	0641
Accel Time #3	0510	Earth Fault Trip Level	0642
Decel Time #3	0511	Earth Fault Trip Time	0643
Accel/Decel Pattern #3	0512	Accel/Decel Base Frequency Adjustment	0650
Accel/Decel Switching Frequency #2	0513	Upper Limit Frequency Adjustment	0651
Accel Time #4	0514	Accel Time Adjustment	0652
Decel Time #4	0515	Decel Time Adjustment	0653
Accel/Decel Pattern #4	0516	Torque Boost Adjustment	0654
Accel/Decel Switching Frequency #3	0517	Adding Input Selection	0660
Electronic Thermal Protection #1	0600	Multiplying Input Selection	0661
Overcurrent Stall Level	0601	AM Terminal Assignment	0670
Trip Save at Power Down Enable	0602	AM Terminal Adjustment	0671
Emergency Off Mode	0603	Analog 1 Terminal Assignment	0672
Emergency Off Mode Time	0604	Analog 1 Terminal Adjustment	0673
Output Phase Loss Detection	0605	Analog 2 Terminal Assignment	0674

Parameter Name	No.	Parameter Name	No.
Analog 2 Terminal Adjustment	0675	#1 Scan Receive	0831
FP Terminal Assignment	0676	#2 Scan Receive	0832
FP Terminal Adjustment	0677	#3 Scan Receive	0833
Optional Analog Terminal Mark	0680	#4 Scan Receive	0834
Units for Voltage and Current	0701	#5 Scan Receive	0835
Hz Per User-defined Unit	0702	#6 Scan Receive	0836
Frequency Display Resolution	0703	#1 Scan Transmit	0841
Accel/Decel Frequency Display Resolution	0704	#2 Scan Transmit	0842
Prohibit Initializing User Parameters During Typeform Initialization	0709	#3 Scan Transmit	0843
Panel V/f Group Selection	0720	#4 Scan Transmit	0844
Panel Stop Pattern	0721	#5 Scan Transmit	0845
Panel PID Control	0724	#6 Scan Transmit	0846
LED Option Override Multiplication Gain	0729	S20 Error Mode	0850
Low Output Disable Selection	0731	Error Detect Time	0851
Low Output Disable Start Level	0732	Receive Address	0860
Low Output Disable Start Time	0733	Transmit Address	0861
Low Output Disable Boost Level	0734	Speed Reference Station	0862
Low Output Disable Boost Time	0735	Speed Reference Address	0863
Low Output Disable Feedback Level	0736	Torque Reference Station	0865
Low Output Disable Restart Delay Time	0737	Torque Reference Address	0866
TTL Baud Rate	0800	Fault Detect Station Number	0868
Parity (RS232/RS485/TTL)	0801	Station Mode	0869
ASD Number	0802	Optional Parameter #1	0890
RS232/RS485 Communication Time-Out Time	0803	Optional Parameter #2	0891
RS232/RS485 Communication Time-Out Action	0804	Optional Parameter #3	0892
Communication Interval (TTL)	0805	Optional Parameter #4	0893
TTL Master Output	0806	Optional Parameter #5	0894
Communications (Freq.) Reference Point Selection	0810	S20 Reset	0899
Communications Speed Reference Setpoint #1 (%)	0811	Use Traverse Control	0900
Communications Speed Frequency Setpoint #1 (Hz)	0812	Traverse Accel Time	0901
Communications Speed Reference Setpoint #2 (%)	0813	Traverse Decel Time	0902
Communications Speed Frequency Setpoint #2 (Hz)	0814	Traverse Width	0903
RS232/RS485 Baud Rate	0820	Peak Jump	0904
RS232/RS485 Wire Count	0821	Switch-on-the-Fly	0961
RS232/RS485 Delay Time	0825	4–20 mA Loss Selection	0962
RS232/RS485 Master Output	0826	Ramped PWM Enable	0963
Scan Transmit Error	0830	4–20 mA Speed Reference	0964

# W7 ASD Parameter Descriptions

This section lists the user-settable parameters of the W7 ASD alphabetically.

The listing includes the access path where applicable, the Direct Access Number, and a description of each parameter.

*Note:* Setup procedures included within this section may require a **Reset** before performing the procedure. Application-specific settings may then be performed. The pre-Reset conditions may be saved (see *Type Reset*).

<p><b>0 Hz Command Function</b></p> <p>No Path — Direct Access Only</p> <p>This parameter selects the go-to-zero method to be used by the ASD when the ASD is commanded to go to zero Hz.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Standard (DC Injection Braking)</li> <li>0 Hz Command</li> </ul>	<p><b>Direct Access Number — F255</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Standard (DC Injection Braking)</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>0 Hz Dead Band Signal</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets an output frequency threshold that, until the commanded frequency surpasses this setting, the ASD will output 0 Hz to the motor.</p> <p><i>Note:</i> This setting will override the <b>Startup Frequency</b> setting (F240) if this setting has a higher value.</p>	<p><b>Direct Access Number — F244</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 5.0</p> <p>Units — Hz</p>
<p><b>4–20 mA Loss Selection</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Miscellany</b></p> <p>Provides an alternative reference in the event of the loss of the 4–20 mA input signal.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disable</li> <li>Fault</li> <li>Panel Control</li> <li>Common Serial Control</li> <li>RS232/RS485 Control</li> <li>0 Hz</li> <li>Hold Last</li> <li>Min Speed</li> <li>Max Speed</li> <li>Setting</li> </ul>	<p><b>Direct Access Number — F244</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>



<p><b>4–20 mA Speed Reference</b></p> <p>Program ⇒ <b>System Info and Setup</b> ⇒ <b>PID Setup</b></p> <p>This setting provides a value to be used in the event that <b>Setting</b> is chosen for the <b>4–20 mA Loss</b> selection.</p>	<p><b>Direct Access Number — F964</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<p><b>Abnormal Speed Detection Filter</b></p> <p>Program ⇒ <b>Protection Settings</b> ⇒ <b>Abnormal Speed</b></p> <p>This parameter sets the time that an overspeed condition must exist to cause an overspeed trip.</p>	<p><b>Direct Access Number — F622</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>10.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.01</p> <p>Maximum — 100.0</p> <p>Units — Seconds</p>
<p><b>Accel/Decel Base Frequency Adjustment</b></p> <p>No Path — Direct Access Only</p> <p>This parameter <b>Enables/Disables</b> the feature that allows for the external adjustment of the <b>Base Frequency</b>. When enabled, either <b>VI/II</b> or <b>RR</b> may be used as an input source for the modification of the <b>Base Frequency</b> setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> </ul>	<p><b>Direct Access Number — F650</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Accel/Decel Frequency Display Resolution</b></p> <p>Program ⇒ <b>Utilities</b> ⇒ <b>Display Attributes</b></p> <p>This parameter sets the number of decimal places to be displayed for <b>Accel/Decel</b> functions.</p>	<p><b>Direct Access Number — F704</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.1</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.01</p> <p>Maximum — 1</p>



**Accel/Decel Pattern #1**

Program ⇒ **Fundamentals #1**


This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the **#1 Accel/Decel** parameter.

Settings:


- Linear
- S-Pattern 1
- S-Pattern 2

The figures below provide a profile of the available accel/decel patterns.


**Linear** acceleration and deceleration is the default pattern and is used on most applications.



**S-pattern 1** is used for applications that require quick acceleration and deceleration. This setting is also popular for applications that require shock absorption at the start of acceleration or deceleration.



**S-pattern 2** acceleration and deceleration decreases the rate of change above the base frequency.



<p><b>Accel/Decel Pattern #2</b></p> <p>Program ⇒ <b>Fundamentals #2</b></p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the <b>#2 Accel/Decel</b> parameter.</p> <p>See <a href="#">Accel/Decel Pattern #1</a> for more information on this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>S-Pattern 2</li> <li>S-Pattern 1</li> <li>Linear</li> </ul>	<p><b>Direct Access Number — F503</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>Linear</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Accel/Decel Pattern #3</b></p> <p>No Path — Direct Access Only</p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the <b>#3 Accel/Decel</b> parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Linear</li> <li>S-Pattern 1</li> <li>S-Pattern 2</li> </ul>	<p><b>Direct Access Number — F512</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Linear</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Accel/Decel Pattern #4</b></p> <p>No Path — Direct Access Only</p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the <b>#4 Accel/Decel</b> parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Linear</li> <li>S-Pattern 1</li> <li>S-Pattern 2</li> </ul>	<p><b>Direct Access Number — F516</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Linear</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Accel/Decel Switching Frequency #1</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the frequency at which the acceleration/deceleration control is switched from the <b>Acc/Dec #1</b> profile to the <b>Acc/Dec #2</b> profile during a multiple-profile configuration.</p>	<p><b>Direct Access Number — F505</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 80.0</p> <p>Units — Hz</p>

<p><b>Accel/Decel Switching Frequency #2</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the frequency at which the acceleration control is switched from the <b>Accel #2</b> profile to the <b>Accel #3</b> profile during a multiple-acceleration profile configuration.</p>	<p><b>Direct Access Number — F513</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Max. Freq. (F011)</b></p> <p>Units — Hz</p>
<p><b>Accel/Decel Switching Frequency #3</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the frequency at which the acceleration control is switched from the <b>Accel #3</b> profile to the <b>Accel #4</b> profile during a multiple-acceleration profile configuration.</p>	<p><b>Direct Access Number — F517</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Max. Freq. (F011)</b></p> <p>Units — Hz</p>
<p><b>Accel/Decel Time Lower-Limit</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the lower limit of the <b>Accel/Decel</b> time.</p>	<p><b>Direct Access Number — F508</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.10</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.01</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p><b>Accel Time #1</b></p> <p>Program ⇒ <b>Fundamentals #1</b></p> <p>This parameter specifies the programmed time in seconds for the output of the ASD to go from 0.0 Hz to the <b>Maximum Frequency</b> for the <b>#1 Acceleration</b> profile. The accel/decel pattern may be set using <b>Accel/Decel #1 Pattern</b>. The minimum and maximum accel/decel time may be set using <b>S-Pattern Lower Limit Adjustment</b> and the <b>S-Pattern Upper Limit Adjustment</b>.</p> <p><i>Note: An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads.</i></p> <p><i>Automatic Accel/Decel and Stall settings may lengthen the acceleration time.</i></p> <p><b>Acceleration</b></p> <p>The acceleration rate of a motor is determined by several factors: applied power, applied load, and the physical properties of the motor (winding parameters, motor size, etc.). The ASD will control the first of these factors: input power. The settings of the ASD control the frequency and amplitude of the applied voltage to the motor.</p> <p>Under most operating conditions, as the output frequency of the ASD goes up so does the output voltage (linear acceleration). The ASD has the ability to modify the relationship between frequency and voltage automatically to produce smoother operation or increased (starting) torque.</p>	<p><b>Direct Access Number — F009</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>

<p><b>Accel Time #2</b></p> <p>Program ⇒ <b>Fundamentals #2</b></p> <p>This parameter specifies the programmed time in seconds for the output of the ASD to go from 0.0 Hz to the <b>Maximum Frequency</b> for the <b>#2 Acceleration</b> profile. The accel/decel pattern may be set using <b>Accel/Decel #2 Pattern</b>. The minimum and maximum accel/decel time may be set using <b>S-Pattern Lower Limit Adjustment</b> and the <b>S-Pattern Upper Limit Adjustment</b>.</p> <p>This setting is also used to determine the acceleration rate of the <b>Motorized Pot</b> function.</p> <p><i>Note: An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel and Stall settings may lengthen the acceleration time.</i></p>	<p><b>Direct Access Number — F500</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Accel Time #3</b></p> <p>No Path — Direct Access Only</p> <p>This parameter specifies the time in seconds for the drive to go from 0.0 Hz to the <b>Maximum Frequency</b> for the <b>#3 Acceleration</b> profile. The accel/decel pattern may be set using <b>F502</b>. The minimum accel/decel time may be set using <b>F508</b>.</p> <p><i>Note: An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel and Stall settings may lengthen the acceleration time.</i></p>	<p><b>Direct Access Number — F510</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Accel Time #4</b></p> <p>No Path — Direct Access Only</p> <p>This parameter specifies the time in seconds for the drive to go from 0.0 Hz to the <b>Maximum Frequency</b> for the <b>#4 Acceleration</b> profile. The accel/decel pattern may be set using <b>F502</b>. The minimum accel/decel time may be set using <b>F508</b>.</p> <p><i>Note: An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel and Stall settings may lengthen the acceleration time.</i></p>	<p><b>Direct Access Number — F514</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Accel Time Adjustment</b></p> <p>No Path — Direct Access Only</p> <p>This parameter <b>Enables/Disables</b> the feature that allows for the external adjustment of the <b>Acceleration Time</b>. Selecting either <b>VI/II</b> or <b>RR</b> enables this feature. The selected input is used as a multiplier of the programmed <b>Acceleration Time</b> setting. The multiplication factor may be from 1 to 10.</p> <p><i>Note: An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> </ul>	<p><b>Direct Access Number — F652</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>

**Adding Input Selection**

Program ⇒ **Protection Settings** ⇒ **Overtorque**

This parameter **Enables/Disables** the feature that allows for the external adjustment of the **Output Frequency**.

Selecting either of the input methods listed enables this feature. The selected input is used as a modifier of the programmed **Output Frequency**.

Settings:

- Pulse Input 1
- Motorized Pot
- Communication Card
- RS232/RS485
- Common Serial (TTL)
- Binary/BCD Input
- LED Keypad (option)
- RX2 (option)
- RX
- RR
- VI/II
- Disabled

**Direct Access Number** — **F660**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

**AM Terminal Adjustment**

Program ⇒ Terminal Settings ⇒ **FM/AM**

This function is used to calibrate the **AM** analog output terminal.

To calibrate the **AM** analog output, connect a meter (current or voltage) as described at the **AM Terminal Assignment** parameter.

With the ASD running at a known frequency, adjust this parameter until the running frequency produces the desired DC level output at the **AM** terminal.

**Direct Access Number** — **F671**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

**AM Terminal Assignment**

Program ⇒ Terminal Settings ⇒ **FM/AM**

This setting determines the output function of the **AM** analog output terminal. This output terminal produces an output current that is proportional to the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 172](#).

***Note:** To read **voltage** at this terminal connect a 100 – 500Ω resistor from AM (+) to AM (-). The voltage is read across the 100 – 500Ω resistor.*

*Read current by connecting an ammeter from AM (+) to AM (-).*

The **AM** analog output has a maximum resolution of 1/1024. The **AM Terminal Adjustment** parameter must be used to calibrate the output signal for a proper response. **SW-1** may be switched to allow for the full-range output to be either 0 – 1 mA or 4 – 20 mA when providing an output current, or either 0 – 1 or 1 – 7.5 volts when providing an output voltage at this terminal.

**Direct Access Number** — **F670**

Parameter Type — **Selection List**


Factory Default — **Output Current**

Changeable During Run — **Yes**

<p><b>Analog 1 Terminal Adjustment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>FM/AM</b></p> <p>This parameter adjusts the coefficient of the <b>Analog 1</b> circuit to obtain an output that corresponds with a known input.</p> <p>This function is used in the calibration of external signal measuring devices (DVM, counters, etc.).</p>	<p><b>Direct Access Number</b> — F673</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>512</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1</p> <p>Maximum — 1280</p>
<p><b>Analog 1 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>FM/AM</b></p> <p>This parameter sets the <b>Analog 1</b> multifunction programmable terminal to 1 of 33 possible functions and is available on the <b>ASD Multicom</b> option board only.</p> <p>Possible assignments for this output terminal are listed in Table 8 on page 175.</p>	<p><b>Direct Access Number</b> — F672</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Output Voltage</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Analog 2 Terminal Adjustment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>FM/AM</b></p> <p>This parameter adjusts the coefficient of the circuit to obtain an output that corresponds with a known input.</p> <p>This function is used in the calibration of external signal measuring devices (DVM, counters, etc.).</p>	<p><b>Direct Access Number</b> — F675</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>512</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1</p> <p>Maximum — 1280</p>
<p><b>Analog 2 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>FM/AM</b></p> <p>This parameter sets the <b>Analog 2</b> multifunction programmable terminal to 1 of 33 possible functions and is available on the <b>ASD Multicom</b> option board only.</p> <p>Possible assignments for this output terminal are listed in Table 8 on page 175.</p>	<p><b>Direct Access Number</b> — F674</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Post-compensation Frequency</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Analog Input Filter</b></p> <p>No Path — Direct Access Only</p> <p>This function is used to calibrate the <b>AM</b> analog output terminal.</p> <p>To calibrate the <b>AM</b> analog output, connect a meter (current or voltage) as described at the <b>AM Terminal Assignment</b> parameter. With the ASD running at a known frequency, adjust this parameter until the running frequency produces the desired DC level output at the <b>AM</b> terminal.</p>	<p><b>Direct Access Number</b> — F209</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>512</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1</p> <p>Maximum — 1280</p>

**ASD-to-Power Line Switching Wait Time**Program ⇒ Special Control ⇒ **Miscellany**

This parameter determines the amount of time that the drive will wait before outputting a signal to the motor once the switch-to-drive-output criteria has been met.

**Direct Access Number — F356**Parameter Type — **Numerical**Factory Default — **(ASD-dependent)**Changeable During Run — **No****ASD Number**Program ⇒ Communication ⇒ **Comm. Settings**

This parameter plays a role in the setup of the communications network by assigning an identification (ID) number to each ASD in the communications network.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.

***Note:** Valid address numbers for this parameter are 1–247. The default setting is 0. The default setting must be changed to a valid setting to use this parameter. Otherwise an **Invalid Address** error is returned.*

**Direct Access Number — F802**Parameter Type — **Numerical**Factory Default — **0**Changeable During Run — **Yes**Minimum — **0**Maximum — **255****ASD Typeform**Program ⇒ Utilities ⇒ **Version**

This parameter is read-only and displays the current typeform configuration of the ASD.

**Direct Access Number — None**Parameter Type — **Read-Only**Factory Default — **(ASD-dependent)**Changeable During Run — **No****Automatic Accel/Decel**

No Path — Direct Access Only

This parameter **Enables/Disables** the ability of the ASD to adjust the acceleration and deceleration rates in accordance with the applied load automatically.

The adjusted acceleration and deceleration times range from 12.5% to 800% of the programmed values for **Acceleration Time #1 (F009)** and **Deceleration Time #1 (F010)**.

Settings:

- Disabled
- Enabled (box checked)

***Note:** The motor and the load must be connected prior to selecting **Automatic Accel/Decel**.*

**Direct Access Number — F000**Parameter Type — **Check Box**Factory Default — **Disabled**Changeable During Run — **No**

<p><b>Autotune Control</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>When enabled via the <a href="#">Autotune Enable</a> parameter, this parameter sets the <b>Autotune</b> command status.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>(Autotune) Disabled</li> <li>Reset (Motor) Defaults</li> <li>Enable (Autotune) on Run Command</li> </ul>	<p><b>Direct Access Number</b> — F400</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Autotune Enable</b></p> <p>Program ⇒ <b>Motor Settings</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Autotune</b> function.</p>	<p><b>Direct Access Number</b> — F414</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Enabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Base Frequency #1</b></p> <p>Program ⇒ <b>Motor Settings</b> ⇒ <b>Motor Set #1</b></p> <p>The <b>Base Frequency</b> setting determines the <u>frequency</u> at which the output <u>voltage</u> of the ASD reaches its maximum setting. The maximum voltage setting cannot be more than the input voltage (see the <a href="#">Maximum Output Voltage #1</a> parameter). There are four <b>Base Frequency</b> profile settings: #1 – #4.</p> <p><i>Note: For proper motor operation, the <b>Base Frequency</b> is normally set for the name-plated frequency of the motor.</i></p>	<p><b>Direct Access Number</b> — F014</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 25.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p><b>Base Frequency #2</b></p> <p>Program ⇒ <b>Motor Settings</b> ⇒ <b>Motor Set #2</b></p> <p>The <b>Motor #2 Base Frequency</b> setting determines the <u>frequency</u> at which the output <u>voltage</u> of the ASD reaches its maximum setting. The maximum voltage setting cannot be more than the input voltage (see the <a href="#">Maximum Output Voltage #2</a> parameter). There are four <b>Base Frequency</b> profile settings: #1 – #4.</p> <p>This parameter is used only when the parameters for motor set #2 are configured and selected. Motor set #2 may be activated via a properly configured discrete input terminal.</p> <p>For proper motor operation, the <b>Base Frequency</b> should be set for the name-plated frequency of the motor.</p>	<p><b>Direct Access Number</b> — F170</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 25.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p><b>Base Frequency #3</b></p> <p>Program ⇒ <b>Motor Settings</b> ⇒ <b>Motor Set #3</b></p> <p>The <b>Motor #3 Base Frequency</b> setting determines the <u>frequency</u> at which the output <u>voltage</u> of the ASD reaches its maximum setting. The maximum voltage setting cannot be more than the input voltage (see the <a href="#">Maximum Output Voltage #3</a> parameter). There are four <b>Base Frequency</b> profile settings: #1 – #4.</p> <p>This parameter is used only when the parameters for motor set #3 are configured and selected. Motor set #3 may be activated via a properly configured discrete input terminal.</p> <p>For proper motor operation, the <b>Base Frequency</b> should be set for the name-plated frequency of the motor.</p>	<p><b>Direct Access Number</b> — F174</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 25.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>



**Base Frequency #4**

Program ⇒ **Motor Settings** ⇒ **Motor Set #4**

The **Motor #4 Base Frequency** setting determines the frequency at which the output voltage of the ASD reaches its maximum setting. The maximum voltage setting cannot be more than the input voltage (see the **Maximum Output Voltage #4** parameter). There are four **Base Frequency** profile settings: #1 – #4.

This parameter is used only when the parameters for motor set #4 are configured and selected. Motor set #4 may be activated via a properly configured discrete input terminal.

For proper motor operation, the **Base Frequency** should be set for the name-plated frequency of the motor.

**Direct Access Number** — F178

Parameter Type — **Numerical**

Factory Default — **60.0**

Changeable During Run — **Yes**

Minimum — 25.0

Maximum — 299.0

Units — Hz

**BIN Speed Frequency Setpoint #1 (Hz)**

Program ⇒ **Frequency Settings** ⇒ **Speed Reference Setpoints** ⇒ **BIN**

This parameter is used to set the gain, bias, and direction of the discrete input terminals when using the discrete input terminals as the control input while operating in the **Speed Control** mode.

**BIN Input Speed/Direction Control Setup**

Perform the following setup to allow the system to receive **Speed** control input at the discrete input terminals:

- Program ⇒ **Utilities** ⇒ **Cmd., Frq., and Carrier** ⇒ **Command Mode** ⇒ **Control Terminal Strip**.
- Program ⇒ **Utilities** ⇒ **Cmd., Frq., and Carrier** ⇒ **Frq. Mode #1** ⇒ **Binary/BCD Input**.
- Program ⇒ **Terminal Settings** ⇒ **Input Terminals**; select and set the desired discrete input terminals to **Bin Bit(s) 0 – 7** or **0 – MSB** (see table **Table 6** on pg. 167 for a listing of the available terminal settings). The binary terminal input word will control the direction, speed, and torque of the motor.

**Speed/Direction Control**

Perform the following setup to allow the system to perform **Speed** control from the **BIN** input terminals:

- Set the binary input value (% of 255<sub>D</sub>) (F228) that will produce the output frequency established at the **BIN Speed Frequency Setpoint #1 (Hz)** parameter.

*Note:* 255<sub>D</sub> is the decimal equivalent of the 8-bit BIN word with all input terminals set to one (255 decimal = 11111111 binary).

- Set **BIN Speed Frequency Setpoint #1 (Hz)**.
- Set the binary input value (% of 255<sub>D</sub>) (F230) that will produce the output frequency setting established at the **BIN Speed Frequency Setpoint #2 (Hz)** parameter.
- Set **BIN Speed Frequency Setpoint #2 (Hz)**.
- Provide a **Run** command (**F** and/or **R**).
- Provide a **Run** command (**F** and/or **R**).

Once set, as the **BIN** input data changes, the directional information and the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **BIN Speed Frequency Setpoint #1 (Hz)** and is the frequency that is associated with the setting of **BIN Speed Reference Setpoint #1(%)**.

**Direct Access Number** — F229

Parameter Type — **Numerical**


Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — -80.0

Maximum — 80.0

Units — Hz



<p><b>BIN Speed Frequency Setpoint #2 (Hz)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>BIN</b></p> <p>This parameter is used to set the gain, bias, and direction of the discrete input terminals when using the discrete input terminals as the control input while operating in the <b>Speed Control</b> mode.</p> <p>See <a href="#">BIN Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting.</p> <p>This parameter sets <a href="#">BIN Speed Frequency Setpoint #2 (Hz)</a> and is the frequency that is associated with the setting of <a href="#">BIN Speed Reference Setpoint #2 (%)</a>.</p>	<p><b>Direct Access Number — F231</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>80.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — -80.0</p> <p>Maximum — +80.0</p> <p>Units — Hz</p>
<p><b>BIN Speed Reference Setpoint #1(%)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>BIN</b></p> <p>This parameter is used to set the gain, bias, and direction of the discrete input terminals when using the discrete input terminals as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">BIN Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">BIN Torque Reference Setpoint #1</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>BIN</b> input that is associated with <a href="#">BIN Speed Frequency Setpoint #1 (Hz)</a> when operating in the <b>Speed</b> control mode or is associated with the <a href="#">BIN Torque Reference Setpoint #1</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as 0 to 100% of the binary input word 11111111 (255<sub>D</sub>).</p>	<p><b>Direct Access Number — F228</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 100.00</p> <p>Units — %</p>
<p><b>BIN Speed Reference Setpoint #2 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>BIN</b></p> <p>This parameter is used to set the gain, bias, and direction of the discrete input terminals when using the discrete input terminals as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">BIN Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">BIN Torque Reference Setpoint #1</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>BIN</b> input that is associated with <a href="#">BIN Speed Frequency Setpoint #2 (Hz)</a> when operating in the <b>Speed</b> control mode or is associated with the <a href="#">BIN Torque Reference Setpoint #2</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as 0 to 100% of the binary input word 11111111 (255<sub>D</sub>).</p>	<p><b>Direct Access Number — F230</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 100.0</p> <p>Units — %</p>

**BIN Torque Reference Setpoint #1**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **BIN**

This parameter is used to set the gain, bias, and direction of the discrete input terminals when using the discrete input terminals as the control input while operating in the **Torque Control** mode.

**BIN Input Torque Control Setup**

Perform the following setup to allow the system to receive **Torque** control input from the discrete input terminals:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd., Frq., and Carrier ⇒ Frq. Mode #1 ⇒ **Binary/BCD Input.**
- Program ⇒ Terminal Settings ⇒ **Input Terminals**; select and set the desired discrete input terminals to **Bin Bit(s) 0 – 7** or **0 – MSB** (see [Table 6 on pg. 167](#) for a listing of the available terminal settings). The binary terminal input word will control the direction, speed, and torque of the motor.
- Provide a **Run** command (**F** or **R**).

**Torque Control**

When operating in the **Torque Control** mode, scaling of the discrete input terminals is accomplished via the following parameters as described below:

- Set the binary input value (% of 255<sub>D</sub>) (**F228**) that will produce the output torque established at the **BIN Torque Reference Setpoint #1** parameter.

*Note: 255<sub>D</sub> is the decimal equivalent of the 8-bit BIN word with all input terminals set to one (255 decimal = 11111111 binary).*

- Set **BIN Torque Reference Setpoint #1**.
- Set the binary input value (% of 255<sub>D</sub>) (**F230**) that will produce the output frequency setting established at the **BIN Torque Reference Setpoint #2** parameter.
- Set **BIN Torque Reference Setpoint #2**.
- Provide a **Run** command (**F** and/or **R**).

This parameter sets **BIN Torque Reference Setpoint #1** and is the output torque value that is associated with the setting of **BIN Speed Reference Setpoint #1**(%) when operating in the **Torque** control mode.

This value is entered as -250% to 250% of the output torque range.

**Direct Access Number — F232**

**Parameter Type — Numerical**


**Factory Default — 0.0**

**Changeable During Run — Yes**

**Minimum — -250.0**

**Maximum — +250.0**

**Units — %**



**BIN Torque Reference Setpoint #2**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **BIN**

This parameter is used to set the gain, bias, and direction of the discrete input terminals when using the discrete input terminals as the control input while operating in the **Torque Control** mode.

See **BIN Torque Reference Setpoint #1** for further information on this setting.

This parameter sets **BIN Torque Reference Setpoint #2** and is the output torque value that is associated with the setting of **BIN Speed Reference Setpoint #2** (%) when operating in the **Torque** control mode.

This value is entered as -250% to 250% of the output torque range.

**Direct Access Number — F233**

**Parameter Type — Numerical**

**Factory Default — +100.0**

**Changeable During Run — Yes**

**Minimum — -250.0**


**Maximum — +250.0**

**Units — %**

<p><b>Brake Fault Internal Timer</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overtorque</b></p> <p>After a brake failure has occurred, the user-set <b>Brake Fault Internal Timer</b> clock setting will begin to count down. Once this time has elapsed, a signal will be provided to indicate that the brake has failed. This signal may be used to halt a related system or to notify the user.</p>	<p><b>Direct Access Number</b> — F630</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p><b>Break/Make ST</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Retry/Ridethrough</b></p> <p><b>Enables/Disables</b> the ability of the drive to start into a spinning motor when the <b>ST-to-CC</b> connection momentarily opens and is then closed (Break/Make ST) or after a power interruption (momentary power failure).</p>	<p><b>Direct Access Number</b> — F301</p> <p>Parameter Type — <b>Check Box</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Command Mode</b></p> <p>Program ⇒ Utilities ⇒ <b>Cmd. Frq. and Carrier</b></p> <p>The <b>Command Mode Selection</b> establishes the source of the command input for the ASD. <b>Command</b> inputs include <b>Run, Stop, Forward</b>, etc.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Control Terminal Strip</li> <li>LED Keypad</li> <li>Common Serial (TTL)</li> <li>RS232/RS485</li> <li>Communication Card</li> </ul>	<p><b>Direct Access Number</b> — F003</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Control Terminal Strip</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Communication Interval (TTL)</b></p> <p>Program ⇒ <b>Communication</b> ⇒ <b>Communication Settings</b></p> <p>This parameter sets the <b>TTL</b> response delay time.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p>	<p><b>Direct Access Number</b> — F805</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — 0.00</p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 2.00</p> <p>Units — Seconds</p>
<p><b>Commercial Power Hold Time</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Miscellany</b></p> <p>This parameter determines the amount of time that the connection to commercial power is maintained once the switch-to-drive-output criteria has been met.</p>	<p><b>Direct Access Number</b> — F358</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>2.00</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.10</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>

**Commercial Power Wait Time**Program ⇒ Special Control ⇒ **Miscellany**

This parameter determines the amount of time that the drive will wait before allowing commercial power to be applied to the motor once the switch-to-commercial-power criteria has been met.

**Direct Access Number — F357**Parameter Type — **Selection List**Factory Default — **0.62**Changeable During Run — **No**

Minimum — 0.37

Maximum — **10.00**

Units — Seconds

**Communications (Freq.) Reference Point Selection**Program ⇒ Communications Settings ⇒ **Comm. Ref. Adjust**

This parameter **Enable/Disables** speed control via communications. Selecting a signal source enables this function. Selecting **Disable** disables this function.

Settings:

Communications Card  
RS232/RS485  
LCD Keypad  
Disabled

**Direct Access Number — F810**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

## Communications Speed Reference Setpoint #1 (%)      Communications Speed Reference Setpoint #2 (%)

### Communications Speed Reference Setpoint #1 (%)

Program ⇒ Communications Settings ⇒ **Comm. Ref. Adjust**

When enabled via the [Communications \(Freq.\) Reference Point Selection](#) parameter, this parameter is used to allow the user to set the gain and bias of the speed control input to the ASD when the speed control signal is received via the source selected at the [Communications \(Freq.\) Reference Point Selection](#) parameter.

#### Gain and Bias Settings

When operating in the **Speed Control** mode and using one of the control sources from the [Communications \(Freq.\) Reference Point Selection](#) parameter, the settings that determine the gain and bias properties of the received signal are:

- Set the **Communications** input signal value (F811) that will produce the output frequency established at the [Communications Speed Reference Setpoint #1 \(%\)](#) parameter.
- Set [Communications Speed Reference Setpoint #1 \(%\)](#).
- Set the **Communications** input signal value (F813) that will produce the output frequency setting established at the [Communications Speed Reference Setpoint #2 \(%\)](#) parameter.
- Set [Communications Speed Reference Setpoint #2 \(%\)](#).
- Provide a **Run** command (**F** and/or **R**).

Once set, as the input signal value changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets [Communications Speed Reference Setpoint #1 \(%\)](#) and is the input signal reference that is associated with the setting of [Communications Speed Frequency Setpoint #1 \(Hz\)](#) when operating in the **Speed Control** mode.

This value is entered as 0 to 100% of the [Communications Speed Reference Setpoint #1 \(%\)](#) input value range.

Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.

**Direct Access Number — F811**

Parameter Type — **Numerical**

Factory Default — **0.00**


Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.0

Units — %

#### Frequency Settings



### Communications Speed Reference Setpoint #2 (%)

Program ⇒ Communications Settings ⇒ **Comm. Ref. Adjust**

This parameter is used to set the gain and bias of the **Communications Reference** speed control input.

This parameter sets the [Communications Speed Reference Setpoint #2 \(%\)](#) and is the input signal reference that is associated with the setting of [Communications Speed Frequency Setpoint #2 \(Hz\)](#).

This value is entered as 0 to 100% of the [Communications Speed Reference Setpoint #2 \(%\)](#) input value range.

Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.

See [Communications Speed Reference Setpoint #1 \(%\)](#) for further information on this setting.

**Direct Access Number — F813**

Parameter Type — **Numerical**

Factory Default — **100.0**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.0

Units — %

<p><b>Communications Speed Frequency Setpoint #1 (Hz)</b></p> <p>Program ⇒ Communications Settings ⇒ <b>Comm. Ref. Adjust</b></p> <p>This parameter is used to set the gain and bias of the <b>Communications Reference</b> speed control input.</p> <p>This parameter sets <a href="#">Communications Speed Frequency Setpoint #1 (Hz)</a> and is the output frequency that is associated with the setting of <a href="#">Communications Speed Reference Setpoint #1 (%)</a>.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>See <a href="#">Communications Speed Reference Setpoint #1 (%)</a> for further information on this setting.</p>	<p><b>Direct Access Number — F812</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Communications Speed Frequency Setpoint #2 (Hz)</b></p> <p>Program ⇒ Communications Settings ⇒ <b>Comm. Ref. Adjust</b></p> <p>This parameter is used to set the gain and bias of the <b>Communications Reference</b> speed control input.</p> <p>This parameter sets the <a href="#">Communications Speed Frequency Setpoint #2 (Hz)</a> and is the output frequency that is associated with the setting of <a href="#">Communications Speed Reference Setpoint #2 (%)</a>.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>See <a href="#">Communications Speed Reference Setpoint #1 (%)</a> for further information on this setting.</p>	<p><b>Direct Access Number — F814</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>80.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Compensation Coefficient for Iron Loss</b></p> <p>No Path — Direct Access Only</p> <p>This parameter compensates for losses in the rotor-to-stator coupling of the excitation and torque current energy.</p>	<p><b>Direct Access Number — F487</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>105.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p><b>Constant Vector Control</b></p> <p>No Path — Direct Access Only</p> <p>This parameter establishes the control margin of modulation when operating in the <b>Constant Vector Control</b> mode.</p>	<p><b>Direct Access Number — F484</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>105.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 80.0</p> <p>Maximum — 300.0</p> <p>Units — %</p>

<p><b>Continuing Stall Period</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Stall</b></p> <p>This setting allows the user to extend the <b>Overvoltage Stall</b> and the <b>Overcurrent Stall</b> time settings.</p>	<p><b>Direct Access Number</b> — F452</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 1.00</p> <p>Units — Seconds</p>
<p><b>Contrast</b></p> <p>Program ⇒ <b>EOI Options</b></p> <p>Press the <b>Up/Down Arrow</b> keys to increase or decrease the contrast of the LCD screen.</p>	<p><b>Direct Access Number</b> — <b>None</b></p> <p>Parameter Type — <b>Click to Select</b></p> <p>Factory Default — <b>Lighter</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Control Margin Modulation</b></p> <p>No Path — Direct Access Only</p> <p>This parameter establishes the control margin of modulation when operating in the <b>Current Vector Control</b> mode.</p>	<p><b>Direct Access Number</b> — F482</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>90.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 80.0</p> <p>Maximum — 300.0</p> <p>Units — %</p>
<p><b>CPU</b></p> <p>Program ⇒ Utilities ⇒ <b>Version</b></p> <p>This is a read-only parameter that displays the version level of the CPU.</p>	<p><b>Direct Access Number</b> — <b>None</b></p>
<p><b>Cumulative Run-timer Alarm Setting</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Trip/Fan/Timer</b></p> <p>This parameter sets a run-time value that, once exceeded, provides an output signal. The output signal may be used to control external equipment or used to engage a brake.</p> <p><i>Note: The time displayed is 1/100th of the actual time (0.01 hr. = 1.0 hr.).</i></p>	<p><b>Direct Access Number</b> — F621</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>175.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 999.9</p> <p>Units — Hours (X 100)</p>
<p><b>Current/Voltage Control Switching Frequency</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the threshold frequency at which ASD control is switched between Current-control and Voltage -control.</p>	<p><b>Direct Access Number</b> — F491</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>40.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10.00</p> <p>Maximum — 60.00</p> <p>Units — Hz</p>



**Current Control Integral Gain**

No Path — Direct Access Only

This parameter sets the degree and rate at which the output frequency will be allowed to change when prompted by changes in the output current.

The larger the value entered here, the quicker/more the drive responds to changes in feedback.

**Current Control Proportional Gain**

No Path — Direct Access Only

This parameter sets the sensitivity of the drive when monitoring the output current to control speed. The larger the value entered here, the more sensitive the drive is to changes in the received feedback.

**Current Differential Gain**

No Path — Direct Access Only

This parameter determines the degree that the current differential function affects the output signal. The larger the value entered here, the more pronounced the **Current Differential Gain**.

**DC Injection Braking Current**Program ⇒ **Protection** ⇒ **DC Injection**

This parameter sets the percentage of the rated current of the ASD that will be used for **DC Injection** braking. A larger load will require a higher setting.

**DC Injection Braking**

**DC Injection Braking** is a braking system used with three-phase motors. Unlike conventional brakes, there is no physical contact between the rotating shaft and a stationary brake pad or drum. When braking is required, the ASD outputs a DC current that is applied to the windings of the motor to quickly brake the motor. The braking current stops when the time entered in **DC Injection Braking Time** times out.

The intensity of the DC current used while braking determines how fast the motor will come to a stop and may be set at the **DC Injection Braking Current** parameter. The intensity setting is entered as a percentage of the full load current of the ASD.

*Note: **DC Injection Braking** is also used to preheat the motor or to keep the rotor from spinning freely when no rotation is required by providing a pulsating DC current into the motor at the **Carrier Frequency**. This feature may be enabled at the **Motor Shaft Stationary Control** parameter.*

**Direct Access Number** — F375Parameter Type — **Numerical**Factory Default — **(ASD-dependent)**Changeable During Run — **No**

Minimum — 100.0

Maximum — 1250

**Direct Access Number** — F374Parameter Type — **Numerical**Factory Default — **(ASD-dependent)**Changeable During Run — **No**

Minimum — 100.0

Maximum — 1000

**Direct Access Number** — F454Parameter Type — **Numerical**Factory Default — **1.23**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 327.6

**Direct Access Number** — F251Parameter Type — **Numerical**Factory Default — **50.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.00

Units — %

<p><b>DC Injection Braking Start Frequency</b></p> <p>Program ⇒ <b>Protection</b> ⇒ <b>DC Injection</b></p> <p>During deceleration this is the frequency at which <b>DC Injection</b> braking will start.</p>	<p><b>Direct Access Number</b> — <b>F250</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 120.0</p> <p>Units — Hz</p>
<p><b>DC Injection Braking Time</b></p> <p>Program ⇒ <b>Protection</b> ⇒ <b>DC Injection</b></p> <p>This parameter is used to set the on-time duration of the <b>DC Injection</b> braking.</p>	<p><b>Direct Access Number</b> — <b>F252</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p><b>DC Injection On During Direction Change</b></p> <p>Program ⇒ Protection Settings ⇒ <b>DC Injection</b></p> <p>This parameter <b>Enables/Disables</b> the use of <b>DC Injection</b> braking during a change in the direction of the motor.</p>	<p><b>Direct Access Number</b> — <b>F253</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Dead-time Compensation Bias</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets a bias for the <b>Dead-time Compensation</b> function. The <b>Dead-time Compensation</b> feature provides a smoothing of the on-off IGBT signal that feeds the <b>Gate Driver</b> board.</p>	<p><b>Direct Access Number</b> — <b>F490</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.000</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — -32.768</p> <p>Maximum — 32.767</p>
<p><b>Dead Time Compensation (Enable)</b></p> <p>No Path — Direct Access Only</p> <p>This parameter <b>Enables/Disables</b> the <b>Dead Time Compensation</b> function. The <b>Dead Time Compensation</b> feature provides a smoothing of the on-off IGBT signal that feeds the <b>Gate Driver</b> board during the off portion of the on-off cycle.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Enabled</li> <li>Disabled</li> </ul>	<p><b>Direct Access Number</b> — <b>F489</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Enabled</b></p> <p>Changeable During Run — <b>Yes</b></p>

<p><b>Decel Time #1</b></p> <p>Program ⇒ <b>Fundamentals #1</b></p> <p>This parameter specifies the time in seconds for the ASD output to go from the <b>Maximum Frequency</b> to 0.0 Hz for the <b>#1 Deceleration</b> profile. The accel/ decel pattern may be set using <b>Accel/Decel #1 Pattern</b>.</p> <p><i>Note: A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads.</i></p>	<p><b>Direct Access Number — F010</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Decel Time #2</b></p> <p>Program ⇒ <b>Fundamentals #2</b></p> <p>This parameter specifies the time in seconds for the ASD output to go from the <b>Maximum Frequency</b> to 0.0 Hz for the <b>#2 Deceleration</b> profile. The accel/ decel pattern may be set using <b>Accel/Decel #2 Pattern</b>.</p> <p>This setting is also used to determine the deceleration rate of the <b>Motorized Pot</b> function.</p> <p><i>Note: A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads.</i></p>	<p><b>Direct Access Number — F501</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Decel Time #3</b></p> <p>No Path — Direct Access Only</p> <p>This parameter specifies the time in seconds for the drive to go from the <b>Maximum Frequency</b> to 0.0 Hz for the <b>#3 Deceleration</b> profile.</p> <p>The accel/decel pattern may be set using <b>F502</b>. The minimum accel/decel time may be set using <b>F508</b>.</p> <p><i>Note: A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel and Stall settings may lengthen the deceleration time.</i></p>	<p><b>Direct Access Number — F511</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p><b>Decel Time #4</b></p> <p>No Path — Direct Access Only</p> <p>This parameter specifies the time in seconds for the drive to go from the <b>Maximum Frequency</b> to 0.0 Hz for the <b>#4 Deceleration</b> profile. The accel/ decel pattern may be set using <b>F502</b>. The minimum accel/decel time may be set using <b>F508</b>.</p> <p><i>Note: A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel and Stall settings may lengthen the deceleration time.</i></p>	<p><b>Direct Access Number — F515</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>

<p><b>Decel Time Adjustment</b></p> <p>No Path — Direct Access Only</p> <p>This parameter <b>Enables/Disables</b> the feature that allows for the external adjustment of the <b>Deceleration Time</b>. Selecting either <b>VI/II</b> or <b>RR</b> enables this feature. The selected input is used as a modifier of the programmed <b>Deceleration Time</b> setting.</p> <p><i>Note:</i> A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> </ul>	<p><b>Direct Access Number</b> — F653</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Delay Filter</b></p> <p>Program ⇒ <b>Feedback Settings</b></p> <p>This parameter determines the delay in the ASD output response to the motor-control feedback signal.</p>	<p><b>Direct Access Number</b> — F361</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p><b>Differential (D) Gain</b></p> <p>Program ⇒ <b>Feedback Settings</b></p> <p>This parameter determines the degree that the differential function affects the output signal. The larger the value entered here, the more pronounced the <b>Differential Gain</b>.</p>	<p><b>Direct Access Number</b> — F366</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 2.55</p>
<p><b>Disable Forward Run/Disable Reverse Run</b></p> <p>Program ⇒ Fundamental Parameters ⇒ <b>Fundamental #1</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Forward Run</b> or <b>Reverse Run</b> mode. If either direction is disabled, commands received for the disabled direction will not be recognized. If both are selected as disabled, the received direction command will be followed.</p>	<p><b>Direct Access Number</b> — F311</p> <p>Parameter Type — <b>Check Box</b></p> <p>Factory Default — <b>Off</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Driving Torque Limit #1</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Manual Torque Limit</b></p> <p>This parameter provides a value for the <b>Power Running Torque Limit #1</b> setting if <b>Setting</b> is selected at <b>F440</b>. This value provides the positive torque upper limit for the #1 motor.</p>	<p><b>Direct Access Number</b> — F441</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>

<p><b>Driving Torque Limit #2</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Manual Torque Limit</b></p> <p>This parameter is used to set the positive torque upper limit for the #2 motor profile when multiple motors are controlled by a single drive or when a single motor is to be controlled by multiple profiles.</p>	<p><b>Direct Access Number — F444</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Driving Torque Limit #3</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Manual Torque Limit</b></p> <p>This parameter is used to set the positive torque upper limit for the #3 motor profile when multiple motors are controlled by a single drive or when a single motor is to be controlled by multiple profiles.</p>	<p><b>Direct Access Number — F446</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Driving Torque Limit #4</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Manual Torque Limit</b></p> <p>This parameter is used to set the positive torque upper limit for the #4 motor profile when multiple motors are controlled by a single drive or when a single motor is to be controlled by multiple profiles.</p>	<p><b>Direct Access Number — F448</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Drooping Gain 100%</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the effective 100% output torque level while operating in the <b>Drooping Control</b> mode. This value is the upper torque limit of the motor being driven by a given ASD while operating in the <b>Drooping Control</b> mode.</p> <p><b>Drooping</b></p> <p><b>Drooping Control</b>, also called <b>Load Share</b>, is used to share the load among two or more mechanically coupled motors. Unlike <b>Stall</b>, which reduces the output frequency in order to limit the load once the load reaches a preset level, <b>Drooping</b> can decrease or increase the V/f setting of a motor to maintain a balance between the output torque levels of mechanically coupled motors.</p> <p>Because of variances in gearboxes, sheaves, belts, motors, and because the speed of the motor is constrained by the mechanical system, one motor may experience more load than its counterpart and may become overloaded. <b>Drooping Control</b> allows the overloaded motor to slow down, thus shedding load and encouraging a lightly-loaded motor to pick up the slack. The goal of <b>Drooping Control</b> is to have the same torque ratios for mechanically coupled motors.</p>	<p><b>Direct Access Number — F320</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 100.0</p> <p>Units — %</p>

<p><b>Drooping Insensitive Torque Band</b></p> <p>No Path — Direct Access Only</p> <p>This parameter defines a torque range in which the <b>Drooping Control</b> settings will be ignored and the programmed torque settings will be followed.</p>	<p><b>Direct Access Number — F323</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>10.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>Drooping Output Filter</b></p> <p>No Path — Direct Access Only</p> <p>This parameter is used to set the rate of output change allowed when operating in the <b>Drooping Control</b> mode.</p> <p>Jerky operation may be decreased by increasing this setting.</p>	<p><b>Direct Access Number — F324</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.1</p> <p>Maximum — 200.0</p>
<p><b>Drooping Reference</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the method to be used in determining the output torque while operating in the <b>Drooping Control</b> mode.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Total Torque Calculated by the Detection Current.</li> <li>Torque without Acc/Dec Torque Calculated by Detection Current.</li> <li>Total Torque Calculated by the Command Current.</li> <li>Torque without Acc/Dec Torque Calculated by the Command Current.</li> </ul>	<p><b>Direct Access Number — F327</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Total torque calculated by the detection current</b></p> <p>Changeable During Run — <b>Yes</b></p>

**Dynamic Braking Enable**Program ⇒ **Protection Settings** ⇒ **Dynamic Braking**This parameter **Enables/Disables** the **Dynamic Braking** system.

Settings:

- Enabled
- Disabled

**Dynamic Braking**

**Dynamic Braking** uses the inertial energy of the load to produce a braking force or it may be used to reduce the bus voltage in an attempt to preclude an overvoltage trip during deceleration. The inertial energy of the load drives the rotor and induces a current into the stator of the motor.

The induced stator current (energy) is dissipated through a resistive load. The resistive load is connected across terminals **PA** and **PB** (non-polarized). Using a low-value, high-wattage resistance as a load for the generated current, the resistive load dissipates the induced energy. The dissipated energy is the energy that would otherwise have caused the rotor to continue to rotate.

**Dynamic Braking** helps to slow the load quickly; it cannot act as a holding brake.

The **Dynamic Braking** function may be setup and enabled by connecting a braking resistor from terminal **PA** to **PB** of the ASD and providing the proper information at the DBR parameters: **Dynamic Braking Resistor (DBR) Capacity, Dynamic Braking Resistance**, and **DC Injection Braking Current**.

For additional information on selecting the proper resistance value for a given application contact Toshiba's Marketing Department.

**Direct Access Number** — **F304**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No****Dynamic Braking Resistance**Program ⇒ **Protection Settings** ⇒ **Dynamic Braking**This parameter is used to input the resistive value of the **Dynamic Braking Resistor**.

*Note: Using a resistor value that is too low may result in system damage.*

**Direct Access Number** — **F308**Parameter Type — **Numerical**Factory Default — **(ASD-dependent)**Changeable During Run — **No**

Minimum — 1.0

Maximum — 1000.0

Units —  $\Omega$ **Dynamic Braking Resistance Capacity**Program ⇒ **Protection Settings** ⇒ **Dynamic Braking**This parameter is used to input the wattage of the **Dynamic Braking Resistor**.

For additional information on selecting the proper resistor wattage value for a given application contact **Toshiba's Marketing Department**.

*Note: Using a resistor with a wattage rating that is too low may result in system damage.*

**Direct Access Number** — **F309**Parameter Type — **Numerical**Factory Default — **(ASD-dependent)**Changeable During Run — **No**

Minimum — 0.01

Maximum — 600.0

Units — kW

<p><b>Earth Fault Alarm Level</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Earth Fault</b></p> <p>This parameter sets the threshold level (%) that must be exceeded to meet the <b>Earth Fault Alarm</b> activation criteria.</p>	<p><b>Direct Access Number — F640</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p><b>Earth Fault Alarm Time</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Earth Fault</b></p> <p>In the event that the <b>Earth Fault Alarm</b> activation criteria is met, a timer begins to count down to zero. Upon reaching zero, the <b>Earth Fault Alarm</b> is activated.</p> <p>This parameter sets the start-time of the count-down timer.</p>	<p><b>Direct Access Number — F641</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 2.50</p> <p>Units — Seconds</p>
<p><b>Earth Fault Trip Level</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Earth Fault</b></p> <p>This parameter sets the threshold level (%) that must be exceeded to meet the <b>Earth Fault Trip</b> activation criteria.</p>	<p><b>Direct Access Number — F642</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 1.00</p> <p>Units — %</p>
<p><b>Earth Fault Trip Time</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Earth Fault</b></p> <p>In the event that the <b>Earth Fault Trip</b> activation criteria is met, a timer begins to count down to zero. Upon reaching zero, the <b>Earth Fault Trip</b> is activated.</p> <p>This parameter sets the start-time of the count-down timer.</p>	<p><b>Direct Access Number — F643</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 1.00</p> <p>Units — %</p>
<p><b>Electronic Gear Setting</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the number of pulses per revolution when using a shaft-mounted encoder and the <b>PG Option Board</b> for closed loop speed control.</p>	<p><b>Direct Access Number — F370</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1000</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 100</p> <p>Maximum — 4000</p>



<p><b>Electronic Thermal Protection #1</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Set #1</b></p> <p>This parameter specifies the motor overload current level for motor set #1. This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to <b>Amps</b> or it may be set as a percentage of the ASD rating. The name-plated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (see Program ⇒ Utilities ⇒ Display Attributes ⇒ <b>Units for V/A</b> to change the display unit).</p> <p><b>Thermal Protection</b> settings will be displayed in <b>Amps</b> if the keypad display units are set to <b>V/A</b> rather than <b>%</b>.</p>	<p><b>Direct Access Number — F600</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>Electronic Thermal Protection #2</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Set #2</b></p> <p>This parameter specifies the motor overload current level for motor set #2. This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to <b>Amps</b> or it may be set as a percentage of the ASD rating. The name-plated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (see Program ⇒ Utilities ⇒ Display Attributes ⇒ <b>Units for Voltage and Current</b> to change the display unit).</p> <p><b>Thermal Protection</b> settings will be displayed in <b>Amps</b> if the keypad display units are set to <b>V/A</b> rather than <b>%</b>.</p>	<p><b>Direct Access Number — F173</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>Electronic Thermal Protection #3</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Set #3</b></p> <p>This parameter specifies the motor overload current level for motor set #3. This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to <b>Amps</b> or it may be set as a percentage of the ASD rating. The name-plated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (see Program ⇒ Utilities ⇒ Display Attributes ⇒ <b>Units for Voltage and Current</b> to change the display unit).</p> <p><b>Thermal Protection</b> settings will be displayed in <b>Amps</b> if the keypad display units are set to <b>V/A</b> rather than <b>%</b>.</p>	<p><b>Direct Access Number — F177</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>Electronic Thermal Protection #4</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Set #4</b></p> <p>This parameter specifies the motor overload current level for motor set #4. This value is entered as either a percentage of the full load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to <b>Amps</b> or it may be set as a percentage of the ASD rating. The name-plated FLA of the motor may be entered directly when <b>Amps</b> is selected as the unit of measurement (see Program ⇒ Utilities ⇒ Display Attributes ⇒ <b>Units for Voltage and Current</b> to change the display unit).</p> <p><b>Thermal Protection</b> settings will be displayed in <b>Amps</b> if the keypad display units are set to <b>V/A</b> rather than <b>%</b>.</p>	<p><b>Direct Access Number — F181</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>

<p><b>Emergency Off Mode</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Retry/Ridethrough</b></p> <p>This parameter determines the method used to stop the motor in the event that an <b>Emergency Off</b> command is received.</p> <p>This setting may also be associated with the <b>FL</b> terminals to allow the <b>FL</b> relay to change states when an <b>EOFF</b> condition occurs by setting the <b>FL</b> terminal to <b>Fault FL (all)</b>.</p> <p><i>Note: A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Deceleration Stop</li> <li>DC Injection Braking Stop</li> <li>Coast Stop</li> </ul>	<p><b>Direct Access Number — F603</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Coast Stop</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Emergency Off Mode Time</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Retry/Ridethrough</b></p> <p>When <b>DC Injection</b> is used for <b>Emergency Off</b> stopping, this parameter determines the time that the <b>DC Injection</b> braking is applied to the motor.</p>	<p><b>Direct Access Number — F604</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.10</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p><b>End Frequency</b></p> <p>Program ⇒ Special Control ⇒ <b>Frequency Control</b></p> <p>This parameter sets the lowest frequency that the ASD will recognize during deceleration before the ASD goes to 0.0 Hz.</p>	<p><b>Direct Access Number — F243</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 80.0</p> <p>Units — Hz</p>
<p><b>Error Detect Time</b></p> <p>Program ⇒ Communication ⇒ <b>S20 Settings</b></p> <p>This setting determines the length of time that an ASD is monitored for an error.</p>	<p><b>Direct Access Number — F851</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>200</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 1000</p> <p>Units — Seconds</p>

<p><b>Excitation Starting Rate</b></p> <p>No Path — Direct Access Only</p> <p>This parameter establishes the rate of increase in the excitation current from a zero output of the ASD.</p>	<p><b>Direct Access Number — F486</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>163.8</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1.64</p> <p>Maximum — 327.6</p>
<p><b>Exciting Strengthening Coefficient</b></p> <p>No Path — Direct Access Only</p> <p>This parameter determines the rate at which the excitation current is allowed to go from zero to saturation and is enabled at <b>F481</b>.</p>	<p><b>Direct Access Number — F480</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>64</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p><b>Extended Terminal Function</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Other</b></p> <p>The <b>Extended Terminal Function</b> is used with the optional <b>ASD-Multicom</b> card only. This parameter defines the format of the binary or BCD data when using the option card.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>None</li> <li>12-Bit Binary</li> <li>16-Bit Binary</li> <li>3-Digit BCD</li> <li>4-Digit BCD</li> <li>Reverse 12-Bit Binary</li> <li>Reverse 16-Bit Binary</li> <li>Reverse 3-Digit BCD</li> <li>Reverse 4-Digit BCD</li> </ul> <p>Selections using 16-bit binary or 4-digit BCD will require the configuration of terminals S1-S4 on the <b>Control Terminal Strip</b> as binary bits 0 – 3 (<b>F115 – F118</b>). The <b>Frequency Mode #1 Selection (F004)</b> must be set to <b>Binary/BCD Input</b>.</p> <p>For proper scaling of the binary or BCD input, parameters <b>F228 – F231</b> must be configured [<b>BIN Reference Point #1, BIN Reference #1 (frequency), Bin Reference Point #2, and BIN Reference #2 (frequency)</b>].</p>	<p><b>Direct Access Number — F107</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>None</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Fan Control Mode Selection</b></p> <p>Program ⇒ <b>Protection Settings</b></p> <p>This parameter sets the cooling fan run-time command.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Automatic</li> <li>Always On</li> </ul>	<p><b>Direct Access Number — F620</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Automatic</b></p> <p>Changeable During Run — <b>Yes</b></p>

**Fault Detect Station Number**

Program ⇒ Communication ⇒ **S20 Settings**

In a multiple-ASD configuration this setting determines the ASD responsible for fault notification.

**Direct Access Number — F868**

Parameter Type — **Selection List**

Factory Default — **0**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 64

**Feedback Input Selection**

Program ⇒ **Feedback Settings**

This parameter **Enables/Disables PID** feedback control. This parameter is enabled by selecting a source for motor-control feedback.

Settings:

- PID (Control) Disabled
- VI/II
- RR
- RX
- RX2 (option)

**Direct Access Number — F360**

Parameter Type — **Selection List**

Factory Default — **PID Disabled**


Changeable During Run — **Yes**

**FL Off Delay**

Program ⇒ Terminal Settings ⇒ **Output Terminal Delays**

This parameter delays the response of the **FL** output terminals by the programmed value.

The on and off delay times of the **FL** terminals may be adjusted to provide more response time to the device that is connected to the output terminals.



**Direct Access Number — F162**

Parameter Type — **Numerical**

Factory Default — **2.0**

Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0


Units — mS

**FL On Delay**

Program ⇒ Terminal Settings ⇒ **Output Terminal Delays**

This parameter delays the response of the **FL** output terminals by the programmed value.

The delay may be increased to prevent relay chatter.



**Direct Access Number — F152**

Parameter Type — **Numerical**

Factory Default — **2.0**

Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS


**FL Terminal Assignment**

Program ⇒ Terminal Settings ⇒ **Output Terminals**

This parameter sets the functionality of the **FL** output terminals to 1 of the 77 possible functions that are listed in [Table 7 on pg. 171](#).

The on and off delay times of the **FL** terminals may be adjusted to provide more response time to the device that is connected to the output terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.



**Direct Access Number — F132**

Parameter Type — **Selection List**

Factory Default — **Fault (All)**

Changeable During Run — **No**

**FM Terminal Adjustment**

Program ⇒ Terminal Settings ⇒ **FM/AM**

This function is used to calibrate the **FM** analog output terminal.

To calibrate the **FM** analog output, connect a meter (current or voltage) as described at the [FM Terminal Assignment](#) parameter.

With the ASD running at a known frequency, adjust this parameter until the running frequency produces the desired DC level output at the **FM** terminal.

**Direct Access Number — F006**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

**FM Terminal Assignment**

Program ⇒ Terminal Settings ⇒ **FM/AM**

This setting determines the output function of the **FM** analog output terminal. This output terminal produces an output current that is proportional to the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 172](#).

***Note:** To read **voltage** at this terminal connect a 100 – 500Ω resistor from FM (+) to FM (-). The voltage is read across the 100 – 500Ω resistor.*

*To read **current** at this terminal connect an ammeter from FM (+) to FM (-).*

The **FM** analog output has a maximum resolution of 1/1024. The **FM Terminal Adjustment** parameter must be used to calibrate the output signal for a proper response. **SW-2** may be switched to allow for the full-range output to be either 0 – 1 mA or 4 – 20 mA when providing an output current, or either 0 – 1 or 1 – 7.5 volts when providing an output voltage at this terminal.

**Direct Access Number — F005**

Parameter Type — **Selection List**

Factory Default — **Output Current**

Changeable During Run — **Yes**

<p><b>Forward Speed Limit Input</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Forward Speed Limit Input</b> control function. When enabled and operating in the <b>Torque Control</b> mode, the forward speed limit is controlled by the terminal selected here. If <b>Setting</b> is selected, the value set at <b>F426</b> is used as the <b>Forward Speed Limit</b> input.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>RX2 (option)</li> <li>Setting</li> </ul>	<p><b>Direct Access Number</b> — <b>F425</b></p> <p><b>Parameter Type</b> — <b>Selection List</b></p> <p><b>Factory Default</b> — <b>Disabled</b></p> <p><b>Changeable During Run</b> — <b>Yes</b></p>
<p><b>Forward Speed Limit Level</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>This parameter provides a value to be used as the <b>Forward Speed Limit</b> setting if <b>Setting</b> is selected at <b>F425</b>.</p>	<p><b>Direct Access Number</b> — <b>F426</b></p> <p><b>Parameter Type</b> — <b>Numerical</b></p> <p><b>Factory Default</b> — <b>80.0</b></p> <p><b>Changeable During Run</b> — <b>Yes</b></p> <p><b>Minimum</b> — 0.00</p> <p><b>Maximum</b> — <b>Upper Limit (F012)</b></p> <p><b>Units</b> — Hz</p>
<p><b>FP Terminal Adjustment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>FP Terminal</b></p> <p>This parameter sets the full-scale reading of the <b>FP</b> terminal. The full-scale reading of the monitored variable selected in <b>FP Terminal Setting</b> may be set here.</p>	<p><b>Direct Access Number</b> — <b>F677</b></p> <p><b>Parameter Type</b> — <b>Numerical</b></p> <p><b>Factory Default</b> — <b>3.840</b></p> <p><b>Changeable During Run</b> — <b>Yes</b></p> <p><b>Minimum</b> — 1.000</p> <p><b>Maximum</b> — 43.200</p> <p><b>Units</b> — kHz</p>
<p><b>FP Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>FP Terminal</b></p> <p>This parameter commands the multifunction programmable <b>FP</b> terminal to monitor the value of 1 of 33 possible system functions. As the monitored function changes in magnitude or frequency, the pulse count of the <b>FP</b> output pulse train changes in direct proportion to changes in the monitored function. As the monitored value goes up so does the pulse count of the <b>FP</b> output.</p> <p><i>Note: The duty cycle of the output pulse train remains at 65 ±5.0 μS.</i></p> <p>Possible assignments for this output terminal are listed in <a href="#">Table 8 on pg. 172</a>.</p>	<p><b>Direct Access Number</b> — <b>F676</b></p> <p><b>Parameter Type</b> — <b>Selection List</b></p> <p><b>Factory Default</b> — <b>Output Frequency</b></p> <p><b>Changeable During Run</b> — <b>Yes</b></p>

<p><b>Frequency Display Resolution</b></p> <p>Program ⇒ Utilities ⇒ <b>Display Attributes</b></p> <p>The parameter sets the number of decimal places to be displayed during non-<b>Accel/Decel</b> functions.</p>	<p><b>Direct Access Number — F703</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.1</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1</p> <p>Maximum — 0.01</p>
<p><b>Frequency for Automatic High-Speed Operation at Light-Load</b></p> <p>No Path — Direct Access Only</p> <p>This parameter establishes the speed that the ASD will ramp to when operating in the <b>Light-Load High-Speed</b> mode.</p>	<p><b>Direct Access Number — F341</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>80</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 80.00</p> <p>Units — %</p>
<p><b>Frequency Limit at Position</b></p> <p>No Path — Direct Access Only</p> <p>While operating in the <b>Position-Control</b> mode and using <b>PG</b> feedback, this setting determines the maximum acceleration rate in Hz/second.</p>	<p><b>Direct Access Number — F373</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>800</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 1</p> <p>Maximum — 8001</p> <p>Units — Hz/Second</p>
<p><b>Frequency Mode #1</b></p> <p>Program ⇒ Utilities ⇒ <b>Cmd. Frq, and Carrier</b></p> <p>The <b>Frequency Mode (#1)</b> setting establishes the source of the frequency-control input for the ASD.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>Option Card RX2</li> <li>LED Keypad Option</li> <li>Binary/BCD Input</li> <li>Common Serial (TTL)</li> <li>RS232/RS485</li> <li>Communication Card</li> <li>Motorized Pot. Simulation</li> <li>Pulse Input Option</li> </ul>	<p><b>Direct Access Number — F004</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>RR</b></p> <p>Changeable During Run — <b>No</b></p>

**Frequency Mode #2**

Program ⇒ Frequency Settings ⇒ **Reference Priority**

This parameter selects the source of the frequency command signal to be used as **Frequency Mode #2** in the event that **Frequency Mode #1** is disabled or if **Frequency Mode #2** is set up as the primary control parameter.

See the [Reference Priority Selection](#) parameter for additional information on this setting.

The **Frequency Mode** setting establishes the source of the frequency-control input for the ASD.

Settings:

- VI/II
- RR
- RX
- Option Card RX2
- LED Keypad Option
- Binary/BCD Input
- Common Serial (TTL)
- RS232/RS485
- Communication Card
- Motorized Pot. Simulation
- Pulse Input Option

**Direct Access Number — F207**

Parameter Type — **Selection List**

Factory Default — **RR**

Changeable During Run — **No**

**F Terminal Assignment**

Program ⇒ Terminal Settings ⇒ **Input Terminals**

This parameter selects the functionality of the **F** discrete input terminal.

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

This parameter sets the programmable **F** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

**Direct Access Number — F111**

Parameter Type — **Selection List**

Factory Default — **Forward**


Changeable During Run — **No**

**F Terminal Delay**

Program ⇒ Terminal Settings ⇒ **Input Terminal Delays**

This parameter delays the response of the ASD to any change in the **F** terminal input by the programmed value.

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.



**Direct Access Number — F140**

Parameter Type — **Numerical**

Factory Default — **8**

Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS



<p><b>Heavy-Load Torque During Fixed-Speed Forward Run</b></p> <p>No Path — Direct Access Only</p> <p>During forward deceleration, this parameter establishes the threshold torque level that is used to determine if the <b>Light-Load High-Speed (F331)</b> operation may engage or remain engaged if active.</p> <p>If the <b>Light-Load High-Speed</b> operation is terminated normal operation resumes.</p>	<p><b>Direct Access Number</b> — F337</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 250</p> <p>Units — %</p>
<p><b>Heavy-Load Torque During Fixed-Speed Reverse Run</b></p> <p>No Path — Direct Access Only</p> <p>During reverse deceleration, this parameter establishes the threshold torque level that is used to determine if the <b>Light-Load High-Speed (F331)</b> operation may engage or remain engaged if active.</p> <p>If the <b>Light-Load High-Speed</b> operation is terminated normal operation resumes.</p>	<p><b>Direct Access Number</b> — F340</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 250</p> <p>Units — %</p>
<p><b>Heavy-Load Torque During Forward Acceleration</b></p> <p>No Path — Direct Access Only</p> <p>During forward acceleration, this parameter establishes the threshold torque level that is used to determine if the <b>Light-Load High-Speed (F331)</b> operation may engage or remain engaged if active.</p> <p>If the <b>Light-Load High-Speed</b> operation is terminated normal operation resumes.</p>	<p><b>Direct Access Number</b> — F336</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>150</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 250</p> <p>Units — %</p>
<p><b>Heavy-Load Torque During Reverse Acceleration</b></p> <p>No Path — Direct Access Only</p> <p>During reverse acceleration, this parameter establishes the threshold torque level that is used to determine if the <b>Light-Load High-Speed (F331)</b> operation may engage or remain engaged if active.</p> <p>If the <b>Light-Load High-Speed</b> operation is terminated normal operation resumes.</p>	<p><b>Direct Access Number</b> — F339</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>150</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 250</p> <p>Units — %</p>
<p><b>Hz Per User-defined Unit</b></p> <p>Program ⇒ Utilities ⇒ <b>Display Attributes</b></p> <p>This parameter allows the user to input a quantity to be displayed on the EOI that is proportional to the output frequency of the drive.</p> <p>This feature is useful when the output of a process is moved along at a rate that is proportional to the output frequency of the drive.</p>	<p><b>Direct Access Number</b> — F702</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 200.0</p> <p>Units — Hz/UDU</p>

**Input Terminal Priority**Program ⇒ Terminal Settings ⇒ **Input Other**

This parameter is used to allow the **Jog** or the **DC Injection Braking** input signals to control the ASD when received via the **Control Terminal Strip** even though the system is in the **Local** mode.

With this parameter enabled, a **Jog** command or a **DC Injection Braking** command received from the **Control Terminal Strip** will receive priority over commands from the keypad.

See [Jog Run Frequency](#) for further information on using the **Jog** function.

See [DC Injection Braking Current](#) for further information on this parameter.

Settings:

- Enabled
- Disabled

**Direct Access Number — F106**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No****Inrush Current Suppression Time (MS Relay Delay)**Program ⇒ Protection Settings ⇒ **Overtorque**

The startup inrush current may be suppressed for up to 2.5 seconds. This parameter determines the length of the inrush current suppression.

**Direct Access Number — F608**Parameter Type — **Numerical**Factory Default — **0.30**Changeable During Run — **No**

Minimum — 0.30

Maximum — 2.50

Units — Seconds

**Integral (I) Gain**Program ⇒ **Feedback Settings**

This parameter determines the degree that the **Integral** function affects the output signal when using PID feedback to control the ASD output. The smaller the value here, the more pronounced the effect of the integral function on the output signal.

**Direct Access Number — F363**Parameter Type — **Numerical**Factory Default — **0.10**Changeable During Run — **Yes**

Minimum — 0.01

Maximum — 100.0

**Interlock Inrush Relay With ST**Program ⇒ **Protection Settings**

The **MS1 AUX** relay circuit is normally open and is in series with the **ST-to-CC** connection.

After normal system power is available the **MS1 AUX** relay circuit closes and completes the **ST-to-CC** connection.

**Direct Access Number — F609**Parameter Type — **Check Box**Factory Default — **Disabled**Changeable During Run — **Yes**

**Jog Run Frequency**

Program ⇒ Frequency Settings ⇒ **Jog Settings**

This parameter sets the output frequency of the ASD during a **Jog**. **Jogging** is the term used to describe turning the motor on for small increments of time and is used when precise positioning of motor-driven equipment is required.

The **Jog** function is initiated via the **Control Terminal Strip** or using **Communications** (for further information on using **Communications** for **Jogging** see the **Communications** manual).

To perform a **Jog**, first set this parameter to the desired **Jog** frequency.

Jog Using the Control Terminal Strip

To initiate a **Jog** from the **Control Terminal Strip** perform the following:

1. Assign a discrete input terminal to the **Jog** function (see [Table 6 on pg. 167](#)).
2. Assign a discrete input terminal to the **F (Forward)** function (and **Reverse** if required) (see [Table 6 on pg. 167](#)).
3. Provide a **Forward** and/or **Reverse** command from the **Control Terminal Strip**.
4. Place the system in the **Remote** mode (**Local/Remote** LED is off).
5. Connect the assigned **Jog** terminal (from step 1) to **CC** for the desired **Jog** duration.

**Direct Access Number** — F260

**Parameter Type** — Numerical

**Factory Default** — 0.00

**Changeable During Run** — Yes

**Minimum** — 0.00

**Maximum** — 20.00

**Units** — Hz

**Jog Stop Control**

Program ⇒ Frequency Settings ⇒ **Jog Settings**

This parameter sets the stopping method used while operating in the **Jog** mode.

Settings:

- Deceleration Stop
- Coast Stop
- DC Injection Braking Stop

**Direct Access Number** — F261

**Parameter Type** — Selection List

**Factory Default** — Coast Stop

**Changeable During Run** — Yes

**Jump Frequency #1**

Program ⇒ Special Control ⇒ **Jump Frequencies**

This parameter sets a frequency that, during acceleration, deceleration, or while running, will not be output from the ASD. This parameter operates in conjunction with the bandwidth setting of **Jump Frequency #1 Bandwidth**.

During acceleration, the output frequency of the ASD will hold at the frequency of the lower level of the **Jump Frequency** (1, 2, or 3) range until the programmed acceleration ramp reaches the upper level of the **Jump Frequency** range. Then, the output frequency of the ASD will accelerate to the upper level of the **Jump Frequency** range and continue upward as programmed.

During deceleration, the output frequency of the ASD will hold at the frequency of the upper level of the **Jump Frequency** range until the programmed deceleration ramp reaches the lower level of the **Jump Frequency** range. Then, the output frequency of the ASD will decelerate to the lower level of the **Jump Frequency** range and continue downward as programmed.

If overlapping **Jump Frequency** bandwidths are set up, the system will respond with one bandwidth setting that includes the total range.

Once set up and enabled, it is on in all control modes.

User-selected frequencies may be jumped to avoid the negative effects of mechanical resonance.

**Direct Access Number** — F270

**Parameter Type** — Numerical

**Factory Default** — 0.0

**Changeable During Run** — Yes

**Minimum** — 0.0

**Maximum** — Max. Freq.

**Units** — Hz

## Jump Frequency #1 Bandwidth

---

### Jump Frequency #1 Bandwidth

Program ⇒ Special Control ⇒ **Jump Frequencies**

This parameter establishes a plus-or-minus value for **Jump Frequency #1**.

See the [Jump Frequency #1](#) parameter for further information on this setting.

---

### Jump Frequency #2

Program ⇒ Special Control ⇒ **Jump Frequencies**

This parameter establishes the **Jump Frequency #2** setting.

Once set up and enabled, it is on in all control modes.

See the [Jump Frequency #1](#) parameter for further information on this setting.

---

### Jump Frequency #2 Bandwidth

Program ⇒ Special Control ⇒ **Jump Frequencies**

This parameter establishes a plus-or-minus value for **Jump Frequency #2**.

See the [Jump Frequency #1](#) parameter for further information on this setting.

---

### Jump Frequency #3

Program ⇒ Special Control ⇒ **Jump Frequencies**

This parameter establishes the **Jump Frequency #3** setting.

Once set up and enabled, it is on in all control modes.

See the [Jump Frequency #1](#) parameter for further information on this setting.

---

### Jump Frequency #3 Bandwidth

Program ⇒ Special Control ⇒ **Jump Frequencies**

This parameter establishes a plus-or-minus value for **Jump Frequency #3**.

See the [Jump Frequency #1](#) parameter for further information on this setting.

## Jump Frequency #3 Bandwidth

---

**Direct Access Number** — F273

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.00

Units — Hz

---

**Direct Access Number** — F271

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — Max. Freq.

Units — Hz

---

**Direct Access Number** — F274

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — Hz

---

**Direct Access Number** — F272

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — Max. Freq.

Units — Hz

---

**Direct Access Number** — F275

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — Hz

<p><b>Jump Frequency Processing</b></p> <p>Program ⇒ Special Control ⇒ <b>Jump Frequencies</b></p> <p>This parameter determines if the output frequency of the ASD or the PID feedback signal will be used as a reference for determining the <b>Jump Frequency</b> range.</p> <p>See the <a href="#">Jump Frequency #1</a> parameter for further information on this setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Process Amount (use PID feedback)</li> <li>Output Frequency</li> </ul>	<p><b>Direct Access Number</b> — <b>F276</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Process Amount</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Light-Load High-Speed Operation Load Detection Time</b></p> <p>No Path — Direct Access Only</p> <p>This parameter determines the length of time that the load requirement must meet the <b>Light-Load High-Speed</b> criteria before the <b>Light-Load High-Speed Enable (F330)</b> is recognized.</p> <p>Once recognized, the timer setting of <b>F332</b> must expire to engage the <b>Light-Load High-Speed</b> function.</p>	<p><b>Direct Access Number</b> — <b>F333</b></p> <p>Parameter Type — <b>Yes</b></p> <p>Factory Default — <b>1.0</b></p> <p>Changeable During Run — <b>Numerical</b></p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p><b>Light-Load High-Speed Operation Load Wait Time</b></p> <p>No Path — Direct Access Only</p> <p>After the time setting of <b>F333</b> times out, this parameter determines the length of time that the <b>Light-Load High-Speed</b> criteria must be met until the <b>Light-Load High-Speed</b> function engages.</p>	<p><b>Direct Access Number</b> — <b>F332</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p><b>Light-Load High-Speed Operation Heavy-Load Detection Time</b></p> <p>No Path — Direct Access Only</p> <p>While operating in the <b>Light-Load High-Speed</b> mode, this parameter determines the length of time that a load exceeding the <b>Light-Load High-Speed</b> operation criteria may exist before the <b>Light-Load High-Speed</b> mode is terminated and normal operation resumes.</p>	<p><b>Direct Access Number</b> — <b>F334</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>5.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>

**Light-load High-speed Operation Selection**

No Path — Direct Access Only

This parameter enables the **Light-Load High-Speed** function by selecting an operating mode. The **Light-Load High-Speed** function accelerates the output frequency of the ASD from the programmed speed to the setting established in **F341**.

This parameter may be disabled.

If either of the other selections are made and configured, and after the criteria of **F331 – F333** are met, the **Light-Load High-Speed** function is enabled and this parameter setting determines the operating mode of the **Light-Load High-Speed** function.

Settings:

- 0 — Disabled
- 1 — Reserved
- 2 — Automatic Enable - Automatic Speed (**F341**)
- 3 — Automatic Enable - Preset Speed (Preset ID<sub>Bin</sub> is OR'ed w/1000<sub>Bin</sub>)
- 4 — Discrete Enable - Automatic Speed (**F341**)
- 5 — Discrete Enable - Preset Speed (Preset ID<sub>Bin</sub> is OR'ed w/1000<sub>Bin</sub>) (see **Light-Load High-Speed Enable** selection at [Table 6 on page 167](#))

**Light-Load High-Speed Operation Switching Lower-Limit Frequency**

No Path — Direct Access Only

This parameter sets an output frequency threshold that, once surpassed, allows the **Light-load High-speed** function to be used.

The **Light-Load High-Speed** function may be used if the frequency threshold (**F331**) and the following conditions are met:

- 1) **Light-Load High-Speed Operation Enable** is configured at **F330**.
- 2) The output torque is less than the setting established in **F335** when reaching the frequency setting here.

**Load Inertia (Acc/Dec Torque)**

No Path — Direct Access Only

This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the **Drooping Control** mode.

**Direct Access Number — F330**Parameter Type — **Selection List**Factory Default — **1 — Disabled**Changeable During Run — **No**

Minimum — 30.0

Maximum — **Upper Limit (F012)**

Units — Hz

**Direct Access Number — F331**Parameter Type — **Numerical**Factory Default — **40.00**Changeable During Run — **Yes**

Minimum — 30.0

Maximum — **Upper Limit (F012)**

Units — Hz

**Direct Access Number — F325**Parameter Type — **Numerical**Factory Default — **1.0**Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 1000.0

<p><b>Load Sharing Gain Input</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Control</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Load Sharing Gain</b> input function and is enabled by selecting a <b>Load Sharing Gain</b> input signal source.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>RX2 (option)</li> <li>LED Keypad Option</li> <li>Binary/BCD Input</li> <li>Common Serial (TTL)</li> <li>RS232/RS485</li> <li>Communication Card</li> </ul>	<p><b>Direct Access Number</b> — F424</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Load Torque Filter (Acc/Dec Torque)</b></p> <p>No Path — Direct Access Only</p> <p>This parameter is used to set the response sensitivity when calculating the accel/decel torque. This setting applies to load inertia compensation while operating in the <b>Drooping Control</b> mode.</p> <p>This parameter should be gradually adjusted to provide smoother <b>Drooping Control</b> operation while operating with heavy loads.</p>	<p><b>Direct Access Number</b> — F326</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>200.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 200.0</p>
<p><b>Lock-on Rate</b></p> <p>No Path — Direct Access Only</p> <p>After a momentary power outage, the ASD may have to startup into a spinning motor. The <b>Lock On Rate</b> is the difference between the time that the RPM of the motor is determined by the ASD and the time that the ASD outputs a drive signal to the motor.</p> <p>See <b>Break/Make ST</b> for additional information on this parameter.</p>	<p><b>Direct Access Number</b> — F313</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.50</p> <p>Maximum — 2.50</p>
<p><b>Low Current Trip</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Low Current</b></p> <p>This parameter <b>Enables/Disables</b> the low-current trip feature.</p> <p>When enabled, the ASD will trip on a low-current fault if the output current of the ASD falls below the level defined at the <b>Low Current Setting</b> parameter for a duration that exceeds the <b>Low Current Time</b> parameter setting.</p>	<p><b>Direct Access Number</b> — F610</p> <p>Parameter Type — <b>Check Box</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Low Current Trip Threshold</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Low Current</b></p> <p>The <b>Low-current Trip</b> parameter enables this function. The <b>Low Current Trip Threshold</b> establishes the low-current threshold value. The threshold value is entered as a percentage of the maximum rating of the ASD.</p>	<p><b>Direct Access Number</b> — F611</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 100.00</p> <p>Units — %</p>

<p><b>Low Current Trip Threshold Time</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Low Current</b></p> <p>When the low-current monitor is enabled, this function sets the time that the low-current condition must exist to cause a trip.</p>	<p><b>Direct Access Number — F612</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 255</p> <p>Units — Seconds</p>
<p><b>Lower Deviation Limit</b></p> <p>Program ⇒ <b>Feedback Settings</b></p> <p>This parameter determines the maximum amount that the feedback may decrease the output signal.</p>	<p><b>Direct Access Number — F365</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>50.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 50.00</p> <p>Units — %</p>
<p><b>Lower Limit Frequency</b></p> <p>Program ⇒ Fundamental Parameters ⇒ <b>Fundamental #1</b></p> <p>This parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD will output frequencies lower than the <b>Lower Limit Frequency</b> when accelerating to the lower limit or decelerating to a stop. Frequencies below the <b>Lower Limit</b> may also be output when operating in the <b>PID Control</b> mode, <b>Torque Control</b> mode, or the <b>Vector Control</b> modes (sensorless or feedback).</p>	<p><b>Direct Access Number — F013</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<p><b>Low Output Disable Boost Level</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p>The <b>Low Output Disable</b> feature adds the user-input frequency value to the commanded frequency (Hz).</p>	<p><b>Direct Access Number — F734</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Low Output Disable Boost Time</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p>The <b>Low Output Disable Boost Time</b> sets the on-time timer for the <b>LOD Boost</b> function.</p> <p>Once expired, the <b>LOD Boost</b> function ceases.</p>	<p><b>Direct Access Number — F735</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 3600.0</p> <p>Units — Seconds</p>



<p><b>Low Output Disable Feedback Level</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p>The <b>Low Output Disable Feedback Level</b> sets a frequency level that, until the output of the ASD drops below this setting, the <b>Restart Delay Timer</b> does not start.</p>	<p><b>Direct Access Number</b> — F736</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Low Output Disable Restart Delay Time</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p>The <b>Low Output Disable Restart Delay Time</b> sets the time that, once expired and all standard ASD requirements are met, normal ASD operation resumes.</p>	<p><b>Direct Access Number</b> — F737</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 3600.0</p> <p>Units — Seconds</p>
<p><b>Low Output Disable Selection</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p><b>Enables/Disables</b> the <b>LOD</b> function and, if enabled, selects a stopping method.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled — Decel Stop</li> <li>Enabled — Coast Stop</li> </ul>	<p><b>Direct Access Number</b> — F731</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Low Output Disable Start Level</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p>The <b>Low Output Disable Start Level</b> sets the output frequency threshold that, if exceeded, will initiate the <b>LOD</b> function if properly configured.</p>	<p><b>Direct Access Number</b> — F732</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Low Output Disable Start Time</b></p> <p>Program ⇒ <b>Special Control</b> ⇒ <b>Low Output Disable</b></p> <p>The <b>Low Output Disable Delay Time</b> sets the amount of time that the <b>LOD Start Level</b> criteria must be met and maintained for the <b>LOD</b> function to be initiated.</p>	<p><b>Direct Access Number</b> — F733</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 3600.0</p> <p>Units — Seconds</p>

<p><b>Low Speed Signal Output Frequency</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the low-speed trip threshold.</p>	<p><b>Direct Access Number — F100</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<hr/>	
<p><b>Main EEPROM Version</b></p> <p>Program ⇒ Utilities ⇒ <b>Versions</b></p> <p>This is a read-only parameter that displays the Main EEPROM version.</p>	
<p><b>Maximum Output Frequency</b></p> <p>Program ⇒ Fundamental Parameters ⇒ <b>Fundamental #1</b></p> <p>This setting determines the absolute maximum frequency that the ASD can output. This setting is also referred to as <b>FH</b>.</p> <p><b>Accel/decel</b> times are calculated based on the <b>Maximum Frequency</b> setting.</p> <p><i>Note: This setting may not be lower than the <b>Upper Limit</b> setting.</i></p>	<p><b>Direct Access Number — F011</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>80.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 30.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<hr/>	
<p><b>Maximum Output Voltage #1</b></p> <p>Program ⇒ Fundamental Parameters ⇒ <b>Fundamental #1</b></p> <p>This parameter sets the maximum value of the output voltage of the ASD for the <b>#1 Motor Set</b>.</p> <p>Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> parameter setting.</p>	<p><b>Direct Access Number — F306</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — (ASD dependent)</p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — (ASD dependent)</p> <p>Units — Volts</p>
<hr/>	
<p><b>Maximum Output Voltage #2</b></p> <p>Program ⇒ Fundamental Parameters ⇒ <b>Fundamental #2</b></p> <p>This parameter sets the maximum value of the output voltage of the ASD for the <b>#2 Motor Set</b>.</p> <p>Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> parameter setting.</p>	<p><b>Direct Access Number — F171</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — (ASD dependent)</p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — (ASD dependent)</p> <p>Units — Volts</p>

<p><b>Maximum Output Voltage #3</b></p> <p>Program ⇒ <b>Motor Settings</b></p> <p>This parameter sets the maximum value of the output voltage of the ASD for the <b>#3 Motor Set</b>.</p> <p>Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> parameter setting.</p>	<p><b>Direct Access Number — F175</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — (ASD dependent)</p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — (ASD dependent)</p> <p>Units — Volts</p>
<p><b>Maximum Output Voltage #4</b></p> <p>Program ⇒ <b>Motor Settings</b></p> <p>This parameter sets the maximum value of the output voltage of the ASD for the <b>#4 Motor Set</b>.</p> <p>Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the <b>Supply Voltage Compensation</b> parameter setting.</p>	<p><b>Direct Access Number — F179</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — (ASD dependent)</p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — (ASD dependent)</p> <p>Units — Volts</p>
<p><b>Mode 1/2 Switching Frequency</b></p> <p>Program ⇒ Frequency Settings ⇒ <b>Reference Priority</b></p> <p>This parameter sets the threshold frequency that will be used in the <b>Reference Priority Selection</b> parameter to determine if <b>Frequency Mode #1</b> or <b>#2</b> will control the output of the ASD.</p>	<p><b>Direct Access Number — F208</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.10</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Motorized Pot Frequency at Power Down</b></p> <p>No Path — Direct Access Only</p> <p>When the <b>Frequency Mode #1 Selection</b> (F004) setting is set to <b>MOP Function Simulation</b>, this parameter determines the outcome of the <b>Frequency Mode #1</b> setting at powerdown or stop.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Erase</li> <li>Store</li> </ul> <p>If <b>Erase</b> is selected, the ASD will <b>not</b> store the frequency setpoint and establishes a setpoint of 0.0 Hz when restarted.</p> <p>If <b>Store</b> is selected, the ASD will maintain the current frequency setpoint in memory while stopped, during fault conditions, or when power is removed. This setpoint will be used as the initial frequency setpoint when the ASD is restarted.</p> <p>A control terminal configured as <b>MOP Frequency Clear</b> will establish a frequency setpoint of 0.0 Hz regardless of the <b>Motorized Pot Frequency at Power Down</b> setting.</p>	<p><b>Direct Access Number — F108</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Erase</b></p> <p>Changeable During Run — <b>No</b></p>

<p><b>Motor 150% Overload Time Limit</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overload</b></p> <p>This parameter establishes a time that the motor may operate at 150% of its rated current before tripping. This setting applies the time/150% reference to the individual settings of each motor (e.g., this setting references 150% of the <b>Thermal Protection</b> setting for the #1 motor).</p> <p>The unit will trip sooner than the time entered here if the overload is greater than 150%.</p>	<p><b>Direct Access Number — F607</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>600</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10</p> <p>Maximum — 2400</p> <p>Units — Seconds</p>
<p><b>Motor Capacity (kW)</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Settings</b></p> <p>This user-input parameter identifies the wattage rating of the motor.</p>	<p><b>Direct Access Number — F401</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.10</p> <p>Maximum — (ASD-dependent)</p> <p>Units — kW</p>
<p><b>Motor Constant #1</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>This parameter is the measurement of the stator resistance and is considered a <b>Motor Constant</b> (unchanging). This value is used in conjunction with other constants to tune the motor.</p> <p>To use <b>Vector Control</b>, <b>Automatic Torque Boost</b>, or <b>Automatic Energy-saving</b>, the <b>Motor Constant</b> setting (motor tuning) is required.</p>	<p><b>Direct Access Number — F402</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100,000 MΩ</p> <p>Units — Ω</p>
<p><b>Motor Constant #2</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>This parameter is the measurement of the rotor resistance and is considered a <b>Motor Constant</b> (unchanging). This value is used in conjunction with other constants to tune the motor.</p> <p>This setting (motor tuning) is required to use the <b>Vector Control</b>, <b>Automatic Torque Boost</b>, or <b>Automatic Energy-saving</b> functions.</p>	<p><b>Direct Access Number — F403</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — Open</p> <p>Units — Ω</p>
<p><b>Motor Constant #3</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>This parameter is used to input the excitation inductance for the motor. This value is used in conjunction with other constants to tune the motor.</p> <p>This setting (motor tuning) is required to use the <b>Vector Control</b>, <b>Automatic Torque Boost</b>, or <b>Automatic Energy-saving</b> functions.</p>	<p><b>Direct Access Number — F404</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 6500.0</p> <p>Units — μH</p>

<p><b>Motor Constant #4</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>This parameter is used to compensate for the affects of load inertia during speed changes.</p> <p>Acceleration and deceleration overshoot may be reduced by increasing this value.</p> <p>This setting (motor tuning) is required to use the <b>Vector Control, Automatic Torque Boost</b>, or <b>Automatic Energy-saving</b> functions.</p>	<p><b>Direct Access Number — F405</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p>
<p><b>Motor Constant #5</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>This parameter is used to compensate for the affects of leakage inductance.</p> <p>Increases in this setting results in slight increases in the output voltage of the ASD at the high speed range.</p> <p>This (motor tuning) setting is required to use the <b>Vector Control, Automatic Torque Boost</b>, or <b>Automatic Energy-saving</b> functions.</p>	<p><b>Direct Access Number — F410</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 650.0</p> <p>Units — <math>\mu\text{H}</math></p>
<p><b>Motor Counter Data</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the pulses-per-revolution displayed at the Monitor screen when using a shaft-mounted encoder for speed control. This setting is used for display purposes only and does not affect the speed control of the system.</p> <p>If zero is selected here then the setting at F370 (Electronic Gear Setting) determines the pulses-per-revolution to be displayed at the Monitor screen.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li><b>Selection 0</b> — F370 setting</li> <li><b>Selection 1</b> — 256 pulses/revolution</li> <li><b>Selection 2</b> — 512 pulses/revolution</li> <li><b>Selection 3</b> — 1024 pulses/revolution</li> <li><b>Selection 4</b> — 2048 pulses/revolution</li> <li><b>Selection 5</b> — 4096 pulses/revolution</li> </ul>	<p><b>Direct Access Number — F378</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Selection 0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — Selection 0</p> <p>Maximum — Selection 5</p>
<p><b>Motor Shaft Stationary Control</b></p> <p>Program ⇒ Protection Settings ⇒ <b>DC Injection</b></p> <p>This parameter <b>Enables/Disables</b> a continuous DC injection at half of the amperage setting of the <b>DC Injection Braking Current</b> parameter into a stopped motor. This feature is useful in preheating the motor or to keep a stopped motor from spinning freely.</p> <p><b>Motor Shaft Stationary Control</b> starts after the DC injection brake stops the motor and continues until <b>ST-to-CC</b> is opened, power is turned off, receiving an <b>Emergency Off</b> command, or this parameter is changed.</p> <p>To use this feature, a non-zero entry at the <b>DC Injection Braking Start Frequency</b> parameter is required.</p>	<p><b>Direct Access Number — F254</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>

<p><b>Motor Type</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Settings</b></p> <p>This parameter identifies the type of motor being used.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Toshiba EQP III TEFC</li> <li>Toshiba EQP III ODP</li> <li>Toshiba EPACK TEFC</li> <li>Toshiba EPACK ODP</li> <li>Other Motor</li> </ul>	<p><b>Direct Access Number — F413</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Toshiba EQP III TEFC</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Multiplying Input Selection</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overtorque</b></p> <p>This parameter <b>Enables/Disables</b> the feature that allows for the external adjustment of the <b>Output Frequency</b>. Selecting <b>PID Control Disabled</b> disables this feature.</p> <p>Selecting either of the input control methods listed enables this feature. The signal amplitude of the selected input is used as a variable multiplier of the programmed <b>Output Frequency</b>.</p> <p>If operating using the <b>LED Keypad Option</b> and <b>Setting</b> is selected, the value entered at the <b>LED Option Override Multiplication Gain</b> parameter is used as the multiplier.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>PID (Control) Disabled</li> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>RX2 (option)</li> <li>Setting (LED Keypad Option Only)</li> </ul> <p><b>Proportional-Integral-Derivative (PID)</b> — A closed-loop control technique that seeks error minimization by reacting to three values: One that is proportional to the error, one that is representative of the error, and one that is representative of the rate of change of the error.</p>	<p><b>Direct Access Number — F661</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>PID Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Number of Motor Poles</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Motor Settings</b></p> <p>This parameter is used to input the number of motor poles.</p>	<p><b>Direct Access Number — F411</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>4</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — <b>2</b></p> <p>Maximum — <b>16</b></p>

**Number of Retries**

Program ⇒ Protection Settings ⇒ **Retry/Ridethrough**

After a trip has occurred, this parameter sets the number of times that an automatic system restart is attempted for a qualified trip.

The trip conditions listed below will not initiate the **Retry** function:

- OCA1, 2, or 3 (Arm Short Ckt),
- EPH1 (Input Phase Failure),
- EPH0 (Output Phase Failure),
- OCL (Startup Overcurrent),
- EF1 or 2 (Ground Fault),
- EMG (Emergency Off),
- EEP1 (EEPROM Fault),
- Err2 through Err9 (Main RAM/ROM Fault),
- E-10 (Sink/Source Error),
- 13 (Speed Error), or
- 17 (Key Error).

See the section titled [General Safety Information on pg. 1](#) for further information on this setting.

**Direct Access Number — F303**

Parameter Type — **Numerical**

Factory Default — **0**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 10

**ON Terminal Assignment**

Program ⇒ Terminal Settings ⇒ **Input Terminals**

This parameter selects the functionality of the **ON** discrete input virtual terminal.

As a virtual terminal, the **ON** control terminal exists only in memory and is considered to always be in its **True** (or connected to **CC**) state.

It is often practical to assign this terminal to a function that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **ON** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

**Direct Access Number — F110**

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

**Optional Analog Terminal Mark**

No Path — Direct Access Only

This parameter selects the polarity of the analog output of the option board being used.

Settings:

- None
- +
- 
- ±

**Direct Access Number — F680**

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **No**

<p><b>OUT1 Off Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT1 (A &amp; C)</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The on and off delay times of the <b>OUT1</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p>	<p><b>Direct Access Number — F160</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT1 On Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT1 (A &amp; C)</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL On Delay</a>).</p> <p>The delay may be increased to prevent relay chatter.</p>	<p><b>Direct Access Number — F150</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT1 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the functionality of the <b>OUT1 (A &amp; C)</b> output contacts to 1 of the 77 possible functions that are listed in <a href="#">Table 7 on pg. 171</a>.</p> <p>The on and off delay times of the <b>OUT1</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p> <p>In addition, the output contacts must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p>	<p><b>Direct Access Number — F130</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Low Speed</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>OUT2 Off Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT2 (A &amp; C)</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The on and off delay times of the <b>OUT2</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p>	<p><b>Direct Access Number — F161</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT2 On Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>This parameter delays the response of the <b>OUT2 (A &amp; C)</b> output contacts by the programmed value (see waveforms at <a href="#">FL On Delay</a>).</p> <p>The delay may be increased to prevent relay chatter.</p>	<p><b>Direct Access Number — F151</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>



<p><b>OUT2 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the functionality of the <b>OUT2 (A &amp; C)</b> output contacts to 1 of the 77 possible functions that are listed in <a href="#">Table 7 on pg. 171</a>.</p> <p>The on and off delay times of the <b>OUT2</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p> <p>In addition, the output contacts must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p>	<p><b>Direct Access Number — F131</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Acc/Dec Complete</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>OUT4 Off Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT4</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The on and off delay times of the <b>OUT4</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p>	<p><b>Direct Access Number — F163</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT4 On Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>This parameter delays the response of the <b>OUT4</b> output contacts by the programmed value (see waveforms at <a href="#">FL On Delay</a>).</p> <p>The delay may be increased to prevent relay chatter.</p>	<p><b>Direct Access Number — F153</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT4 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the functionality of the <b>OUT4</b> output contacts to 1 of the 77 possible functions that are listed in <a href="#">Table 7 on pg. 171</a>.</p> <p>The on and off delay times of the <b>OUT4</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p> <p>In addition, the output contacts must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p>	<p><b>Direct Access Number — F133</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Lower Limit</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>OUT5 Off Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT5</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The on and off delay times of the <b>OUT5</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p>	<p><b>Direct Access Number — F164</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>

<p><b>OUT5 On Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>This parameter delays the response of the <b>OUT5</b> output contacts by the programmed value (see waveforms at <a href="#">FL On Delay</a>).</p> <p>The delay may be increased to prevent relay chatter.</p>	<p><b>Direct Access Number — F154</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT5 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the functionality of the <b>OUT5</b> output contacts to 1 of the 77 possible functions that are listed in <a href="#">Table 7 on pg. 171</a>.</p> <p>The on and off delay times of the <b>OUT5</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p> <p>In addition, the output contacts must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p>	<p><b>Direct Access Number — F134</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>OUT6 Off Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT6</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The on and off delay times of the <b>OUT6</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p>	<p><b>Direct Access Number — F165</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT6 On Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>This parameter delays the response of the <b>OUT6</b> output contacts by the programmed value (see waveforms at <a href="#">FL On Delay</a>).</p> <p>The delay may be increased to prevent relay chatter.</p>	<p><b>Direct Access Number — F155</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT6 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the functionality of the <b>OUT6</b> output contacts to 1 of the 77 possible functions that are listed in <a href="#">Table 7 on pg. 171</a>.</p> <p>The on and off delay times of the <b>OUT6</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p> <p>In addition, the output contacts must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p>	<p><b>Direct Access Number — F135</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Reach Speed</b></p> <p>Changeable During Run — <b>No</b></p>

<p><b>OUT7 Off Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>Once the condition is met to change the state of the <b>OUT7</b> output contacts, this parameter delays the response of the contacts by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The on and off delay times of the <b>OUT7</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p>	<p><b>Direct Access Number</b> — F166</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT7 On Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminal Delays</b></p> <p>This parameter delays the response of the <b>OUT7</b> output contacts by the programmed value (see waveforms at <a href="#">FL On Delay</a>).</p> <p>The delay may be increased to prevent relay chatter.</p>	<p><b>Direct Access Number</b> — F156</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>OUT7 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Output Terminals</b></p> <p>This parameter sets the functionality of the <b>OUT7</b> output contacts to 1 of the 77 possible functions that are listed in <a href="#">Table 7 on pg. 171</a>.</p> <p>The on and off delay times of the <b>OUT7</b> contacts may be adjusted to provide more response time to the device that is connected to the output terminals.</p> <p>In addition, the output contacts must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p>	<p><b>Direct Access Number</b> — F136</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>OC Alarm</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Output Phase Loss Detection</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Phase Loss</b></p> <p>This parameter <b>Enables/Disables</b> the monitoring of each phase of the 3-phase output signal (U, V, or W) of the ASD. If either line is missing, inactive, or not of the specified level, the ASD incurs a trip.</p>	<p><b>Direct Access Number</b> — F605</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Output Short Circuit Test</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Short Circuit Test</b></p> <p>This parameter determines when the system will perform an <b>Output Short Circuit</b> test.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Every Power up</li> <li>Every Run</li> </ul>	<p><b>Direct Access Number</b> — F613</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Every Run</b></p> <p>Changeable During Run — <b>No</b></p>

<p><b>Overcurrent Stall Level</b></p> <p>Program ⇒ <b>Protection Settings</b> ⇒ <b>Stall</b></p> <p>This parameter specifies the output current level at which the output frequency is reduced in an attempt to prevent a trip. The overcurrent level is entered as a percentage of the maximum rating of the ASD.</p> <p><i>Note:</i> <i>Soft Stall must be enabled to use this feature.</i></p>	<p><b>Direct Access Number</b> — <b>F601</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 200.0</p> <p>Units — %</p>
<p><b>Over Exciting Cooperation</b></p> <p>No Path — Direct Access Only</p> <p>This parameter determines the method used to control the rate that the excitation current is allowed to reach saturation.</p> <p>If <b>Effective</b> is selected, the preset <b>Torque Control</b> or <b>Speed Control</b> settings will determine the rate that the motor reaches excitation saturation.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Effective</li> <li>Applied by <b>F480</b></li> </ul>	<p><b>Direct Access Number</b> — <b>F481</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Effective</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Overload Reduction Starting Frequency</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overload</b></p> <p>This parameter is used to reduce the start frequency during very low-speed motor operation. During very low-speed operation the cooling efficiency of the motor decreases. Lowering the start frequency aides in minimizing the generated heat.</p>	<p><b>Direct Access Number</b> — <b>F606</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>6.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 30.00</p> <p>Units — Hz</p>
<p><b>Overspeed Detection Frequency Range</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Abnormal Speed</b></p> <p>This parameter sets the upper level of the <b>Base Frequency</b> range that, once exceeded, will cause an <b>Overspeed Detected</b> alert.</p>	<p><b>Direct Access Number</b> — <b>F623</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>
<p><b>Overtorque Detection Time</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overtorque</b></p> <p>This parameter sets the amount of time that the overtorque condition may exceed the tripping threshold level set at <b>Overtorque Trip/Alarm Level (Positive Torque)</b> and <b>Overtorque Trip/Alarm Level (Negative Torque)</b> before a trip occurs.</p>	<p><b>Direct Access Number</b> — <b>F618</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.50</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 100.0</p> <p>Units — Seconds</p>

<p><b>Overtorque Trip</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overtorque</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Over Torque Tripping</b> function.</p> <p>When enabled, the ASD trips if an output torque larger than the setting of parameters <b>Overtorque Trip/Alarm Level (Positive Torque)</b> or <b>Overtorque Trip/Alarm Level (Positive Torque)</b> is detected for a time longer than the setting of the <b>Overtorque Detection Time</b> parameter.</p> <p>When disabled, the ASD does not trip due to overtorque conditions.</p>	<p><b>Direct Access Number — F615</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Overtorque Trip/Alarm Level (negative torque)</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overtorque</b></p> <p>This parameter sets the torque threshold level that is used as a setpoint for overtorque tripping during regeneration. This setting is a percentage of the maximum rated torque of the ASD.</p>	<p><b>Direct Access Number — F617</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>150.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Overtorque Trip/Alarm Level (positive torque)</b></p> <p>Program ⇒ <b>Protection Settings</b></p> <p>This parameter sets the torque threshold level that is used as a setpoint for overtorque tripping. This setting is a percentage of the maximum rated torque of the ASD.</p>	<p><b>Direct Access Number — F616</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>150.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Overvoltage Stall</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Stall</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Overvoltage Stall</b> function.</p> <p>When enabled, this function causes the ASD to extend the decel time when the DC bus voltage increases due to transient voltage spikes, regeneration, supply voltage out of specification, etc. in an attempt to reduce the bus voltage.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Enabled</li> <li>Disabled</li> <li>Enabled (Forced Shorted Deceleration)</li> </ul>	<p><b>Direct Access Number — F305</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>

<p><b>Overvoltage Stall Level</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Stall</b></p> <p>This parameter sets the upper DC bus voltage threshold that, once exceeded, will cause an <b>Overvoltage Stall</b>. An <b>Overvoltage Stall</b> increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an <b>Overvoltage Trip</b>.</p> <p>If the overvoltage condition persists for over 4 mS, an <b>Overvoltage Trip</b> will be incurred.</p> <p><i>Note: This feature may increase deceleration times.</i></p>	<p><b>Direct Access Number — F626</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 50.0</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Overvoltage Stall Level (fast)</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Stall</b></p> <p>This parameter sets the upper DC bus voltage threshold that, once exceeded, will cause an <b>Overvoltage Stall</b>. An <b>Overvoltage Stall</b> increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an <b>Overvoltage Trip</b>.</p> <p>If the overvoltage condition persists for over 250 μS, an <b>Overvoltage Trip</b> will be incurred.</p> <p><i>Note: This feature may increase deceleration times.</i></p>	<p><b>Direct Access Number — F625</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 50.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Panel Acceleration/Deceleration Select</b></p> <p>No Path — Direct Access Only</p> <p>This parameter is used to select 1 of 4 accel/decel profiles that may be configured and run. Each accel/decel profile is comprised of 3 user settings: <b>Acceleration, Deceleration, and Pattern</b>.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>1</li> <li>2</li> <li>3</li> <li>4</li> </ul>	<p><b>Direct Access Number — F504</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>1</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Panel Direction</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the motor direction while operating from the keypad.</p>	<p><b>Direct Access Number — F008</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Forward</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Panel PID Control</b></p> <p>No Path — Direct Access Only</p> <p><b>Enables/Disables PID</b> control while operating from the keypad.</p>	<p><b>Direct Access Number — F724</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Enabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Panel Reset Selection</b></p> <p>No Path — Direct Access Only</p> <p><b>Enables/Disables</b> the ability to reset the system from the keypad.</p>	<p><b>Direct Access Number — F722</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Enabled</b></p> <p>Changeable During Run — <b>Yes</b></p>

<p><b>Panel Stop Pattern</b></p> <p>No Path — Direct Access Only</p> <p>The <b>Decel Stop</b> or <b>Coast Stop</b> settings determine the method used to stop the motor when using the <b>Stop Reset</b> key of the keypad.</p> <p>The <b>Decel Stop</b> setting enables either the <b>Dynamic Braking</b> system or the <b>DC Injection Braking</b> system. The <b>Coast Stop</b> setting allows the motor to stop at the rate allowed by the inertia of the load.</p>	<p><b>Direct Access Number</b> — F721</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Decel Stop</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Panel V/f Group Selection</b></p> <p>No Path — Direct Access Only</p> <p>This parameter is used to select 1 of 4 V/f profiles may be selected and run. Each V/f profile is comprised of 4 user settings: <b>Base Frequency</b>, <b>Base Frequency Voltage</b>, <b>Manual Torque Boost</b>, and <b>Thermal Protection</b>.</p> <p>Settings:</p> <ol style="list-style-type: none"> <li>1</li> <li>2</li> <li>3</li> <li>4</li> </ol>	<p><b>Direct Access Number</b> — F720</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>1</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Parity (RS232/RS485/TTL)</b></p> <p>Program ⇒ <b>Communication Settings</b></p> <p>This parameter plays a role in the setup of the communications network by establishing the <b>Parity</b> setting of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>No Parity</li> <li>Even Parity</li> <li>Odd Parity</li> </ul>	<p><b>Direct Access Number</b> — F801</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Even Parity</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>PG Disconnect Detection Selection</b></p> <p>Program ⇒ <b>Feedback Settings</b></p> <p>This parameter <b>Enables/Disables</b> the system's monitoring of the PG connection status when using encoders with line driver outputs.</p> <p><b>Note:</b> <i>The ASD-Multicom-J option board is required to use this feature.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	<p><b>Direct Access Number</b> — F369</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>

**PID Feedback Input**

Program ⇒ System Information and Setup ⇒ **PID Setup**

This parameter **Enables/Disables PID** feedback control. When enabled, this parameter determines the source of the motor-control feedback.

Settings:

- PID Control Disabled
- VI/II
- RR
- RX
- RX2 (option)

**Proportional-Integral-Derivative (PID)** — A closed-loop control technique that seeks error minimization by reacting to three values: One that is proportional to the error, one that is representative of the error, and one that is representative of the rate of change of the error.

**Direct Access Number — F360**

Parameter Type — **Selection List**

Factory Default — **Control Disabled**

Changeable During Run — **Yes**

**PG Input Phases**

Program ⇒ **Feedback Settings**

This setting determines if motor speed and direction will be conveyed by the encoder.

Settings:

- Single-Phase
- Two-Phase

**Direct Access Number — F368**

Parameter Type — **Selection List**

Factory Default — **Two-Phase**

Changeable During Run — **No**

**PG Number of Pulses**

Program ⇒ **Feedback Settings**

This parameter is used to set the end-of-travel range when using an encoder on a motor-driven positioning system (e.g., hoist/crane, etc.).

**Direct Access Number — F367**

Parameter Type — **Numerical**

Factory Default — **500**

Changeable During Run — **No**

Minimum — 1

Maximum — 9999

Units — Pulse Count



**PG Speed Frequency Setpoint #1 (Hz)**

Program ⇒ Frequency Settings ⇒ **Speed Reference Setpoints**

This parameter is used to set the gain, bias, and direction of the **PG** input when the **PG** input is used as the **Speed/Direction** control input.

The **PG** input signal is a pulse train originating from a shaft-mounted **Encoder**.

*Note: The **PG** input terminal is available with the **ASD-Multicom** option board only.*

**PG Input Speed/Direction Control Setup**

Perform the following setup to allow the system to receive **Speed/Direction** control input at the **PG** input:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ (any setting).
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **Pulse Input**.

**Speed/Direction Control**

Perform the following setup to allow the system to perform **PG Speed/Direction** control:

- Set the **PG** input signal value (F234) that will produce the output frequency established at the **PG Speed Frequency Setpoint #1 (Hz)** parameter.
- Set **PG Speed Frequency Setpoint #1 (Hz)**.
- Set the **PG** input signal value (F236) that will produce the output frequency setting established at the **PG Speed Frequency Setpoint #2 (Hz)** parameter.
- Set **PG Speed Frequency Setpoint #2 (Hz)**.
- Provide a **Run** command (**F** and/or **R**).

Once set, as the **PG** input pulse count changes, the directional information or the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **Communications Speed Frequency Setpoint #1 (Hz)** (direction/speed) and is the output frequency that is associated with the setting of **Communications Speed Reference Setpoint #1 (%)** when operating in the **Speed Control** mode.

The range of values for this parameter is -100 to +100% of the **PG** input pulse count range.

*Note: Further application-specific **PG** settings may be performed from the following path: Program ⇒ **Feedback Settings**.*

**Direct Access Number — F235**

Parameter Type — **Numerical**

Factory Default — **0.0**


Changeable During Run — **Yes**

Minimum — -80.0

Maximum — +80.0

Units — Hz

**Frequency Settings**



**PG Speed Frequency Setpoint #2 (Hz)**

Program ⇒ Frequency Settings ⇒ **Speed Reference Setpoints**

This parameter is used to set the gain, bias, and direction of the **PG** input terminal when it is used as the **Speed/Direction** control input.

This parameter sets **PG Speed Frequency Setpoint #2 (Hz)** and is the frequency that is associated with the **PG Speed Reference Setpoint #2 (%)** setting.

See **PG Speed Frequency Setpoint #1 (Hz)** for further information on this setting.

**Direct Access Number — F237**

Parameter Type — **Numerical**

Factory Default — **80.0**

Changeable During Run — **Yes**

Minimum — -80.0

Maximum — +80.0

Units — Hz

**PG Speed Reference Setpoint #1 (%)**

Program ⇒ Frequency Settings ⇒ **Speed Reference Setpoints**

This parameter is used to set the gain, bias, and direction of the **PG** input terminal when it is used as the **Speed/Direction** control input.

This parameter sets the **PG** input pulse count that represents **PG Speed Frequency Setpoint #1 (Hz)** (direction/speed) and is entered as a percentage of the full ± range.

The range of values for this parameter is -100 to +100% of the **PG** input pulse count range.

See **PG Speed Frequency Setpoint #1 (Hz)** for further information on this setting.

**Direct Access Number — F234**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — -100.0

Maximum — +100.0

Units — %

**PG Speed Reference Setpoint #2 (%)**

Program ⇒ Frequency Settings ⇒ **Speed Reference Setpoints**

This parameter is used to set the gain, bias, and direction of the **PG** input terminal when it is used as the **Speed/Direction** control input.

This parameter sets the **PG** input pulse count that represents **PG Speed Frequency Setpoint #2 (Hz)** (direction/speed) and is entered as a percentage of the full ± range.

The range of values for this parameter is -100 to +100% of the **PG** input pulse count range.

See **PG Speed Frequency Setpoint #1 (Hz)** for further information on this setting.

**Direct Access Number — F236**

Parameter Type — **Numerical**

Factory Default — **+100.00**

Changeable During Run — **Yes**

Minimum — -100.0

Maximum — +100.0

Units — %

**Position Completion Range**

No Path — Direct Access Only

During a deceleration ramp, this parameter sets a speed range that must be attained before the **Stop** command may be executed.

**Direct Access Number — F372**

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**


Minimum — 1

Maximum — 4000

**Position Loop Gain**

No Path — Direct Access Only

This parameter provides a divisor for the pulse input when operating in the **Pulse Control** mode.



**Direct Access Number — F371**

Parameter Type — **Numerical**

Factory Default — **4.00**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 100.0

**Powerline Switching At-Trip Selection**

No Path — Direct Access Only

This parameter **Enables/Disables** the **Powerline Switching** feature. When enabled, the system is instructed to discontinue using the output of the drive and to switch to the commercial power in the event of a trip or when reaching a user-set frequency.

This feature may also be activated via a discrete input terminal set to **Line (Power) Bypass** (see [Table 6 on page 167](#) for a listing of terminal settings).

Place a check in the **On Trip** box to enable Switch-to-Powerline at trip.

Place a check in the **At Frequency** box and provide a switching frequency to enable Switch-to-Powerline at frequency.

Place a check in both enable boxes to enable both. The first of the two qualifying events will cause the switch-to-powerline function.

**Power-Line Switching At-Trip Selection Frequency**

No Path — Direct Access Only

With the **At Frequency** box checked, this parameter sets the frequency at which the **At Frequency** selection of the **Power Switching** parameter is activated.

If the **Power Switching** function is activated via a discrete input terminal, this setting sets the frequency at which discrete input terminal is enabled for activation.

*Note:* Uncheck the **At-Frequency** box to use the discrete input terminal for activation.

**Direct Access Number — F354**Parameter Type — **Check Box**Factory Default — **Disabled**Changeable During Run — **No****Direct Access Number — F355**Parameter Type — **Numerical**Factory Default — **60.0**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq.**

Units — Hz


**Priority Selection**Program ⇒ Terminal Settings ⇒ **Input Other**

The **Direction Priority** selection determines the operation of the ASD if both the **R** and **F** control terminals are activated simultaneously.

Settings:

- Reverse
- Suspend

The waveforms below depict the motor response for all combinations of the **F** and **R** terminal settings if the **Reverse** option is chosen.



The **Suspend** setting will decelerate the motor to a stop regardless of the rotation direction when both the **F** and **R** control terminals are activated.

**Prohibit Initializing User Parameters During Typeform Initialization**

No Path — Direct Access Only

This parameter **Enables/Disables** the ability to initialize user parameters during a **Type Form** initialization.

Settings:

- Allowed
- Prohibited

**Direct Access Number — F105**Parameter Type — **Selection List**Factory Default — **Reverse**Changeable During Run — **No****Direct Access Number — F709**Parameter Type — **Selection List**Factory Default — **Allowed**Changeable During Run — **Yes****Power Running Torque Limit #1**Program ⇒ Torque Settings ⇒ **Torque Limit**

This parameter determines the source of the control signal for the positive torque limit setting. If **Setting** is selected, the value set at **F441** is used as the **Power Running Torque Limit #1** input.

Settings:

- VI/II
- RR
- RX
- RX2 (option)
- Setting

**Direct Access Number — F440**Parameter Type — **Selection List**Factory Default — **Setting**Changeable During Run — **Yes**

**Preset Speed #1**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

Up to 15 output frequency values that fall within the **Lower Limit** and the **Upper Limit** range may be programmed into the ASD and output as a **Preset Speed**. This parameter assigns an output frequency to binary number 0001 and is identified as **Preset Speed #1**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed**.

Perform the following setup to allow the system to receive **Preset Speed** control input at the **S1 – S4** terminals:

1. Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **Binary/BCD**.
2. Program ⇒ Terminal Settings ⇒ Input Terminals ⇒ **S1** (set to **Set Speed 1**; LSB of 4-bit count). Repeat for **S2 – S4 Terminals** (to the MSB of the 4-bit count) as **Set Speed 2 – 4**, respectively (all **Normally Open**).

*Note: The default setting of S4 is EOff, but this terminal may be re-assigned as the MSB. EOFF is a safety feature that should be assigned to another terminal.*

3. Program ⇒ Preset Speeds ⇒ **1** (set an output frequency for **Preset Speed #1**; repeat for **Preset Speed 2 – 15** as required).
4. Program ⇒ Preset Speeds ⇒ Mode ⇒ **Enable/Disable**.

When **Enabled**, the **Speed, Direction, Accel/Decel Group, V/f Group,** and the **Torque Limit Group** settings for the active **Preset Speed** are used (applies to all 1–15).

When **Disabled**, only the speed setting of the active **Preset Speed** is used.

5. From the **Frequency Command** screen (only), place the system in the **Remote** mode (**Local|Remote** LED Off).
6. Provide a **Run** command (connect **F** and/or **R** to **CC**).

Connect **S1** to **CC** to run **Preset Speed #1** (**S1** to **CC** = 0001 binary).

With **S1 – S4** configured to output **Preset Speeds**, 0001<sub>B</sub> – 1111<sub>B</sub> may be applied to **S1 – S4** of the **Control Terminal Strip** to run the associated **Preset Speed** of the truth table.

If bidirectional operation is required, **F** and **R** must be connected to **CC**, and the **Mode** setting must be **Enabled** for a given **Preset Speed** being run.

With **S1** being the least significant bit of a binary count, the **S1 – S4** settings will produce the programmed speed settings as indicated in the truth table to the right.

**Direct Access Number — F018**

Parameter Type — **Numerical**

Factory Default — **60.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed Truth Table.**

PS#	S4 MSB	S3	S2	S1 LSB	Output
1	0	0	0	1	F018
2	0	0	1	0	F019
3	0	0	1	1	F020
4	0	1	0	0	F021
5	0	1	0	1	F022
6	0	1	1	0	F023
7	0	1	1	1	F024
8	1	0	0	0	F287
9	1	0	0	1	F288
10	1	0	1	0	F289
11	1	0	1	1	F290
12	1	1	0	0	F291
13	1	1	0	1	F292
14	1	1	1	0	F293
15	1	1	1	1	F294

*Note: 1 = Terminal connected to CC.*

**Preset Speed #2**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 0010 and is identified as **Preset Speed #2**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F019**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #3**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 0011 and is identified as **Preset Speed #3**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F020**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #4**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 0100 and is identified as **Preset Speed #4**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F021**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #5**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 0101 and is identified as **Preset Speed #5**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F022**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #6**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 0110 and is identified as **Preset Speed #6**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F023**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #7**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 0111 and is identified as **Preset Speed #7**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F024**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #8**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 1000 and is identified as **Preset Speed #8**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F287**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #9**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 1001 and is identified as **Preset Speed #9**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F288**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #10**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 1010 and is identified as **Preset Speed #10**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F289**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #11**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 1011 and is identified as **Preset Speed #11**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F290**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

**Preset Speed #12**

Program ⇒ Preset Speeds ⇒ **Preset Speeds**

This parameter assigns an output frequency to binary number 1100 and is identified as **Preset Speed #12**. The binary number is applied to **S1 – S4** of the **Control Terminal Strip** to output the **Preset Speed** (see [Preset Speed #1](#) for further information on this parameter).

**Direct Access Number — F291**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — **Lower Limit**

Maximum — **Upper Limit (F012)**

Units — Hz

<p><b>Preset Speed #13</b></p> <p>Program ⇒ Preset Speeds ⇒ <b>Preset Speeds</b></p> <p>This parameter assigns an output frequency to binary number 1101 and is identified as <b>Preset Speed #13</b>. The binary number is applied to <b>S1 – S4</b> of the <b>Control Terminal Strip</b> to output the <b>Preset Speed</b> (see <a href="#">Preset Speed #1</a> for further information on this parameter).</p>	<p><b>Direct Access Number — F292</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — <b>Lower Limit</b></p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<p><b>Preset Speed #14</b></p> <p>Program ⇒ Preset Speeds ⇒ <b>Preset Speeds</b></p> <p>This parameter assigns an output frequency to binary number 1110 and is identified as <b>Preset Speed #14</b>. The binary number is applied to <b>S1 – S4</b> of the <b>Control Terminal Strip</b> to output the <b>Preset Speed</b> (see <a href="#">Preset Speed #1</a> for further information on this parameter).</p>	<p><b>Direct Access Number — F293</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — <b>Lower Limit</b></p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<p><b>Preset Speed #15</b></p> <p>Program ⇒ Preset Speeds ⇒ <b>Preset Speeds</b></p> <p>This parameter assigns an output frequency to binary number 1111 and is identified as <b>Preset Speed #15</b>. The binary number is applied to <b>S1 – S4</b> of the <b>Control Terminal Strip</b> to output the <b>Preset Speed</b> (see <a href="#">Preset Speed #1</a> for further information on this parameter).</p>	<p><b>Direct Access Number — F294</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — <b>Lower Limit</b></p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<p><b>Preset Speed Mode Control</b></p> <p>Program ⇒ Preset Speeds ⇒ <b>Preset Speed Mode</b></p> <p><b>Enables/Disables</b> the use of the <b>Preset Speed Mode</b> control for <b>Preset Speeds 1 – 15</b>.</p> <p>The <b>Preset Speed Mode</b> control setting determines if the <b>Speed</b> setting only is used (disabled) or if the user-set combinations of the <b>Torque, Speed, Accel/Decel</b>, and <b>Direction</b> settings will be used (enabled) while running <b>Preset Speeds 1 – 15</b>.</p>	<p><b>Direct Access Number — F380</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Proportional (P) Gain</b></p> <p>Program ⇒ <b>Feedback Settings</b></p> <p>This parameter determines the degree that the <b>Proportional</b> function affects the output signal when using PID feedback to control the ASD output. The larger the value entered here, the quicker the ASD responds to changes in feedback.</p>	<p><b>Direct Access Number — F362</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.10</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.01</p> <p>Maximum — 100.0</p>



**PWM Carrier Frequency**

Program ⇒ Special Control ⇒ **Carrier Frequency**

This parameter sets the frequency of the pulse width modulation signal applied to the motor.

*Note:* The carrier frequency must be 2.2 kHz or above except when operating in the **Constant Torque** or the **Variable Torque** modes.

*Note:* The maximum **Carrier Frequency** setting allowed is 5.0 kHz for the 460-volt, 150 HP – 300 HP.

The maximum **Carrier Frequency** setting allowed for all other ASDs is 15 kHz.

Setting the Carrier Frequency above the Derate Threshold frequency (as listed below) for a given ASD will reduce the capability of the ASD.

**Carrier-Frequency Derate Threshold Frequency**

Derate Threshold Frequency		
4.0 kHz	5.0 kHz	8.0 kHz
VT130W7U		
4600B	412KB – 415KB	4750B – 410KB

**Ramped PWM Enable**

No Path — Direct Access Only

**Enables/Disables** the variable PWM frequency.

**Direct Access Number — F300**

Parameter Type — **Numerical**

Factory Default — **2.200**

Changeable During Run — **No**

Minimum — 0.500

Maximum — (ASD-dependent)

Units — kHz

**Direct Access Number — F963**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

### Reference Priority Selection

Program ⇒ Frequency Settings ⇒ **Reference Priority**

Either the **Frequency Mode (#1)** or the **Frequency Mode #2** setting may control the output frequency of the ASD. This parameter setting determines which of the two will control the output frequency and the conditions in which control will be switched from one to the other.

Settings:

- Freq Mode #1
- Freq Mode #2
- Freq #1 Priority
- Freq #2 Priority
- Freq Priority Switching

The **Freq Mode #1** or **Freq Mode #2** setting specifies the source of the input frequency-command signal.

If **Freq Mode #1** is selected here, the ASD will follow the speed command of the **Freq Mode #1** selection. If **Freq Mode #2** is selected here, the ASD will follow the speed command of the **Freq Mode #2** selection.

The **Freq #1 Priority** and **Freq #2 Priority** selections are used in conjunction with the **Mode #1/#2 SW (Switching) Freq** parameter setting. The **Mode #1/#2 SW (Switching) Freq** parameter establishes a threshold frequency that will be used as a reference when determining when to toggle the output control between the **Frequency Mode (#1)** selection and the **Frequency Mode #2** selection.

If **Freq #1 Priority** is selected here and the commanded frequency exceeds the **Mode #1/#2 SW (Switching) Freq** setting, then the **Freq Mode #1** selection has priority over the **Freq Mode #2** selection.

If **Freq #2 Priority** is selected here and the commanded frequency exceeds the **Mode #1/#2 SW (Switching) Freq** setting, then the **Freq Mode #2** selection has priority over the **Freq Mode #1** selection.

**Freq Priority Switching** allows for the activation of a pre configured discrete input terminal to toggle the frequency control between the selections of **Freq Mode #1** and **Freq Mode #2**. Any unused programmable discrete input terminal may be programmed as the **Frequency Prty (Priority) Switch** terminal (See [Table 6 on pg. 167](#) for a listing of the available discrete input terminal settings).


**Direct Access Number — F200**

Parameter Type — **Selection List**

Factory Default — **Freq Mode #1 Priority**

Changeable During Run — **Yes**

This function is enabled by setting the **Ref Priority Sel** to **Freq Priority Switching** and is located at Program ⇒ Frequency Settings ⇒ **Reference Priority**.



Once the commanded frequency exceeds the F208 value, the setting of parameter F200 determines if the #1 or the #2 frequency command source controls the ASD output.

### Regeneration Torque Limit #1

Program ⇒ Torque Settings ⇒ **Torque Limit**

This parameter determines the source of the **Regenerative Torque Limit** control signal.

If **Setting** is selected, the value set at **F443** is used for this function.

Settings:

- VI/II
- RR
- RX
- RX2 (option)
- Setting

**Direct Access Number — F442**

Parameter Type — **Selection List**

Factory Default — **Setting**

Changeable During Run — **Yes**

<p><b>Regeneration Torque Limit #1 Setting</b></p> <p>Program ⇒ Torque Settings ⇒ Manual Torque Limit ⇒ <b>Regeneration Torque Limit</b></p> <p>This parameter provides a value to be used as the <b>Regeneration Torque Limit #1</b> if <b>Setting</b> is selected at <b>F442</b>.</p>	<p><b>Direct Access Number — F443</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Regeneration Torque Limit #2</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Manual Torque Limit</b></p> <p>This parameter is used to set the negative torque upper limit for the #2 motor profile when multiple motors are controlled by a single drive or when a single motor is to be controlled by multiple profiles.</p>	<p><b>Direct Access Number — F445</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Regeneration Torque Limit #3</b></p> <p>Program ⇒ Torque Setting ⇒ <b>Manual Torque Limit</b></p> <p>This parameter is used to set the negative torque upper limit for the #3 motor profile when multiple motors are controlled by a single drive or when a single motor is to be controlled by multiple profiles.</p>	<p><b>Direct Access Number — F447</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Regeneration Torque Limit #4</b></p> <p>Program ⇒ Torque Setting ⇒ <b>Manual Torque Limit</b></p> <p>This parameter is used to set the negative torque upper limit for the #4 motor profile when multiple motors are controlled by a single drive or when a single motor is to be controlled by multiple profiles.</p>	<p><b>Direct Access Number — F449</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>250.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p><b>Release (brake) After Run Timer</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overtorque</b></p> <p>This parameter sets the time that the brake will hold after the <b>Run</b> command criteria has been met.</p>	<p><b>Direct Access Number — F632</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>

<p><b>RES Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>RES</b> discrete input terminal.</p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>RES</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number</b> — F114</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Reset</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>RES Terminal Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminal Delays</b></p> <p>This parameter delays the response of the ASD to any change in the <b>RES</b> terminal input by the programmed value (see waveforms at <a href="#">F Terminal Delay</a>).</p> <p>The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.</p>	<p><b>Direct Access Number</b> — F143</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>8.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>Reverse Speed Limit Input</b></p> <p>Program ⇒ Torque Setting Parameters ⇒ <b>Torque Control</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Reverse Speed Limit Input</b> control function. When enabled and operating in the <b>Torque Control</b> mode, the reverse speed limit is controlled by the terminal selected here. If <b>Setting</b> is selected, the value set at <b>F428</b> is used as the <b>Reverse Speed Limit</b> input.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>RX2 (option)</li> <li>Setting</li> </ul>	<p><b>Direct Access Number</b> — F427</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Reverse Speed Limit Level</b></p> <p>Program ⇒ Torque Settings ⇒ Torque Speed Limit ⇒ <b>Reverse Speed Limit Level</b></p> <p>This parameter provides a value to be used as the <b>Reverse Speed Limit</b> setting if <b>Setting</b> is selected at <b>F427</b>.</p>	<p><b>Direct Access Number</b> — F428</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>80.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Upper Limit (F012)</b></p> <p>Units — Hz</p>
<p><b>Revision</b></p> <p>Program ⇒ Utilities ⇒ <b>Version</b></p> <p>This is a read-only parameter that displays the revision level of the CPU.</p>	<p><b>Direct Access Number</b> — <b>None</b></p>

<p><b>Ridethrough Mode</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Retry/Ridethrough</b></p> <p><b>Enables/Disables</b> the <b>Ridethrough</b> function.</p> <p>In the event of a momentary power outage or a make/break at <b>ST-to-CC</b>, when enabled, the <b>Ridethrough</b> function uses regenerative energy to maintain the control circuitry settings.</p> <p>Regenerated energy is not used to drive the motor.</p>	<p><b>Direct Access Number</b> — <b>F302</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Ridethrough Time</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Retry/Ridethrough</b></p> <p>In the event of a momentary power outage, this parameter determines the length of the <b>Ridethrough</b> time. During a <b>Ridethrough</b>, regenerative energy is used to maintain the control circuitry settings; it is not used to drive the motor.</p> <p>The <b>Ridethrough</b> will be maintained for the number of seconds set using this parameter.</p> <p><i>Note: The actual <b>Ridethrough Time</b> is load-dependent.</i></p>	<p><b>Direct Access Number</b> — <b>F310</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 320.0</p> <p>Units — Seconds</p>
<p><b>RR Bias Adjust</b></p> <p>Program ⇒ Frequency Setting ⇒ Speed Reference Setpoints ⇒ RR ⇒ <b>Bias</b></p> <p>This parameter is used to fine tune the bias of the <b>RR</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and either increasing or decreasing this setting to provide an output of zero from the ASD.</p>	<p><b>Direct Access Number</b> — <b>F472</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 255</p>
<p><b>RR Gain Adjust</b></p> <p>Program ⇒ Frequency Setting Parameters ⇒ Speed Reference Setpoints ⇒ RR ⇒ <b>Gain</b></p> <p>This parameter is used to fine tune the gain of the <b>RR</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and either increasing or decreasing this setting to provide an output of 100% from the ASD.</p>	<p><b>Direct Access Number</b> — <b>F473</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>184</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 255</p>

**RR Speed Frequency Setpoint #1 (Hz)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RR**

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode. Once setup, the gain and bias may be fine-tuned for application-specific requirements via parameters [F472](#) and [F473](#)

**RR Input Speed Control Setup**

Perform the following setup to allow the system to receive **Speed** control input at the **RR** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **RR.**

**Speed Control**

Perform the following setup to allow the system to perform **Speed** control from the **RR** input terminal:

- Set the **RR** input signal level ([F210](#)) that will produce the output frequency established at the **RR Speed Frequency Setpoint #1 (Hz)** parameter.
- Set **RR Speed Frequency Setpoint #1 (Hz)**.
- Set the **VI/II** input signal level ([F212](#)) that will produce the output frequency setting established at the **RR Speed Frequency Setpoint #2 (Hz)** parameter.
- Set **RR Speed Frequency Setpoint #2 (Hz)**.
- Provide a **Run** command (**F** and/or **R**).

Once set, as the **RR** input voltage changes the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **RR Speed Frequency Setpoint #1 (Hz)** and is the frequency that is associated with the setting of **RR Speed Reference Setpoint #1 (%)** when operating in the **Speed Control** mode.

**Direct Access Number — F211**

Parameter Type — **Numerical**

Factory Default — **0.0**


Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 80.0

Units — Hz

**Frequency Settings**



**RR Speed Frequency Setpoint #2 (Hz)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RR**

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

See [RR Speed Frequency Setpoint #1 \(Hz\)](#) for further information on this setting.

This parameter sets **RR Speed Frequency Setpoint #2 (Hz)** and is the frequency that is associated with the setting of **RR Speed Reference Setpoint #2 (%)** when operating in the **Speed Control** mode.

**Direct Access Number — F213**

Parameter Type — **Numerical**

Factory Default — **80.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 80.0

Units — Hz

<p><b>RR Speed Reference Setpoint #1 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>RR</b></p> <p>This parameter is used to set the gain and bias of the <b>RR</b> input terminal when the <b>RR</b> terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">RR Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">RR Torque Reference Setpoint #1 (%)</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>RR</b> input level that is associated with <a href="#">RR Speed Frequency Setpoint #1 (Hz)</a> when operating in the <b>Speed</b> control mode or is associated with the <a href="#">RR Torque Reference Setpoint #1 (%)</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as 0.0 to +100% of the 0 – 10 VDC <b>RR</b> input signal range.</p>	<p><b>Direct Access Number — F210</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>RR Speed Reference Setpoint #2 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>RR</b></p> <p>This parameter is used to set the gain and bias of the <b>RR</b> input terminal when the <b>RR</b> terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">RR Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">RR Torque Reference Setpoint #1 (%)</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>RR</b> input level that is associated with <a href="#">RR Speed Frequency Setpoint #2 (Hz)</a> when operating in the <b>Speed</b> control mode or is associated with the <a href="#">RR Torque Reference Setpoint #2 (%)</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as 0.0 to +100% of the 0 – 10 VDC <b>RR</b> input signal range.</p>	<p><b>Direct Access Number — F212</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>

**RR Torque Reference Setpoint #1 (%)**

Program ⇒ Torque Settings ⇒ Torque Reference Setpoints ⇒ **RR**

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

**RR Input Torque Control Setup**

Perform the following setup to allow the system to receive **Torque** control input at the **RR** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip**.
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **RR**.

**Torque Control**

Perform the following setup to allow the system to perform **Torque** control from the **RR** input terminal:

- Set **RR Torque Reference Setpoint #1 (%)**.
- Set the **RR** input signal level (**RR Speed Reference Setpoint #1 (%)**) that represents the **RR Torque Reference Setpoint #1 (%)**.
- Set **RR Torque Reference Setpoint #2 (%)**.
- Set the **RR** input signal level (**RR Speed Reference Setpoint #2 (%)**) that represents the **RR Torque Reference Setpoint #2 (%)**.
- Provide a **Run** command (**F** and/or **R**).

This parameter sets **RR Torque Reference Setpoint #1 (%)** and is the output torque value that is associated with the setting of **RR Speed Reference Setpoint #1 (%)** when operating in the **Torque** control mode.

This value is entered as 0.0 to 250% of the output torque range.

**Direct Access Number — F214**

Parameter Type — **Numerical**


Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 250.0

Units — %

**Torque Settings****RR Torque Reference Setpoint #2 (%)**

Program ⇒ Torque Settings ⇒ Torque Reference Setpoints ⇒ **RR**

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

See **RR Torque Reference Setpoint #1 (%)** for further information on this setting.

This parameter sets **RR Torque Reference Setpoint #2 (%)** and is the output torque value that is associated with setting of **RR Speed Reference Setpoint #2 (%)** when operating in the **Torque** control mode.

This value is entered as 0.0 to 250% of the output torque range.

**Direct Access Number — F215**

Parameter Type — **Numerical**

Factory Default — **100.00**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 250.0

Units — %



<p><b>RS232/RS485 Baud Rate</b></p> <p>Program ⇒ Communication ⇒ <b>Communication Settings</b></p> <p>This parameter sets the RS232/RS485 baud rate.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>1200</li> <li>2400</li> <li>4800</li> <li>9600</li> <li>19200</li> <li>38400</li> </ul>	<p><b>Direct Access Number — F820</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>9600</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>RS232/RS485 Communication Time-Out Action</b></p> <p>Program ⇒ Communication ⇒ <b>Communication Settings</b></p> <p>This parameter plays a role in the setup of the communications network by determining the action to be taken in the event of a time-out (<b>Time-Out Action</b>).</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>No Action</li> <li>Trip</li> <li>Alarm</li> </ul>	<p><b>Direct Access Number — F804</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Trip</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>RS232/RS485 Communication Time-Out Time</b></p> <p>Program ⇒ Communication ⇒ <b>Communication Settings</b></p> <p>This parameter plays a role in the setup of the communications network by setting the time that no activity may exist over the communications link before the link is severed (<b>Time Out</b>).</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p>	<p><b>Direct Access Number — F803</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — Seconds</p>
<p><b>RS232/RS485 Delay Time</b></p> <p>Program ⇒ <b>Communication Settings</b></p> <p>This parameter sets the <b>RS232/RS485</b> response delay time.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p>	<p><b>Direct Access Number — F825</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — 0.00</p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 2.00</p> <p>Units — Seconds</p>

<p><b>RS232/RS485 Master Output</b></p> <p>Program ⇒ Communication ⇒ <b>Communication Settings</b></p> <p>In a master/follower configuration, this setting determines the output parameter of the master ASD that will be used to control the applicable follower ASDs.</p> <p><i>Note: Select Normal if TTL Master Out is configured as a Master Output controller. Otherwise, a keypad failure will result.</i></p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Normal (No Follower)</li> <li>Frequency Reference</li> <li>Output Frequency</li> <li>Torque Reference</li> <li>Output Torque</li> </ul>	<p><b>Direct Access Number — F806</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Normal (No Follower)</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>RS232/RS485 Wire Count</b></p> <p>Program ⇒ <b>Communication Settings</b></p> <p>This parameter sets the communications protocol to the 2 or 4 wire method.</p> <p>Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>2 wire</li> <li>4 wire</li> </ul>	<p><b>Direct Access Number — F821</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — 4-Wire</p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>R Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>R</b> discrete input terminal.</p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>R</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F112</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Reverse</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>R Terminal Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminal Delays</b></p> <p>This parameter delays the response of the ASD to any change in the <b>R</b> terminal input by the programmed value.</p> <p>The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.</p>	<p><b>Direct Access Number — F141</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>8.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>

<p><b>Run Frequency</b></p> <p>Program ⇒ Special Control ⇒ <b>Frequency Control</b></p> <p>This parameter establishes a center frequency (<b>Run Frequency</b>) of a frequency band.</p> <p>The <b>Run Frequency Hysteresis</b> parameter provides a plus-or-minus value for the <b>Run Frequency</b>; thus, establishing a frequency band.</p> <p>During acceleration, the ASD will not output a signal to the motor until the lower level of the band is reached.</p> <p>During deceleration, the ASD will continue to output the programmed deceleration output signal to the motor until the lower level of the band is reached; at which time the output will go to 0.0 Hz.</p>	<p><b>Direct Access Number — F241</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Run Frequency Hysteresis</b></p> <p>Program ⇒ Special Control ⇒ <b>Frequency Control</b></p> <p>This parameter provides a plus-or-minus value for the <b>Run Frequency</b> setting.</p>	<p><b>Direct Access Number — F242</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>
<p><b>RX2 Bias Adjust</b></p> <p>Program ⇒ Frequency Setting Parameters ⇒ Speed Reference Setpoints ⇒ RX2 ⇒ <b>Bias</b></p> <p>This parameter is used to fine tune the bias of the <b>RX2</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and either increasing or decreasing this setting to provide a zero output from the ASD.</p>	<p><b>Direct Access Number — F476</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>99</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 255</p>
<p><b>RX2 Gain Adjust</b></p> <p>Program ⇒ Frequency Setting Parameters ⇒ Speed Reference Setpoints ⇒ RX2 ⇒ <b>Gain</b></p> <p>This parameter is used to fine tune the gain of the <b>RX2</b> input terminal when this terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and either increasing or decreasing this setting to provide an output of 100% from the ASD.</p>	<p><b>Direct Access Number — F477</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>141</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 255</p>

**RX2 Speed Frequency Setpoint #1 (Hz)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX2**

This parameter is used to set the gain, bias, and direction of the **RX2** input terminal when the **RX2** terminal is used as the control input while operating in the **Speed Control** mode.

*Note: The **RX2** input terminal is available with the **ASD-Multicom** option board only.*

**RX2 Input Speed/Direction Control Setup**

Perform the following setup to allow the system to receive **Speed** control input at the **RX2** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **RX2.**

**Speed/Direction Control**

Perform the following setup to allow the system to perform **Speed** control from the **RX2** input terminal:

- Set the **RX2** input signal level (F222) that will produce the output frequency established at the **RX2 Speed Frequency Setpoint #1 (Hz)** parameter.
- Set **RX2 Speed Frequency Setpoint #1 (Hz)**.
- Set the **RX2** input signal level (F224) that will produce the output frequency setting established at the **RX2 Speed Frequency Setpoint #2 (Hz)** parameter.
- Set **RX2 Speed Frequency Setpoint #2 (Hz)**.
- Provide a **Run** command (**F** and/or **R**).

Once set, as the **RX2** input voltage changes, the directional information, and the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **RX2 Speed Frequency Setpoint #1 (Hz)** and is the frequency that is associated with the setting of **RX2 Speed Reference Setpoint #1 (%)** when operating in the **Speed Control** mode.

**Direct Access Number — F223**

**Parameter Type — Numerical**

**Factory Default — 0.0**


**Changeable During Run — Yes**

**Minimum — -Max. Freq.**

**Maximum — +Max. Freq.**

**Units — Hz**

Frequency Settings



**RX2 Speed Frequency Setpoint #2 (Hz)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX2**

This parameter is used to set the gain, bias, and direction of the **RX2** input terminal when the **RX2** terminal is used as the control input while operating in the **Speed Control** mode.

See **RX2 Speed Frequency Setpoint #1 (Hz)** for further information on this setting.

This parameter sets **RX2 Speed Frequency Setpoint #2 (Hz)** and is the frequency that is associated with the setting of **RX2 Speed Reference Setpoint #2 (%)** when operating in the **Speed Control** mode.

**Direct Access Number — F225**

**Parameter Type — Numerical**

**Factory Default — 80.0**

**Changeable During Run — Yes**

**Minimum — -Max. Freq.**

**Maximum — +Max. Freq.**

**Units — Hz**

<p><b>RX2 Speed Reference Setpoint #1 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>RX2</b></p> <p>This parameter is used to set the gain, bias, and direction of the <b>RX2</b> input terminal when the <b>RX2</b> terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">RX2 Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">RX2 Speed Reference Setpoint #1 (%)</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>RX2</b> input level that is associated with <a href="#">RX2 Speed Frequency Setpoint #1 (Hz)</a> when operating in the <b>Speed</b> control mode and is associated with the <a href="#">RX2 Speed Reference Setpoint #1 (%)</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as -100 to +100% of the -10 to +10 VDC <b>RX2</b> input signal range.</p>	<p><b>Direct Access Number — F222</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — -100.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>RX2 Speed Reference Setpoint #2 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ <b>RX2</b></p> <p>This parameter is used to set the gain, bias, and direction of the <b>RX2</b> input terminal when the <b>RX2</b> terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">RX2 Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">RX2 Torque Reference Setpoint #1 (%)</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>RX2</b> input level that is associated with <a href="#">RX2 Speed Frequency Setpoint #2 (Hz)</a> when operating in the <b>Speed</b> control mode and is associated with the <a href="#">RX2 Torque Reference Setpoint #2 (%)</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as -100 to +100% of the -10 to +10 VDC <b>RX2</b> input signal range.</p>	<p><b>Direct Access Number — F224</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — -100.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>

**RX2 Torque Reference Setpoint #1 (%)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX2**

This parameter is used to set the gain, bias, and direction of the **RX2** input terminal when the **RX2** terminal is used as the control input while operating in the **Torque Control** mode.

**RX2 Input Torque Control Setup**

Perform the following setup to allow the system to receive **Torque** control input at the **RX2** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **RX2.**

**Torque Control**

Perform the following setup to allow the system to perform **Torque** control from the **RX2** input terminal:

- Set the **RX2** input signal level (F222) that will produce the output torque established at the **RX2 Torque Reference Setpoint #1 (%)** parameter.
- Set **RX2 Torque Reference Setpoint #1 (%)**.
- Set the **RX2** input signal level (F224) that will produce the output torque setting established at the **RX2 Torque Reference Setpoint #2 (%)** parameter.
- Set **RX2 Torque Reference Setpoint #2 (%)**.
- Provide a **Run** command (**F** and/or **R**).

This parameter sets **RX2 Torque Reference Setpoint #1 (%)** and is the output torque value that is associated with the setting of **RX2 Speed Reference Setpoint #1 (%)** when operating in the **Torque** control mode.

This value is entered as -250 to +250% of the rated torque.

**RX2 Torque Reference Setpoint #2 (%)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX2**

This parameter is used to set the gain, bias, and direction of the **RX2** input terminal when the **RX2** terminal is used as the control input while operating in the **Torque Control** mode.

See **RX2 Torque Reference Setpoint #1 (%)** for further information on this setting.

This parameter sets **RX2 Torque Reference Setpoint #2 (%)** and is the output torque value that is associated with setting of **RX2 Speed Reference Setpoint #2 (%)** when operating in the **Torque** control mode.

This value is entered as -250 to +250% of the rated torque.

**Direct Access Number — F226**

Parameter Type — **Numerical**

Factory Default — **0.00**


Changeable During Run — **Yes**

Minimum — -250.0

Maximum — +250.0

Units — %

Torque Settings



**Direct Access Number — F227**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — -250.0

Maximum — +250.0

Units — %

---

**RX Bias Adjust**

Program ⇒ Frequency Setting Parameters ⇒ Speed Reference  
Setpoints ⇒ RX ⇒ **Bias**

This parameter is used to fine tune the bias of the **RX** input terminal when this terminal is used as the control input while operating in the **Speed Control** or the **Torque Control** modes.

This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.

This is accomplished by setting the input source to zero and either increasing or decreasing this setting to provide an output of zero from the ASD.

**Direct Access Number — F474**

Parameter Type — **Numerical**

Factory Default — **99**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 255

---

**RX Gain Adjust**

Program ⇒ Frequency Setting Parameters ⇒ Speed Reference  
Setpoints ⇒ RX ⇒ **Gain**

This parameter is used to fine tune the gain of the **RX** input terminal when this terminal is used as the control input while operating in the **Speed Control** or the **Torque Control** modes.

This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.

This is accomplished by setting the input source to 100% and either increasing or decreasing this setting to provide an output of 100% from the ASD.

**Direct Access Number — F475**

Parameter Type — **Numerical**

Factory Default — **141**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 255

**RX Speed Frequency Setpoint #1 (Hz)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX**

This parameter is used to set the gain, bias, and direction of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

**RX Input Speed/Direction Control Setup**

Perform the following setup to allow the system to receive **Speed** control input at the **RX** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **RX.**

**Speed/Direction Control**

Perform the following setup to allow the system to perform **Speed** control from the **RX** input terminal:

- Set the **RX** input signal level (F216) that will produce the output frequency established at the **RX Speed Frequency Setpoint #1 (Hz)** parameter.
- Set **RX Speed Frequency Setpoint #1 (Hz)**.
- Set the **RX** input signal level (F218) that will produce the output frequency setting established at the **RX Speed Frequency Setpoint #2 (Hz)** parameter.
- Set **RX Speed Frequency Setpoint #2 (Hz)**.
- Provide a **Run** command (**F** and/or **R**).

Once set, as the **RX** input voltage changes, the directional information, and the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **RX Speed Frequency Setpoint #1 (Hz)** and is the frequency that is associated with the setting of **RX Speed Reference Setpoint #1 (%)** when operating in the **Speed Control** mode.

**Direct Access Number — F217**

**Parameter Type — Numerical**

**Factory Default — 0.0**


**Changeable During Run — Yes**

**Minimum — -Max. Freq.**

**Maximum — +Max. Freq.**

**Units — Hz**

Frequency Settings



**RX Speed Frequency Setpoint #2 (Hz)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX**

This parameter is used to set the gain, bias, and direction of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

See **RX Speed Frequency Setpoint #1 (Hz)** for further information on this setting.

This parameter sets **RX Speed Frequency Setpoint #2 (Hz)** and is the frequency that is associated with the setting of **RX Speed Reference Setpoint #2 (%)** when operating in the **Speed Control** mode.

**Direct Access Number — F219**

**Parameter Type — Numerical**

**Factory Default — 80.0**

**Changeable During Run — Yes**

**Minimum — -Max. Freq.**

**Maximum — +Max. Freq.**

**Units — Hz**



**RX Speed Reference Setpoint #1 (%)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX**

This parameter is used to set the gain, bias, and direction of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** or the **Torque Control** modes.

See [RX Speed Frequency Setpoint #1 \(Hz\)](#) for further information on this setting when used for **Speed** control.

See [RX Torque Reference Setpoint #1 \(%\)](#) for further information on this setting when used for **Torque** control.

This parameter sets the **RX** input level that is associated with [RX Speed Frequency Setpoint #1 \(Hz\)](#) when operating in the **Speed** control mode or is associated with the [RX Torque Reference Setpoint #1 \(%\)](#) when operating in the **Torque** control mode.

This value is entered as -100 to +100% of the -10 to +10 VDC **RX** input signal range.

**Direct Access Number — F216**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — -100.0

Maximum — 100.0

Units — %

**RX Speed Reference Setpoint #2 (%)**

Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ **RX**

This parameter is used to set the gain, bias, and direction of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** or the **Torque Control** modes.

See [RX Speed Frequency Setpoint #1 \(Hz\)](#) for further information on this setting when used for **Speed** control.

See [RX Torque Reference Setpoint #1 \(%\)](#) for further information on this setting when used for **Torque** control.

This parameter sets the **RX** input level that is associated with [RX Speed Frequency Setpoint #2 \(Hz\)](#) when operating in the **Speed** control mode or is associated with the [RX Torque Reference Setpoint #2 \(%\)](#) when operating in the **Torque** control mode.

This value is entered as -100 to +100% of the -10 to +10 VDC **RX** input signal range.

**Direct Access Number — F218**

Parameter Type — **Numerical**

Factory Default — **100.00**

Changeable During Run — **Yes**

Minimum — -100.0

Maximum — 100.0

Units — %

**RX Torque Reference Setpoint #1 (%)**

Program ⇒ Torque Settings ⇒ **Torque Reference Setpoints**

This parameter is used to set the gain, bias, and direction of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

**RX Input Torque Control Setup**

Perform the following setup to allow the system to receive **Torque** control input at the **RX** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **RX.**

**Torque Control**

Perform the following setup to allow the system to perform **Torque** control from the **RX** input terminal:

- Set the **RX** input signal level (F216) that will produce the output torque established at the **RR Torque Reference Setpoint #1 (%)** parameter.
- Set **RR Torque Reference Setpoint #1 (%)**.
- Set the **RX** input signal level (F218) that will produce the output torque setting established at the **RR Torque Reference Setpoint #2 (%)** parameter.
- Set **RR Torque Reference Setpoint #2 (%)**.
- Provide a **Run** command (**F** and/or **R**).

This parameter sets **RX Torque Reference Setpoint #1 (%)** and is the output torque value that is associated with the setting of **RX Speed Reference Setpoint #1 (%)** when operating in the **Torque** control mode.

This value is entered as -250 to +250% of the rated torque.

**Direct Access Number — F220**

Parameter Type — **Numerical**

Factory Default — **0.00**


Changeable During Run — **Yes**

Minimum — -250.0

Maximum — +250.0

Units — %

**Torque Settings**



**RX Torque Reference Setpoint #2 (%)**

Program ⇒ Torque Settings ⇒ **Torque Reference Setpoints**

This parameter is used to set the gain, bias, and direction of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

See **RX Torque Reference Setpoint #1 (%)** for further information on this setting.

This parameter sets **RX Torque Reference Setpoint #2 (%)** and is the output torque value that is associated with setting of **RX Speed Reference Setpoint #2 (%)** when operating in the **Torque** control mode.

This value is entered as -250 to +250% of the rated torque.

**Direct Access Number — F221**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — -250.0

Maximum — +250.0

Units — %

---

**S10 Terminal Assignment**Program ⇒ Terminal Settings ⇒ **Input Terminals**This parameter selects the functionality of the **S10** discrete input terminal.***Note:** The **S10** input terminal may be used without the **ASD-Multicom** option board.**Without the **ASD-Multicom** option board the **S10** terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.*In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.This parameter sets the programmable **S10** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

---

**S11 Terminal Assignment**Program ⇒ Terminal Settings ⇒ **Input Terminals**This parameter selects the functionality of the **S11** discrete input terminal.***Note:** The **S11** input terminal may be used without the **ASD-Multicom** option board.**Without the **ASD-Multicom** option board the **S11** terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.*In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.This parameter sets the programmable **S11** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

---

**S12 Terminal Assignment**Program ⇒ Terminal Settings ⇒ **Input Terminals**This parameter selects the functionality of the **S12** discrete input terminal.***Note:** The **S12** input terminal may be used without the **ASD-Multicom** option board.**Without the **ASD-Multicom** option board the **S12** terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.*In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.This parameter sets the programmable **S12** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).**Direct Access Number — F124**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F125**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F126**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

<p><b>S1–S4 Terminal Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminal Delays</b></p> <p>This parameter delays the response of the ASD to any change in the <b>S1–S4</b> terminal input by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.</p>	<p><b>Direct Access Number — F144</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>8.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>S1 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>S1</b> discrete input terminal.</p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>S1</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F115</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Preset Speed 1</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>S2 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>S2</b> discrete input terminal.</p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>S2</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F116</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Preset Speed 2</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>S3 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>S3</b> discrete input terminal.</p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>S3</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F117</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Preset Speed 3</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>S4 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>S4</b> discrete input terminal.</p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>S4</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F118</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Emergency Off</b></p> <p>Changeable During Run — <b>No</b></p>

<p><b>S5 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>S5</b> discrete input terminal.</p> <p><i>Note: The S5 input terminal may be used without the ASD-Multicom option board.</i></p> <p><i>Without the ASD-Multicom option board the S5 terminal settings will be stored in volatile memory. The terminal setting information will be lost if the system is powered down or reset.</i></p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>S5</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F119</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Unassigned</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>S5–S16 Terminal Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminal Delays</b></p> <p>This parameter delays the response of the ASD to any change in the <b>S5–S16</b> terminal input by the programmed value (see waveforms at <a href="#">FL Off Delay</a>).</p> <p>The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.</p> <p><i>Note: The S5–S16 input terminals may be used without the ASD-Multicom option board.</i></p> <p><i>Without the ASD-Multicom option board the S5–S16 terminal settings will be stored in volatile memory. The terminal setting information will be lost if the system is powered down or reset.</i></p>	<p><b>Direct Access Number — F145</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>8.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>S6 Terminal Assignment</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminals</b></p> <p>This parameter selects the functionality of the <b>S6</b> discrete input terminal.</p> <p><i>Note: The S6 input terminal may be used without the ASD-Multicom option board.</i></p> <p><i>Without the ASD-Multicom option board the S6 terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.</i></p> <p>In addition, the input terminal must be specified as <b>Normally Open</b> or <b>Normally Closed</b>.</p> <p>This parameter sets the programmable <b>S6</b> terminal to 1 of the 69 possible functions that are listed in <a href="#">Table 6 on pg. 167</a>.</p>	<p><b>Direct Access Number — F120</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Unassigned</b></p> <p>Changeable During Run — <b>No</b></p>

---

**S7 Terminal Assignment**Program ⇒ Terminal Settings ⇒ **Input Terminals**This parameter selects the functionality of the **S7** discrete input terminal.***Note:** The S7 input terminal may be used without the ASD-Multicom option board.**Without the ASD-Multicom option board the S7 terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.*In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.This parameter sets the programmable **S7** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

---

**S8 Terminal Assignment**Program ⇒ Terminal Settings ⇒ **Input Terminals**This parameter selects the functionality of the **S8** discrete input terminal.***Note:** The S8 input terminal may be used without the ASD-Multicom option board.**Without the ASD-Multicom option board the S8 terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.*In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.This parameter sets the programmable **S8** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

---

**S9 Terminal Assignment**Program ⇒ Terminal Settings ⇒ **Input Terminals**This parameter selects the functionality of the **S9** discrete input terminal.***Note:** The S9 input terminal may be used without the ASD-Multicom option board.**Without the ASD-Multicom option board the S9 terminal settings will be stored in volatile memory. The terminal settings will be lost if the system is powered down or reset.*In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.This parameter sets the programmable **S9** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).**Direct Access Number — F121**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F122**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

---

**Direct Access Number — F123**Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

<p><b>S-Pattern Lower Limit Adjustment</b></p> <p>Program ⇒ <b>Fundamentals #1</b></p> <p>Sets the time added to the lower portion of <b>S-pattern 1</b> and <b>S-pattern 2</b> (decreases the accel rate at the ramp start).</p>	<p><b>Direct Access Number — F506</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>25.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 50.00</p> <p>Units — %</p>
<p><b>S-Pattern Upper Limit Adjustment</b></p> <p>Program ⇒ <b>Fundamentals #1</b></p> <p>Sets the time added to the upper portion of <b>S-pattern 1</b> and <b>S-pattern 2</b> (decreases the decel rate at the ramp end).</p>	<p><b>Direct Access Number — F507</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>25.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 50.00</p> <p>Units — %</p>
<p><b>Scan Rate</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Retry/Ridethrough</b></p> <p>In the event of a momentary power outage, the output signal of the ASD will cease. Upon restoration of power, the ASD will output a low-level signal that will be used to determine the rotation speed of the rotor.</p> <p>The low-level signal will start scanning the motor at <b>FH</b> and decrease until it reaches 0.0 Hz or it matches the signal produced by the turning rotor. Once the rate of rotation is determined, the ASD will provide the normal output to engage the motor from its present speed.</p> <p>This parameter determines the rate at which the scanning signal goes from <b>FH</b> to 0.0 Hz.</p>	<p><b>Direct Access Number — F312</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.50</p> <p>Maximum — 2.50</p> <p>Units — Seconds</p>
<p><b>Search (Changed From Default Parameters)</b></p> <p>Program ⇒ <b>Changed from Default</b></p> <p>This function reads all of the parameters and halts at the parameters that have been changed from the factory default setting.</p> <p>See the section titled <a href="#">Default Setting Changes on pg. 33</a> for more information on this parameter.</p>	

**Search Inertia**

Program ⇒ Protection Settings ⇒ **Retry/Ridethrough**

After a momentary power loss or the momentary loss of the **ST-to-CC** connection, this parameter sets the time for the commanded torque to reach its programmed setting during the automatic restart.

The **Speed Search** parameter must be enabled to use this feature.

Settings:

- 0.5 Sec.(fast)
- 1.0 Sec. (standard)
- 1.5 Sec.
- 2.0 Sec.
- 2.5 Sec.
- 3.0 Sec.
- 3.5 Sec.
- 4.0 Sec.
- 4.5 Sec.
- 5.0 Sec. (slow)

**Direct Access Number — F315**

Parameter Type — **Selection List**

Factory Default — **1.0**

Changeable During Run — **No**

Units — Seconds

**Search Method**

Program ⇒ Protection Settings ⇒ **Retry/Ridethrough**

In the event of a momentary power outage, this parameter may be used to set the starting point (frequency) of the scanning signal that is used to determine the rotor speed or, depending on the selection, this parameter may be used to select the method used to search for the speed of the rotor.

See **Scan Rate** for additional information on this parameter.

Settings:

- Normal
- Start from 0.0 Hz
- Start from Running Frequency
- Option Board (ASD-SS)
- PG

**Direct Access Number — F314**

Parameter Type — **Selection List**

Factory Default — **Normal**

Changeable During Run — **No**

**Short Circuit Pulse Duration**

Program ⇒ Protection Settings ⇒ **Short Circuit Test**

This parameter sets the pulse width of the ASD output pulse that is applied to the motor during an **Output Short Circuit** test.

**Direct Access Number — F614**

Parameter Type — **Numerical**

Factory Default — **(ASD-dependent)**

Changeable During Run — **No**

Minimum — 1

Maximum — 100

Units —  $\mu$ S



<p><b>Soft Stall Enable</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Overload</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Soft Stall, Motor Overload Trip</b>, and use of a <b>V/f Motor</b>. The <b>Soft Stall</b> function reduces the output frequency of the ASD when the current requirements of the motor exceed the <b>Thermal Protection #1</b> setting; thus, reducing the output current.</p> <p>If the current drops below the <b>Thermal Protection #1</b> level setting within a specified time, the output of the ASD will accelerate to the programmed frequency setpoint.</p> <p>If the current does not drop below the <b>Thermal Protection #1</b> level setting within the specified time, a trip will be incurred if the <b>Trip</b> function is enabled at this parameter.</p> <p><b>Soft Stall</b> is highly effective in preventing motor overload trips when used on fans, blowers, pumps, and other centrifugal loads which require less torque at lower frequencies.</p> <p><i>Note: The <b>Soft Stall</b> setting may affect acceleration times and patterns.</i></p>	<p><b>Direct Access Number — F017</b></p> <p>Parameter Type — <b>Check Box</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Speed at 0% Drooping Gain</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the motor speed when at the 0% output torque gain while operating in the <b>Drooping Control</b> mode. This function determines the lowest speed that <b>Drooping</b> will be in effect for motors that share the same load.</p>	<p><b>Direct Access Number — F321</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 320.0</p> <p>Units — Hz</p>
<p><b>Speed at 100% Drooping Gain</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the motor speed when at the 100% output torque gain while operating in the <b>Drooping Control</b> mode. This function determines the speed of the individual motors at the 100% <b>Drooping Gain</b> setting for motors that share the same load.</p>	<p><b>Direct Access Number — F322</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 320.0</p> <p>Units — Hz</p>
<p><b>Speed Drop Detection Frequency Range</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Abnormal Speed</b></p> <p>While operating using <b>PG</b> feedback, this parameter sets the lower level of the deviation limit that, once the output frequency falls below this setting, causes a <b>Speed Drop Detected</b> alert.</p>	<p><b>Direct Access Number — F624</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 30.00</p> <p>Units — Hz</p>

<p><b>Speed Limit Torque Band</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the <b>Torque Control</b> mode. This parameter sets a plus-or-minus value (range) for the <b>Speed Limit Torque Level (F431)</b>.</p>	<p><b>Direct Access Number — F432</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Max. Freq. (F011)</b></p> <p>Units — Hz</p>
<p><b>Speed Limit Torque Level</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the <b>Torque Control</b> mode. This parameter sets the targeted speed. The plus-or-minus value (range) for this setting may be set at <b>F432</b>.</p>	<p><b>Direct Access Number — F431</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — <b>Max. Freq. (F011)</b></p> <p>Units — Hz</p>
<p><b>Speed Limit Torque Recovery Time</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the <b>Torque Control</b> mode. This parameter sets the response time of the system to torque change requirements.</p>	<p><b>Direct Access Number — F433</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.20</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.00</p> <p>Maximum — 2.50</p> <p>Units — Seconds</p>
<p><b>Speed Limit Torque Reference</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the <b>Torque Control</b> mode. This parameter sets the input terminal that will be used to control the allowable speed variance.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>None</li> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>RX2 (option)</li> <li>Fixed</li> </ul>	<p><b>Direct Access Number — F430</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>None</b></p> <p>Changeable During Run — <b>Yes</b></p>

<p><b>Speed Loop Integral Gain</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the response time of the <b>Speed Loop Integral Gain</b>. The smaller the value here, the more pronounced (quicker) the effect of the integral function.</p>	<p><b>Direct Access Number</b> — F377</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 10.0</p> <p>Maximum — 200.0</p>
<p><b>Speed Loop Parameter Ratio</b></p> <p>No Path — Direct Access Only</p> <p>Contact Toshiba's Marketing Department for information on this parameter.</p>	<p><b>Direct Access Number</b> — F379</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>1.00</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.01</p> <p>Maximum — 10.00</p>
<p><b>Speed Loop Proportional Gain</b></p> <p>No Path — Direct Access Only</p> <p>This parameter sets the <b>Proportional Gain</b> (sensitivity) of the drive when monitoring the <b>PG</b> signal to control speed. The larger the value entered here, the more sensitive the drive is to changes in the received feedback and the quicker it responds.</p>	<p><b>Direct Access Number</b> — F376</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>(ASD-dependent)</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 3.2</p> <p>Maximum — 1000</p>
<p><b>Speed Reach Bandwidth</b></p> <p>Program ⇒ Terminal Settings ⇒ Output Terminals ⇒ <b>Reach</b></p> <p>This parameter sets the bandwidth of the <b>Speed Reach Frequency</b> setting.</p>	<p><b>Direct Access Number</b> — F102</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.5</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Speed Reach Frequency</b></p> <p>Program ⇒ <b>Output Terminals</b></p> <p>This setting establishes a frequency threshold that, when reached or is within the <b>Reach Detection</b> bandwidth, will provide a signal at an output terminal that can close an appropriately configured output contact.</p>	<p><b>Direct Access Number</b> — F101</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>2.5</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>

<p><b>Stall Cooperation Gain at Field Weakening Zone</b></p> <p>No Path — Direct Access Only</p> <p>This parameter determines the degree that the <b>Stall</b> function is effective while operating the motor in the field weakening zone.</p>	<p><b>Direct Access Number — F485</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>128</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p><b>Stall Prevention During Regeneration</b></p> <p>Program ⇒ <b>Protection Settings</b></p> <p><b>Enables/Disables</b> the <b>Overvoltage Stall</b> and the <b>Overcurrent Stall</b> function during regeneration <u>only</u>.</p>	<p><b>Direct Access Number — F453</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Startup Frequency</b></p> <p>Program ⇒ Special Control ⇒ <b>Frequency Control</b></p> <p>The output of the ASD will remain at 0.0 Hz until the programmed speed value exceeds this setting during startup. Once exceeded during startup, the output frequency of the ASD will accelerate to the programmed setting.</p> <p>Output frequencies below the <b>Startup Frequency</b> will not be output from the ASD during startup. However, once reaching the <b>Startup Frequency</b>, speed values below the <b>Startup Frequency</b> may be output from the ASD.</p>	<p><b>Direct Access Number — F240</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.10</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Hz</p>

**ST Signal Selection**


Program ⇒ Terminal Settings ⇒ **Input Other**

This parameter is used to set the operation of the **Standby (ST)** control terminal or any terminal configured as the **ST** terminal.

Settings:


- ST-to-CC Required
- ST-to-CC Not Required
- Interlock with F/R Terminal

The setting **ST-to-CC Required** enables the ASD for operation so long as the control terminal **ST** is connected to **CC** via a jumper, contact, or other means.



The **ST-to-CC Not Required** setting allows the ASD to operate without the **ST-to-CC** connection. The control terminal **ST** may be configured for other functions.

The **Interlock with F/R Terminal** setting configures the **F (Forward)** and **R (Reverse)** control terminals for the secondary function of **Standby**. Closing a set of contacts to either **F** or **R** will cause the ASD to accelerate the motor to the programmed setpoint of **F** or **R**. Opening the **F** and **R** contact will disable the ASD and the motor will coast to a stop. The control terminal **ST** may be configured for other functions.



**ST Terminal Assignment**

Program ⇒ Terminal Settings ⇒ **Input Terminals**

This parameter selects the functionality of the **ST** discrete input terminal.

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

This parameter sets the programmable **ST** terminal to 1 of the 69 possible functions that are listed in [Table 6 on pg. 167](#).

**Direct Access Number — F103**

Parameter Type — **Selection List**

Factory Default — **ST – CC Required**

Changeable During Run — **No**

**Direct Access Number — F113**

Parameter Type — **Selection List**

Factory Default — **Standby**

Changeable During Run — **No**

<p><b>ST Terminal Delay</b></p> <p>Program ⇒ Terminal Settings ⇒ <b>Input Terminal Delays</b></p> <p>This parameter delays the response of the ASD to any change in the <b>ST</b> terminal input by the programmed value (see waveforms at <b>FL Off Delay</b>).</p> <p>The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.</p>	<p><b>Direct Access Number</b> — F142</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>8.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p><b>Supply Voltage Compensation</b></p> <p>Program ⇒ <b>Fundamentals</b> ⇒ <b>Fundamentals #1</b> ⇒</p> <p>This parameter adjusts the degree of voltage compensation during dead time by increasing or decreasing the on-time of the programmed PWM just prior to the start of the dead time.</p>	<p><b>Direct Access Number</b> — F307</p> <p>Parameter Type — <b>Check Box</b></p> <p>Factory Default — <b>On</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Switching Load Torque During Forward-Run</b></p> <p>No Path — Direct Access Only</p> <p>While running forward, this parameter establishes the threshold torque level that is used to determine if the <b>Light-Load High-Speed (F331)</b> operation may engage or remain engaged if active.</p> <p>If the <b>Light-Load High-Speed</b> operation is terminated normal operation resumes.</p>	<p><b>Direct Access Number</b> — F335</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>50</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0</p> <p>Maximum — 250</p> <p>Units — %</p>
<p><b>Switching Load Torque During Reverse-Run</b></p> <p>No Path — Direct Access Only</p> <p>While running in reverse, this parameter establishes the threshold torque level that is used to determine if the <b>Light-Load High-Speed (F331)</b> operation may engage or remain engaged if active.</p> <p>If the <b>Light-Load High-Speed</b> operation is terminated normal operation resumes.</p>	<p><b>Direct Access Number</b> — F338</p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>50</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 250</p> <p>Units — %</p>
<p><b>Switch-on-the-Fly</b></p> <p>No Path — Direct Access Only</p> <p>The ability to switch between the <b>Manual</b> and <b>Auto</b> modes while running.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled</li> </ul>	<p><b>Direct Access Number</b> — F961</p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Enabled</b></p> <p>Changeable During Run — <b>No</b></p>

---

**Synchronized Torque Bias Input**Program ⇒ Torque Settings ⇒ **Torque Control**

This parameter **Enables/Disables** the **Synchronized Torque Bias** input function. When enabled, this parameter identifies the source of the **Synchronized Torque Bias** input signal.

Settings:

- Disabled
- VI/II
- RR
- RX
- RX2 (option)
- LED Keypad Option
- Binary/BCD Input
- Common Serial (TTL)
- RS232/RS485
- Communication Card

**Direct Access Number — F422**Parameter Type — **Selection list**Factory Default — **Disabled**Changeable During Run — **Yes**

---

**Tension Torque Bias Input**Program ⇒ Torque Settings ⇒ **Torque Control**

This parameter **Enables/Disables** the **Tension Torque Bias** input function and identifies the source of the **Tension Torque Bias** input signal when enabled.

Settings:

- Disabled
- VI/II
- RR
- RX
- RX2 (option)
- LED Keypad Option
- Binary/BCD Input
- Common Serial (TTL)
- RS232/RS485
- Communication Card


**Direct Access Number — F423**Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

**Torque Boost #1**

Program ⇒ Fundamentals ⇒ **Fundamentals #1**

The **Motor #1 Torque Boost** function is used to increase the low frequency torque for high-inertia loads by increasing the output voltage at frequencies below ½ of the **#1 Base Frequency** setting.

The value programmed as a boost percentage establishes an output voltage vs. output frequency relationship to be used to start the motor or to provide smoother operation.



*Note: Setting an excessive **Torque Boost** level may cause nuisance tripping and mechanical stress to loads.*

**Direct Access Number — F016**

Parameter Type — **Numerical**

Factory Default — **(ASD-dependent)**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 30.0

Units — %

**Torque Boost #2**

Program ⇒ Fundamentals ⇒ **Fundamentals #2**

The **Motor #2 Torque Boost** function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the **#2 Base Frequency** setting).

This parameter is used only when the parameters for motor set **#2** are configured and selected. Motor set **#2** may be selected by a properly configured input terminal.

See parameter **Motor #1 Torque Boost** for more information on this setting.

**Direct Access Number — F172**

Parameter Type — **Numerical**

Factory Default — **(ASD-dependent)**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %

**Torque Boost #3**

Program ⇒ Motor Settings ⇒ **Motor Set #3**

The **Motor #3 Torque Boost** function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the **#3 Base Frequency** setting.

This parameter is used only when the parameters for motor set **#3** are configured and selected. Motor set **#3** may be selected by a properly configured input terminal.

See parameter **Motor #1 Torque Boost** for more information on this setting.

**Direct Access Number — F176**

Parameter Type — **Numerical**

Factory Default — **(ASD-dependent)**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %

**Torque Boost #4**

Program ⇒ Motor Settings ⇒ **Motor Set #4**

The **Motor #4 Torque Boost** function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the **#4 Base Frequency** setting.

This parameter is used only when the parameters for motor set **#4** are configured and selected. Motor set **#4** may be selected by a properly configured input terminal.

See parameter **Motor #1 Torque Boost** for more information on this setting.

**Direct Access Number — F180**

Parameter Type — **Numerical**

Factory Default — **(ASD-dependent)**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %



<p><b>Torque Boost Adjustment</b></p> <p>No Path — Direct Access Only</p> <p>This parameter <b>Enables/Disables</b> the feature that allows for the external adjustment of the <b>Torque Boost</b> setting. Selecting either <b>VI/II</b> or <b>RR</b> enables this feature. The selected input is used as a modifier of the programmed <b>Torque Boost</b> setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> </ul>	<p><b>Direct Access Number</b> — F654</p> <p><b>Parameter Type</b> — Selection List</p> <p><b>Factory Default</b> — Disabled</p> <p><b>Changeable During Run</b> — Yes</p>
<p><b>Torque Command</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Control</b></p> <p>When operating in the <b>Torque Control</b> mode, this parameter allows the user to select the source of the torque command signal.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>VI/II</li> <li>RR</li> <li>RX</li> <li>RX2 (option)</li> <li>LED Keypad Option</li> <li>Binary/BCD Input</li> <li>Common Serial (TTL)</li> <li>RS232/RS485</li> <li>Communication Card</li> </ul>	<p><b>Direct Access Number</b> — F420</p> <p><b>Parameter Type</b> — Selection List</p> <p><b>Factory Default</b> — RX</p> <p><b>Changeable During Run</b> — Yes</p>
<p><b>Torque Command Filter</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Control</b></p> <p>This parameter reduces the motor vibration caused by large-inertia loads. A small value will have a great effect while an increased value will have a lesser effect.</p>	<p><b>Direct Access Number</b> — F421</p> <p><b>Parameter Type</b> — Numerical</p> <p><b>Factory Default</b> — 200.0</p> <p><b>Changeable During Run</b> — Yes</p> <p><b>Minimum</b> — 10.0</p> <p><b>Maximum</b> — 200.0</p>
<p><b>Torque Command Mode</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Speed Limit</b></p> <p>This parameter specifies whether the torque command function is to be used in one direction or both (F/R).</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Fixed Direction</li> <li>F/R Permitted</li> </ul>	<p><b>Direct Access Number</b> — F429</p> <p><b>Parameter Type</b> — Selection List</p> <p><b>Factory Default</b> — Fixed Direction</p> <p><b>Changeable During Run</b> — No</p>

<p><b>Torque Limit Mode</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Limit</b></p> <p>This parameter sets the operating condition in which the torque limit settings of <a href="#">F440</a> and <a href="#">F442</a> are applied to the motor.</p> <p>If <b>Driving/Regen</b> is selected here the torque limit set at <a href="#">F440</a> applies when driving the motor (F or R) and the setting of <a href="#">F442</a> applies during regenerative operation.</p> <p>If <b>Positive/Negative</b> is selected here the torque limit set at <a href="#">F440</a> applies when driving the motor forward only and the setting of <a href="#">F442</a> applies when driving the motor in reverse only.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Driving/Regen</li> <li>Positive/Negative</li> </ul>	<p><b>Direct Access Number — F450</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Driving/Regen</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Torque Limit Mode (Speed Dependent)</b></p> <p>Program ⇒ Torque Settings ⇒ <b>Torque Limit</b></p> <p>This parameter allows for either wide or very limited speed fluctuations while operating in the <b>Torque Control</b> mode.</p> <p>The ASD output follows the commanded speed when <b>No Speed Cooperation</b> is selected and has a very limited speed fluctuation range when <b>Standard</b> is selected.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Standard</li> <li>No Speed Cooperation</li> </ul>	<p><b>Direct Access Number — F451</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Standard</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Trip Save at Power Down Enable</b></p> <p>Program ⇒ Protection Settings ⇒ <b>Trip/Fan/Timer</b></p> <p>This parameter <b>Enables/Disables</b> the <b>Trip Save at Power Down</b> setting. When enabled, this feature logs the trip event and retains the trip information when the system powers down. The trip information may be viewed from the <b>Monitor</b> screen.</p> <p>When disabled, the trip information will be cleared when the system powers down.</p>	<p><b>Direct Access Number — F602</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>No</b></p>

**TTL Baud Rate**Program ⇒ Communication ⇒ **Comm. Baud Rate (TTL)**

This parameter plays a role in the setup of the communications network by establishing the **Baud Rate** of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.

Settings:

1200  
2400  
4800  
9600  
19200  
38400

**Direct Access Number — F800**Parameter Type — **Selection List**Factory Default — **9600**Changeable During Run — **Yes****TTL Master Output**Program ⇒ **Communication**

In a master/follower configuration, this setting determines the output parameter of the master ASD that will be used to control the applicable follower ASDs.

***Note:** Select **Normal** if **RS485 Master Output** is configured as a **Master Output** controller. Otherwise, a keypad failure will result.*

Changes made to this parameter require that the power be cycled (Off then On) for the changes to take effect.

Settings:

Normal  
Frequency Reference  
Output (Commanded) Frequency  
Torque Command  
Output Torque (Command)

**Direct Access Number — F806**Parameter Type — **Selection List**Factory Default — **Normal**Changeable During Run — **Yes**

---

**Type Reset**Program ⇒ **Utilities**

This feature assists the user when performing fault analysis or by allowing a quick system setup change when required. Performing a **Type Reset** results in one of the following user-selected post-reset configurations.

Settings:

- Auto Setup for 50 Hz
- Auto Setup for 60 Hz
- Restore Factory Defaults
- Clear Past Trips
- Clear Run Timer
- New Base Drive Board
- Save User Parameters
- Restore User Settings
- Upgrade Firmware
- Set EOI Memory to Default

To perform a **Reset** select one of the above-listed functions. Arrow down the **Reset** field and press **Enter**. From the **Confirm Reset** screen, press the **Enter** key.

The MS1 relay will cycle (hear click) and wait 30 seconds for the EOI screen to reset.

**Direct Access Number** — F007Parameter Type — **Selection List**Factory Default — **No Reset**Changeable During Run — **No**

---

**Undervoltage Detection Time**Program ⇒ Protection Settings ⇒ **Undervoltage**

This parameter sets the time that the undervoltage condition must exist to cause an **Undervoltage Trip** when this function is enabled at the **Undervoltage Trip** parameter.

**Direct Access Number** — F628Parameter Type — **Numerical**Factory Default — **0.03**Changeable During Run — **No**

Minimum — 0.00

Maximum — 10.00

Units — Seconds

---

**Undervoltage Stall Level**Program ⇒ Protection Settings ⇒ **Undervoltage**

This parameter sets the low end of the DC bus voltage threshold that, once it drops below this setting, will activate the **Ridethrough** feature. Activation may be the result of a momentary power loss or an excessive load on the bus voltage. Once activated, the system will attempt to maintain the bus voltage level set here until the motor stops.

*Note: This feature may decrease deceleration times.*

**Direct Access Number** — F629Parameter Type — **Numerical**Factory Default — **(ASD-dependent)**Changeable During Run — **Yes**

Minimum — 50.00

Maximum — 100.0

Units — %

---

**Undervoltage Trip**Program ⇒ Protection Settings ⇒ **Undervoltage**

This parameter **Enables/Disables** the **Undervoltage Trip** function.

When enabled, if the DC bus voltage should exceed the setting of the **Undervoltage Stall level** in excess of the duration set at the **Undervoltage Detection Time**, an **Undervoltage Trip** is incurred.

A user-selected contact may also be actuated if so configured.

**Direct Access Number** — F627Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No**

<p><b>Units for Voltage and Current</b></p> <p>Program ⇒ Utilities ⇒ <b>Display Attributes</b></p> <p>This parameter sets the unit of measurement for current and voltage values displayed on the keypad.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>%</li> <li>V/A</li> </ul>	<p><b>Direct Access Number — F701</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — %</p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>Upper Deviation Limit</b></p> <p>Program ⇒ <b>Feedback Settings</b></p> <p>This parameter determines the maximum amount that the feedback may increase the output signal.</p>	<p><b>Direct Access Number — F364</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>50.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 50.00</p> <p>Units — %</p>
<p><b>Upper Limit Frequency</b></p> <p>Program ⇒ Fundamentals ⇒ <b>Fundamental #1</b></p> <p>This parameter sets the highest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD may output frequencies higher than the <b>Upper Limit Frequency</b> (but, lower than the <b>Maximum Frequency</b>) when operating in the <b>PID Control</b> mode, <b>Torque Control</b> mode, or the <b>Vector Control</b> modes (sensorless or feedback).</p> <p><i>Note: This setting may not be higher than the <b>Maximum Frequency</b> setting.</i></p>	<p><b>Direct Access Number — F012</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>60.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — <b>Max. Freq.</b></p> <p>Units — Hz</p>
<p><b>Upper Limit Frequency Adjustment</b></p> <p>No Path — Direct Access Only</p> <p>This parameter <b>Enables/Disables</b> the feature that allows for the external adjustment of the <b>Upper Limit</b>. When enabled, either <b>VI/II</b> or <b>RR</b> may be used as an input source for the modification of the <b>Upper Limit</b> setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Disabled</li> <li>VI/II</li> <li>RR</li> </ul>	<p><b>Direct Access Number — F651</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Disabled</b></p> <p>Changeable During Run — <b>Yes</b></p>
<p><b>V/f Adjustment Coefficient</b></p> <p>No Path — Direct Access Only</p> <p>This parameter may be used in the <b>Constant Torque</b> or the <b>Variable Torque</b> modes only and should be adjusted gradually to improve the application-specific torque requirements. The <b>Torque Boost #1</b> setting may be adjusted to improve the low-frequency torque performance.</p> <p><i>Note: The <b>Torque Boost</b> setting should be adjusted gradually before attempting performance corrections using this parameter.</i></p>	<p><b>Direct Access Number — F183</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>32</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0</p> <p>Maximum — 255</p>

**V/f Five-Point Setting #1 Frequency**


No Path — Direct Access Only

The [V/f Five-Point Setting #1 Frequency](#) setting establishes the frequency that is to be associated with the voltage setting of parameter [V/f Five-Point Setting #1 Voltage](#).

The V/f five-point settings define a custom volts per hertz relationship for the startup output of the ASD.

To enable this function, set the [V/f Pattern](#) selection to **Custom V/f Curve**.

**Custom V/f Curves** may be useful in starting high inertia loads such as rotary drum vacuum filters.

**V/f Five-Point Setting #1 Voltage**

No Path — Direct Access Only

The [V/f Five-Point Setting #1 Voltage](#) establishes the percentage of the output voltage that is to be associated with the [V/f Five-Point Setting #1 Frequency](#) frequency setting.

See [V/f Five-Point Setting #1 Frequency](#) for additional information on custom V/f curves.

**V/f Five-Point Setting #2 Frequency**

No Path — Direct Access Only

The [V/f Five-Point Setting #2 Frequency](#) setting establishes the frequency that is to be associated with the voltage setting of parameter [V/f Five-Point Setting #2 Voltage](#).

See [V/f Five-Point Setting #1 Frequency](#) for additional information on custom V/f curves.

**Direct Access Number — F190**Parameter Type — **Numerical**Factory Default — **0.0**Changeable During Run — **No**

Minimum — 0.0

Maximum — 299

Units — Hz

**Direct Access Number — F191**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **No**

Minimum — 0.0

Maximum — 100.0

Units — %

**Direct Access Number — F192**Parameter Type — **Numerical**Factory Default — **0.0**Changeable During Run — **No**

Minimum — 0.0

Maximum — 299

Units — Hz

<p><b>V/f Five-Point Setting #2 Voltage</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #2 Voltage</a> establishes the percentage of the output voltage that is to be associated with the <a href="#">V/f Five-Point Setting #2 Frequency</a> frequency setting.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F193</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>V/f Five-Point Setting #3 Frequency</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #3 Frequency</a> setting establishes the frequency that is to be associated with the voltage setting of parameter <a href="#">V/f Five-Point Setting #3 Voltage</a>.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F194</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 299</p> <p>Units — Hz</p>
<p><b>V/f Five-Point Setting #3 Voltage</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #3 Voltage</a> establishes the percentage of the output voltage that is to be associated with the <a href="#">V/f Five-Point Setting #3 Frequency</a> frequency setting.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F195</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>V/f Five-Point Setting #4 Frequency</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #4 Frequency</a> setting establishes the frequency that is to be associated with the voltage setting of parameter <a href="#">V/f Five-Point Setting #4 Voltage</a>.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F196</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 299</p> <p>Units — Hz</p>
<p><b>V/f Five-Point Setting #4 Voltage</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #4 Voltage</a> establishes the percentage of the output voltage that is to be associated with the <a href="#">V/f Five-Point Setting #4 Frequency</a> frequency setting.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F197</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>

<p><b>V/f Five-Point Setting #5 Frequency</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #5 Frequency</a> setting establishes the frequency that is to be associated with the voltage setting of parameter <a href="#">V/f Five-Point Setting #5 Voltage</a>.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F198</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 299</p> <p>Units — Hz</p>
<p><b>V/f Five-Point Setting #5 Voltage</b></p> <p>No Path — Direct Access Only</p> <p>The <a href="#">V/f Five-Point Setting #5 Voltage</a> establishes the percentage of the output voltage that is to be associated with the <a href="#">V/f Five-Point Setting #5 Frequency</a> frequency setting.</p> <p>See <a href="#">V/f Five-Point Setting #1 Frequency</a> for additional information on custom V/f curves.</p>	<p><b>Direct Access Number — F199</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.0</b></p> <p>Changeable During Run — <b>No</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>V/f Pattern</b></p> <p>Program ⇒ Fundamentals ⇒ <b>Fundamental #1</b></p> <p>This function establishes the relationship between the output frequency and the output voltage.</p> <p>Settings:</p> <ul style="list-style-type: none"> <li>Constant Torque</li> <li>Variable Torque</li> </ul>	<p><b>Direct Access Number — F015</b></p> <p>Parameter Type — <b>Selection List</b></p> <p>Factory Default — <b>Variable Torque</b></p> <p>Changeable During Run — <b>No</b></p>
<p><b>Vector Motor Model Slip Frequency Gain</b></p> <p>Program ⇒ Motor Settings ⇒ <b>Vector Motor Model</b></p> <p>This parameter provides a degree of slip compensation for a given load. A higher setting here decreases the slip allowed for a given load/ASD output ratio.</p>	<p><b>Direct Access Number — F401</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.60</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.00</p> <p>Maximum — 2.55</p>
<p><b>VI/II Bias Adjust</b></p> <p>Program ⇒ Frequency Settings ⇒ Speed Reference Setpoints ⇒ VI/II ⇒ <b>Bias</b></p> <p>This parameter is used to fine-tune the bias of the <b>VI/II</b> input terminals.</p> <p><b>Note:</b> See note on <a href="#">pg. 37</a> for further information on the <b>VI/II</b> terminal.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and either increasing or decreasing this setting to provide an output of zero from the ASD.</p>	<p><b>Direct Access Number — F470</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>100</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 255</p>



**VI/II Gain Adjust**

Program ⇒ Frequency Setting Parameters ⇒ Speed Reference Setpoints ⇒ VI/II ⇒ **Gain**

This parameter is used to fine tune the gain of the **VI/II** input terminals.

**Note:** See note on pg. 37 for further information on the VI/II terminal.

This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.

This is accomplished by setting the input source to 100% and either increasing or decreasing this setting to provide an output of 100% from the ASD.

**Direct Access Number — F471**

Parameter Type — **Numerical**

Factory Default — **50**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 255

**VI/II Speed Frequency Setpoint #1 (Hz)**

Program ⇒ Frequency Settings ⇒ **Speed Reference Setpoints**

This parameter is used to set the gain and bias of the **VI/II** input terminal when the **VI/II** terminal is used as the control input while operating in the **Speed Control** mode. Once setup, the gain and bias may be fine-tuned for application-specific requirements via parameters **F470** and **F471**.

**Note:** See note on pg. 37 for further information on the **VI/II** terminal.

**Direct Access Number — F202**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — Max. Freq.

Units — Hz

**VI/II Input Speed Control Setup**

Perform the following setup to allow the system to receive **Speed** control input at the **VI/II** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip.**
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **VI/II.**


**Speed Control**

Perform the following setup to allow the system to perform **Speed** control from the **VI/II** input terminal:

- Set the **VI/II** input signal level (**F201**) that will produce the output frequency established at the **VI/II Speed Frequency Setpoint #1 (Hz)** parameter.
- Set **VI/II Speed Frequency Setpoint #1 (Hz)**.
- Set the **VI/II** input signal level (**F203**) that will produce the output frequency setting established at the **VI/II Speed Frequency Setpoint #2 (Hz)** parameter.
- Set **VI/II Speed Frequency Setpoint #2 (Hz)**.
- Provide a **Run** command (**F** and/or **R**).

Once set, as the **VI** input voltage or the **II** input current changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **VI/II Speed Frequency Setpoint #1 (Hz)** and is the frequency that is associated with the setting of **VI/II Speed Reference Setpoint #1 (%)** when operating in the **Speed Control** mode.

**Frequency Settings**

<p><b>VI/II Speed Frequency Setpoint #2 (Hz)</b></p> <p>Program ⇒ Frequency Settings ⇒ <b>Speed Reference Setpoints</b></p> <p>This parameter is used to set the gain and bias of the <b>VI/II</b> input terminal when the <b>VI/II</b> terminal is used as the control input while operating in the <b>Speed Control</b> mode.</p> <p>See <a href="#">VI/II Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting.</p> <p>This parameter sets <a href="#">VI/II Speed Frequency Setpoint #2 (Hz)</a> and is the frequency that is associated with the setting of <a href="#">VI/II Speed Reference Setpoint #2 (%)</a> when operating in the <b>Speed Control</b> mode.</p>	<p><b>Direct Access Number — F204</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>80.0</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — Max. Freq.</p> <p>Units — Hz</p>
<p><b>VI/II Speed Reference Setpoint #1 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ <b>Speed Reference Setpoints</b></p> <p>This parameter is used to set the gain and bias of the <b>VI/II</b> input terminal when the <b>VI/II</b> terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">VI/II Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">VI/II Torque Reference Setpoint #1 (%)</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>VI/II</b> input level that is associated with <a href="#">VI/II Speed Frequency Setpoint #1 (Hz)</a> when operating in the <b>Speed</b> control mode or is associated with the <a href="#">VI/II Torque Reference Setpoint #1 (%)</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as 0.0% to 100% of the 0.0 to +10 VDC or of the 0 – 20 mA <b>VI/II</b> input signal range.</p> <p>The default value for this parameter is 20%. The <b>II</b> input is commonly used for the 4 – 20 mA current loop signal where 4 mA equals 20% of a 20 mA signal. If the <b>VI</b> input is used (0 – 10 VDC input), this parameter may be changed to 0.0% (of the input signal).</p>	<p><b>Direct Access Number — F201</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>20.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p><b>VI/II Speed Reference Setpoint #2 (%)</b></p> <p>Program ⇒ Frequency Settings ⇒ <b>Speed Reference Setpoints</b></p> <p>This parameter is used to set the gain and bias of the <b>VI/II</b> input terminal when the <b>VI/II</b> terminal is used as the control input while operating in the <b>Speed Control</b> or the <b>Torque Control</b> modes.</p> <p>See <a href="#">VI/II Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting when used for <b>Speed</b> control.</p> <p>See <a href="#">VI/II Torque Reference Setpoint #1 (%)</a> for further information on this setting when used for <b>Torque</b> control.</p> <p>This parameter sets the <b>VI/II</b> input level that is associated with <a href="#">VI/II Speed Frequency Setpoint #2 (Hz)</a> when operating in the <b>Speed</b> control mode or is associated with the <a href="#">VI/II Torque Reference Setpoint #2 (%)</a> when operating in the <b>Torque</b> control mode.</p> <p>This value is entered as 0.0% to 100% of the 0.0 to +10 VDC or of the 0 – 20 mA <b>VI/II</b> input signal range.</p>	<p><b>Direct Access Number — F203</b></p> <p>Parameter Type — <b>Numerical</b></p> <p>Factory Default — <b>0.00</b></p> <p>Changeable During Run — <b>Yes</b></p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>

**VI/II Torque Reference Setpoint #1 (%)**Program ⇒ Torque Settings ⇒ **Torque Reference Setpoints**

This parameter is used to set the gain and bias of the **VI/II** input terminal when the **VI/II** terminal is used as the control input while operating in the **Torque Control** mode.

**VI/II Input Torque Control Setup**

Perform the following setup to allow the system to receive **Torque** control input at the **VI/II** input terminal:

- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Command Mode ⇒ **Control Terminal Strip**.
- Program ⇒ Utilities ⇒ Cmd. Frq. and Carrier ⇒ Frq. Mode #1 ⇒ **VI/II**.

**Torque Control**

Perform the following setup to allow the system to perform **Torque** control from the **VI/II** input terminal:

- Set the **VI/II** input signal level (F201) that will produce the output torque established at the **VI/II Torque Reference Setpoint #1 (%)** parameter.
- Set **VI/II Torque Reference Setpoint #1 (%)**.
- Set the **VI/II** input signal level (F203) that will produce the output torque setting established at the **VI/II Torque Reference Setpoint #2 (%)** parameter.
- Set **VI/II Torque Reference Setpoint #2 (%)**.
- Provide a **Run** command (**F** and/or **R**).

This parameter sets **VI/II Torque Reference Setpoint #1 (%)** and is the output torque value that is associated with the setting of **VI/II Speed Reference Setpoint #1 (%)** when operating in the **Torque** control mode.


This value is entered as 0% to 250% of the rated torque.

**Direct Access Number — F205**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 250.0

Units — %

**Torque Settings****VI/II Torque Reference Setpoint #2 (%)**Program ⇒ Torque Settings ⇒ **Torque Reference Setpoints**

This parameter is used to set the gain and bias of the **VI/II** input terminal when the **VI/II** terminal is used as the control input while operating in the **Torque Control** mode.

See **VI/II Torque Reference Setpoint #1 (%)** for further information on this setting.

This parameter sets **VI/II Torque Reference Setpoint #2 (%)** and is the output torque value that is associated with setting of **VI/II Speed Reference Setpoint #2 (%)** when operating in the **Torque** control mode.

This value is entered as 0% to 250% of the rated torque.

**Direct Access Number — F206**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 250.0

Units — %

**Voltage Compensation Coefficient for Dead Time**

No Path — Direct Access Only

This parameter adjusts the degree of voltage compensation during dead time by increasing or decreasing the on-time of the programmed PWM just prior to the start of the dead time.

**Direct Access Number — F488**Parameter Type — **Numerical**Factory Default — **163.8**Changeable During Run — **Yes**

Minimum — 1.64

Maximum — 327.6

---

**Voltage Vector Control**

No Path — Direct Access Only

This parameter establishes the control margin of modulation when operating in the **Voltage Vector Control** mode.

**Direct Access Number — F483**Parameter Type — **Numerical**Factory Default — **105.0**Changeable During Run — **Yes**

Minimum — 80.0

Maximum — 300.0

Units — %

**Table 6.** Discrete Input Terminal Assignment Selections and Descriptions.

<b>Unassigned</b> — No operation.																				
<b>Forward</b> — Enables <b>Forward</b> operation commands.																				
<b>Reverse</b> — Enables <b>Reverse</b> operation commands.																				
<b>Standby</b> — Enables the <b>Forward</b> and <b>Reverse</b> operation commands (maybe disabled at <b>ST Selection</b> ).																				
<b>Reset</b> — Resets the device and any incurred faults.																				
<b>Set Speed 1</b> — The <b>LSB</b> of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																				
<b>Set Speed 2</b> — The second bit of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																				
<b>Set Speed 3</b> — The third bit of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																				
<b>Set Speed 4</b> — The <b>MSB</b> of the 4-bit nibble that is used to select a <b>Preset Speed</b> .																				
<b>Jog</b> — <b>Jog</b> is the term used to describe turning on the motor for small increments of time and is used when precise positioning of motor-driven equipment is required. This terminal activates a <b>Jog</b> for the duration of activation. The <b>Jog Run Frequency</b> and <b>Stop Control</b> may be set from the (Program =>) <b>Frq. Settings</b> menu.																				
<b>Emergency Off</b> — Terminates the output signal from the ASD and may apply a brake if so configured. The braking method may be selected at the (Program => Protection =>) <b>Emg Off Mode Sel</b> parameter.																				
<b>DC Braking</b> — The ASD outputs a DC current that is applied to the stator windings of the motor to quickly brake the motor.																				
<b>ACC/DEC 1/2 and ACC/DEC 3/4 Switching</b> — Activating combinations of discrete input terminals <b>Accel/Decel Switching 1/2</b> and <b>Accel/Decel Switching 3/4</b> allow for the selection of Accel/Decel profiles as shown below.																				
<table border="1"> <thead> <tr> <th colspan="2">Switching Terminal</th> <th rowspan="2">A/D Selection</th> </tr> <tr> <th>#1/2</th> <th>#3/4</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> <tr> <td colspan="2">1=Terminal Activated</td> <td></td> </tr> </tbody> </table> <p>The 1–4 settings of the A/D Switching selections are performed at parameters <b>F009/F010</b>, <b>F500/F501</b>, <b>F510/F511</b>, and <b>F514/F515</b>.</p>	Switching Terminal		A/D Selection	#1/2	#3/4	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated		
Switching Terminal		A/D Selection																		
#1/2	#3/4																			
0	0	1																		
0	1	2																		
1	0	3																		
1	1	4																		
1=Terminal Activated																				
<b>Motor 1/2 and Motor 3/4 Switching</b> — Activating combinations of discrete input terminals <b>Motor 1/2</b> and <b>Motor 3/4</b> allow for the activation of the motor selection as shown below.																				
<table border="1"> <thead> <tr> <th colspan="2">Switching Terminal</th> <th rowspan="2">Motor Selection</th> </tr> <tr> <th>#1/2</th> <th>#3/4</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> <tr> <td colspan="2">1=Terminal Activated</td> <td></td> </tr> </tbody> </table> <p>The 1–4 settings of the Motor Switching selections are performed at parameters <b>F171 – F181</b>.</p>	Switching Terminal		Motor Selection	#1/2	#3/4	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated		
Switching Terminal		Motor Selection																		
#1/2	#3/4																			
0	0	1																		
0	1	2																		
1	0	3																		
1	1	4																		
1=Terminal Activated																				

**Table 6. (Cont.)** Discrete Input Terminal Assignment Selections and Descriptions.

<p><b>Torque Limit 1/2 and Torque Limit 3/4 Switching</b> — Activating combinations of discrete input terminals <b>Torque Limit 1/2</b> and <b>Torque Limit 3/4</b> allow for the activation of the selected torque profile as shown below.</p>																			
<table border="1"> <thead> <tr> <th colspan="2">Switching Terminal</th> <th rowspan="2">Torque Limit Selection</th> </tr> <tr> <th>#1/2</th> <th>#3/4</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> </tbody> </table>		Switching Terminal		Torque Limit Selection	#1/2	#3/4	0	0	1	0	1	2	1	0	3	1	1	4	<p>The 1–4 settings of the Torque Limit Switching selections are performed at parameters <b>F171 – F181</b>.</p>
Switching Terminal		Torque Limit Selection																	
#1/2	#3/4																		
0	0	1																	
0	1	2																	
1	0	3																	
1	1	4																	
<p>1=Terminal Activated</p>																			
<p><b>PID (Control) Off</b> — Activating this terminal turns off <b>PID</b> control. Terminal activation overrides the settings of the <b>Input Feedback Select</b> parameter and the <b>Panel PID Control</b> parameter.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Jog Forward (Forced)</b> — This setting initiates a <b>Forced Forward Jog</b> when activated. The <b>Forced Forward Jog</b> command provides a forward-run signal for the duration of the activation (the status of the <b>F</b> or <b>R</b> terminals is ignored). The <b>Jog Run Frequency</b> and <b>Stop Control</b> may be set from the (Program ⇒) <b>Frq. Settings</b> menu.</p>																			
<p><b>Jog Reverse (Forced)</b> — This setting initiates a <b>Forced Reverse Jog</b> when activated. The <b>Forced Reverse Jog</b> command provides a reverse-run signal for the duration of the activation (the status of the <b>F</b> or <b>R</b> terminals is ignored). The <b>Jog Run Frequency</b> and <b>Stop Control</b> may be set from the (Program ⇒) <b>Frq. Settings</b> menu.</p>																			
<p><b>Binary Bit 0</b> — Bit 0 – 7 may be set up as a speed/torque control register. Speed/torque settings may be applied to this group of terminals in binary form. The required number of input terminals should be set to the respective binary bit settings (0 – MSB). The <b>Frequency Mode</b> setting must be set to <b>Binary/BCD input</b>.</p> <p>The gain and bias of the binary input may be set from the following path: Program ⇒ Frq. Settings ⇒ Speed Ref. Setpoints ⇒ BIN (see <a href="#">BIN Speed Frequency Setpoint #1 (Hz)</a> for further information on this setting.</p>																			
<p><b>Binary Bit 1</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Binary Bit 2</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Binary Bit 3</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Binary Bit 4</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Binary Bit 5</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Binary Bit 6</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Binary Bit 7</b> — See selection <b>Binary Bit 0</b> above.</p>																			
<p><b>Forced Stop</b> — Activating this terminal terminates the <b>Run</b> command regardless of the <b>Command Mode</b> setting and initiates the programmed stopping method.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Damper Feedback</b> — Activation of this terminal indicates an open damper and enables the system for normal operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			
<p><b>Reserved</b> — No operation.</p>																			

**Table 6. (Cont.)** Discrete Input Terminal Assignment Selections and Descriptions.

<b>Reserved</b> — No operation.
<b>Reserved</b> — No operation.
<p><b>Binary Data Write</b> — This terminal serves two functions:</p> <p>1) While operating in the <b>Binary/BCD input</b> mode, each momentary activation of this terminal transfers the speed/torque <b>Binary Bit</b> (0 – MSB) settings to the motor.</p> <p>2) When operating with the <b>Frequency Mode</b> set to <b>Motorized Pot</b>, the status of the <b>Motorized Pot</b> frequency setting may be <b>Stored</b> or <b>Erased</b> after a power down or a system reset. Select <b>Stored</b> or <b>Erased</b> at the <b>Motorized Pot Frequency at Power Down</b> parameter. The <b>Binary Data Write</b> terminal must be activated before the initiation of the power down or reset.</p>
<b>Motorized Pot Up (MOP)</b> — Activating this terminal causes an increase in motor speed for the duration of the activation until the <b>Upper Limit</b> is reached. The <b>Frequency Mode</b> setting must be set to <b>Motorized Pot. Simulation</b> . The MOP acceleration rate is determined by the <b>Accel #2 Time</b> setting.
<b>Motorized Pot Down (MOP)</b> — Activating this terminal causes a decrease in motor speed for the duration of the connection until the <b>Lower Limit</b> is reached. The <b>Frequency Mode</b> setting must be set to <b>Motorized Pot. Simulation</b> . The MOP deceleration rate is determined by the <b>Decel #2 Time</b> setting.
<b>Motorized Pot Clear</b> — Activating this terminal will establish a frequency setpoint of 0.0 Hz after a power down or a system reset regardless of the <b>Motorized Pot Frequency at Power Down</b> setting. The <b>Motorized Pot Clear</b> terminal must be activated before the initiation of the power down or reset.
<b>Momentary (Push) Run</b> — When activated this terminal starts the motor.
<b>Momentary (Push) Stop</b> — When activated this terminal stops the motor.
<b>Forward/Reverse</b> — This setting operates in conjunction with another discrete terminal being set to the <b>Run/Stop</b> function. When configured to <b>Run (Run/Stop activated)</b> , the activation/deactivation of this terminal toggles the direction of the motor.
<b>Run/Stop</b> — This terminal enables the motor to run when connected to <b>CC</b> and disables the motor when the connection is broken.
<p><b>Line (Power) Bypass</b> — Terminal activation of the <b>Line (Power) Bypass</b> function requires an enable at the <b>Power Switching</b> parameter and a user-supplied switching frequency at the <b>Power Switching Frequency</b> parameter.</p> <p>During acceleration, once the <b>Power Switching Frequency</b> setting is reached, activating this terminal switches off the ASD output and routes commercial power to the motor. If <b>At Frequency</b> is selected at the <b>Power Switching</b> parameter, <b>Line (Power) Bypass</b> will be carried out once reaching the user-supplied switching frequency and activating this terminal will serve no function.</p>
<b>Frequency Priority</b> — Activating this terminal toggles the frequency control between the <b>Frequency Mode #1</b> setting and the setting of <b>Frequency Mode #2</b> . This function is enabled by setting the <b>Ref Priority Sel</b> to <b>Freq Priority Switching</b> and is located at Program ⇒ Frequency Settings ⇒ <b>Reference Priority</b> .
<b>VI/II Prty (VI/II Terminal Priority)</b> — Activating this terminal assigns command control to the <b>VI/II Terminal</b> and overrides all other <b>Control Terminal Strip</b> input so long as the <b>Command Mode</b> is set to <b>Control Terminal Strip</b> .
<b>Term Prty (Terminal Strip Priority)</b> — Activating this terminal overrides the <b>Frequency Mode</b> setting and assigns speed control to the <b>Control Terminal Strip</b> .
<b>Editing Enabled (LED)</b> — The <b>LED Keypad</b> system is unavailable at the time of this release.
<b>Torque/Position (Control Switch)</b> — This function allows for a system change from speed-control to torque- or position-control as a function of the <b>V/f</b> setting when activated.
<b>Deviation Counter Clear</b> — Activating this terminal clears the <b>Deviation Counter</b> when operating in the <b>Position Control</b> mode.
<b>Forward Limit (Position Control)</b> — Activating this terminal will immediately stop the ASD and hold its position. If the connection remains for an extended period the ASD will time out and trip. This function is normally used for over-travel conditions.
<b>Reverse Limit (Position Control)</b> — Activating this terminal will immediately stop the ASD and hold its position. If the connection remains for an extended period the ASD will time out and trip. This function is normally used for over-travel conditions.
<b>Light-Load High-Speed Enable</b> — Activating this terminal sets the lower limit of an output frequency range in which the <b>Light-load/High-speed</b> function may be used.

**Table 6. (Cont.)** Discrete Input Terminal Assignment Selections and Descriptions.

<b>Snap Stop Control Enable</b> — TBD.
<b>Pre-excite (Motor)</b> — Activating this terminal applies an excitation current to the motor (holds shaft stationary) for the duration of the activation.
<b>Brake Command</b> — TBD.
<p><b>Brake Release</b> — Activating this terminal initiates the brake release command. This setting requires that another discrete input terminal be set to <b>System Consistent Sequence</b> (BA: braking answer) to complete the brake release command and to convey the status of the braking system to the user or to a dependent subsystem.</p> <p>Once the braking release function is initiated, the <b>Brake Fault Time</b> begins to count down. Should the count-down timer expire before the brake releases or before the <b>Braking Answer</b> is returned, fault <b>E-11</b> will occur. Otherwise, the brake releases the motor and normal motor operations resume.</p> <p>The <b>Braking Release</b> function is primarily used at startup; but, may be used when the brake is applied while the motor is running.</p>
<p><b>Brake Answer</b> — This setting is required when the <b>Braking Release</b> function is used. The function of this input terminal is to receive the returned status of the braking system. The returned status is either <b>Released</b> or <b>Not Released</b>.</p> <p>If <b>Released</b> is returned within the time setting of the <b>Brake Fault Time</b> parameter, normal system function resumes.</p> <p>If <b>Not Released</b> is returned or if the <b>Brake Fault Time</b> parameter setting times out before either signal is returned, then fault <b>E-11</b> occurs.</p> <p>The returned signal may also be used to notify the user or to control a dependent subsystem.</p>
<b>Brake Test</b> — TBD.
<b>Fire Speed</b> — When activated <b>Preset Speed #1</b> is output from the ASD.
<b>MUV Disable</b> — When activated the <b>Main Undervoltage Detect</b> function is disabled.



**Table 7.** Discrete Output Terminal Assignment Selections (OUT1/2, and FL).

<b>Discrete Output Terminal Functions</b>	
Lower Limit (LL)	POFF Alarm (power supply out of specification)
Upper Limit (UL)	Brake Release
Low	(In) Alarm Status
Acc/Dec Completion	Forward Speed Limit (torque control)
RCH Speed	Reverse Speed Limit (torque control)
Fault (All)	Healthy (Output)
Fault 2 (except EF or OCL)	Abnormal Communication Alarm
OC (Over-current) Alarm	Error Code Output 1 (6-bit error output)
ASD OL (Overload) Alarm	Error Code Output 2 (6-bit error output)
Motor OL (Overload) Alarm	Error Code Output 3 (6-bit error output)
OH (Overheat) Alarm	Error Code Output 4 (6-bit error output)
OV (Overvoltage) Alarm	Error Code Output 5 (6-bit error output)
DCV (DC Voltage) Low Alarm	Error Code Output 6 (6-bit error output)
Low-current Alarm	Designated Data Output 1 (7-bit transmission output)
OT (Overtorque) Alarm	Designated Data Output 2 (7-bit transmission output)
DBR OL (Dynamic Braking Resistor Overload) Alarm	Designated Data Output 3 (7-bit transmission output)
In E-Off (Emergency Off)	Designated Data Output 4 (7-bit transmission output)
Retrying	Designated Data Output 5 (7-bit transmission output)
Damper Cmd	Designated Data Output 6 (7-bit transmission output)
PID Deviate (Deviation Limit)	Designated Data Output 7 (7-bit transmission output)
Start/Stop	Light Load Detection Signal
Hard Fault (OCA, OCL, EF, Lost Phase, Short Circuit, or Abnormal Output)	Heavy Load Detection Signal
Soft Fault (OL, OC1, 2, 3, OP)	Positive Torque Limit
Bypass (Output) #1	Negative Torque Limit
Bypass (Output) #2	Rush Suppression Relay Output
Fan On/Off	Position Overtravel
Jogging	Position Reached
Terminal Mode (Control Terminal Strip Operation Command Mode)	EF Alarm
Run-time Alarm (Total-operation-hours Alarm)	LOD Alarm
Communication Alarm (external cause)	Fire Alarm
Forward/Reverse Operation	Damper Alarm
Ready (for operation) (including <b>ST</b> and <b>RUN</b> )	4–20 mA Loss
Ready (for operation)	Auto-bypass


Table 8 shows the default full-scale output setting of the FM/AM terminal for each selection. The column on the right side of Table 8 shows the actual FM/AM output for a keypad display of 100% (default setting).

Table 8. AM, FM, FP, and Analog 1&2 output terminal selections.

FM, AM, FP, and Analog 1&2 Terminal Functions	Actual FM/AM Output Value at 100% Displayed Output at the EOI
Output Frequency	Maximum Frequency
Frequency Reference	
Output Current	150%
DC Bus Voltage	
Output Voltage	
Post-compensation Frequency	Maximum Frequency
Speed Feedback (realtime)	
Speed Feedback (1 sec filter)	
Torque	150%
Torque Command	
Internal Torque Base	
Torque Current	
Excitation Current	
PID Feedback Value	Maximum Frequency
Motor Overload Ratio	Motor Overload Trip Point Setting
ASD Overload Ratio	ASD Overload Trip Point Setting
DBR Overload Ratio	DBR Overload Trip Point Setting
DBR Load Ratio	Maximum DBR Duty Cycle
Input Power	1.73 * input voltage * ASD rated current
Output Power	
Peak Output Current	150%
Peak DC Bus Voltage	
PG Counter	32767 Encoder Pulses
Position Pulse	
RR Input	100%
VI/II Input	
RX Input	
RX2 Input	
FM Output (used for factory testing only)	
AM Output (used for factory testing only)	
Meter Adjust Value	
Analog Output	
Load Torque	
<b>FM/AM Scaling</b>	
<i>Note: The actual magnitude of the FM/AM output signal at full-scale is selection-specific and may be adjusted to fit the requirements of the application (see AM Terminal Adjustment on pg. 63 and FM Terminal Assignment on pg. 87).</i>	

# Enclosure Dimensions and Conduit Plate Information

## W7 ASD Part Numbering Convention.




---


**Note:** *The Type 1 enclosed versions of the W7 ASD meet or exceed the specification **UL 1995**, the **Standard for Heating and Cooling Equipment**, and complies with the applicable requirements for installation in a compartment handling conditioned air.*

# Enclosure Dimensions/Weight

Table 9. W7 ASD 60 HP – 200 HP Enclosure Dimensions.



**Table 10. W7 ASD 250 HP – 800 HP Enclosure Dimensions.**



# Alarms, Trips, and Troubleshooting

## Alarms and Trips

This section lists the available user-notification codes of the EOI display and provides information that assists the user in the event that a **Fault** is incurred. The **User Notification** codes are displayed as an indication that a system function or system condition is active (i.e., ATN, DB, and DBON). The code is displayed on the EOI for the duration of the activation.

If a user setting or an ASD parameter has been exceeded, or if a data transfer function produces an unexpected result, a condition that is referred to as a **Fault** is incurred.

An **Alarm** is an indication that a **Fault** is imminent if existing operating conditions continue unchanged. An **Alarm** may be associated with an output terminal to notify the operator of the condition remotely, close a contact, or engage a brake. At the least, an **Alarm** will cause an alarm code to appear on the EOI display. [Table 11 on pg. 177](#) lists the 15 possible **Alarm** codes that may be displayed during operation of the **W7 ASD**.

In the event that the condition that caused the **Alarm** does not return to its normal operating level within a specified time, the ASD **Faults** and a **Trip** is incurred (**Fault** and **Trip** are sometimes used interchangeably). A **Trip** is a safety feature, and is the result of a **Fault**, that disables the ASD system in the event that a subsystem of the ASD is malfunctioning, or one or more of the variables listed below exceeds its normal range (time and/or magnitude).

- Current,
- Voltage,
- Speed,
- Temperature,
- Torque, or
- Load.

See [Table 13 on pg. 180](#) for a listing of the potential **Trips** and the associated probable causes.

The operating conditions at the time of the trip may be used to help determine the cause of the trip. Listed below are operating conditions that may be used to assist the operator in correcting the problem or that the ASD operator should be prepared to discuss when contacting Toshiba's Customer Support for assistance.

- What trip information is displayed?
- Is this a new installation?
- Has the system ever worked properly and what are the recent modifications (if any)?
- What is the ASD/Motor size?
- What is the CPU version and revision level?
- What is the EOI version?
- Does the ASD trip when accelerating, running, decelerating, or when not running?
- Does the ASD reach the commanded frequency?
- Does the ASD trip without the motor attached?
- Does ASD trip with an unloaded motor?

# Alarms

Table 11 lists the alarm codes that may be displayed during operation of the **W7 ASD**. Each alarm code listed is accompanied by a description and a possible cause. In the event that the source of the malfunction cannot be determined, contact your Toshiba Sales Representative for further information on the condition and for an appropriate course of action.

The active **Alarm** is displayed on the **Frequency Command** screen. Multiple active alarms are displayed one at a time and are scrolled at one-second intervals.

**Table 11. W7 ASD Alarms.**

<b>EOI Display</b>	<b>Function</b>	<b>Description</b>	<b>Possible Causes</b>
<b>CM1</b>	Comm1 Error	Internal communications error.	<ul style="list-style-type: none"> <li>Improperly programmed ASD.</li> <li>Improper communications settings.</li> </ul>
<b>CM2</b>	Comm2 Error	External communications error.	<ul style="list-style-type: none"> <li>Improperly connected cables.</li> </ul>
<b>EMG</b>	Emergency Off	Output signal from the ASD is terminated and a brake may be applied if so configured.	<ul style="list-style-type: none"> <li>Stop Reset pressed twice at the EOI.</li> <li>EOFF command received remotely.</li> <li>ASD reset required.</li> </ul>
<b>MOFF</b>	Main Undervoltage	Undervoltage condition at the 3-phase AC input to the ASD.	<ul style="list-style-type: none"> <li>Low 3-phase input voltage.</li> </ul>
<b>OC</b>	Over Current	ASD output current greater than the parameter <b>F601</b> setting.	<ul style="list-style-type: none"> <li>Defective IGBT (U, V, or W).</li> <li>ASD output to the motor is connected incorrectly. Disconnect the motor and retry.</li> <li>ASD output phase-to-phase short.</li> <li>The ASD is starting into a spinning motor.</li> <li>Motor/machine jammed.</li> <li>Mechanical brake engaged while the ASD is starting or while running.</li> <li>Accel/Decel time is too short.</li> <li>Voltage Boost setting is too high.</li> <li>Load fluctuations.</li> <li>ASD operating at an elevated temperature.</li> </ul>
<b>*OH</b>	Overheat	ASD ambient temperature excessive.	<ul style="list-style-type: none"> <li>ASD is operating at an elevated temperature.</li> <li>ASD is too close to heat-generating equipment.</li> <li>Cooling fan vent is obstructed (see <a href="#">Mounting the ASD on pg. 14</a>).</li> <li>Cooling fan is inoperative.</li> <li>Internal thermistor is disconnected.</li> </ul>
<b>OJ</b>	Timer	Run-time counter exceeded.	<ul style="list-style-type: none"> <li><b>Type Reset</b> required; select <b>Clear run timer</b>.</li> </ul>
* Reset ignored if active.			

EOI Display	Function	Description	Possible Causes
*OLI	ASD Overload	Load requirement in excess of the capability of the ASD.	<ul style="list-style-type: none"> <li>The carrier frequency is too high.</li> <li>An excessive load.</li> <li>Acceleration time is too short.</li> <li>DC damping rate is set too high.</li> <li>The motor is starting into a spinning load after a momentary power failure.</li> <li>The ASD is improperly matched to the application.</li> </ul>
OLM	Motor Overload	Load requirement in excess of the capability of the motor.	<ul style="list-style-type: none"> <li>V/f parameter improperly set.</li> <li>Motor is locked.</li> <li>Continuous operation at low speed.</li> <li>The load is in excess of what the motor can deliver.</li> </ul>
*OLR	Resistor Overload	Excessive current at the <b>Dynamic Braking Resistor</b> .	<ul style="list-style-type: none"> <li>Deceleration time is too short.</li> <li>DBR configuration improperly set.</li> </ul>
*OP	Overvoltage	DC bus voltage exceeds specifications.	<ul style="list-style-type: none"> <li>ASD attempting to start into a spinning motor after a momentary power loss.</li> <li>Incoming 3-phase power is above the specified range.</li> <li>Decel time is too short.</li> <li>Voltage spikes at the 3-phase input; install inductive filter.</li> <li>DBR required.</li> <li>DBR resistance value is too high.</li> <li>DBR function is turned off.</li> <li>Overvoltage Stall feature is turned off.</li> <li>System is regenerating.</li> <li>Load instability.</li> <li>Disable the Ridethrough function (F302).</li> </ul>
OT	Overtorque	Torque requirement in excess of the setting of parameter F616 or F617 for a time longer than the setting of parameter F618.	<ul style="list-style-type: none"> <li>ASD is not correctly matched to the application.</li> <li>Parameter F616 or F617 setting is too low.</li> <li>Obstructed load.</li> </ul>
*POFF	Control Undervoltage	Undervoltage condition at the 5, 15, or the 24 VDC supply.	<ul style="list-style-type: none"> <li>Defective Control board.</li> <li>Excessive load on power supply.</li> <li>Low input voltage.</li> </ul>
PtSt	Reference Point	Two speed-reference frequency setpoint values are too close to each other.	<ul style="list-style-type: none"> <li>Two speed reference frequency setpoints are too close to each other (increase the difference).</li> </ul>
* Reset ignored if active.			



EOI Display	Function	Description	Possible Causes
UC	Undercurrent	Output current of the ASD is below the level defined at parameter F611 and remains there for the time set at parameter F612.	
* Reset ignored if active.			

## User Notification Codes

The **User Notification** codes appear on the **Frequency Command** screen while the associated function is active.

**User Notification** codes notify the user of active functions that are usually only momentary under normal conditions and are active for the duration of activation only. User notification events are not error conditions and only convey active system functions to the user.

Table 12

EOI	Function	Description
<b>Atn</b>	Autotune Active	<b>Atn</b> indicates that the <b>Autotune</b> function is active. If the initial <b>Autotune</b> fails for any reason, an automatic retry is initiated if <b>Other Motor</b> is selected at parameter F413.
<b>db or dbOn</b>	DC Braking Active	This code conveys that the <b>DC Injection</b> function being carried out. The display shows <b>db</b> when braking and <b>dbOn</b> when the <b>Shaft Stationary</b> function is active.

# Trips/Faults

A **Trip** is an ASD response to a **Fault** (though, **Fault** and **Trip** are sometimes used interchangeably). A **Trip** is a safety feature that disables the ASD system in the event that a subsystem of the ASD is malfunctioning.

Listed in [Table 13](#) are the possible **Faults** that may cause a **Trip** and the possible causes. When a **Trip** is incurred the system displays the **Fault** screen. The **Fault** screen identifies the active **Fault**.

**Table 13**

Fault Screen Display	Possible Causes
<b>Inverter (ASD) OL</b>	<ul style="list-style-type: none"> <li>• Acceleration time is too short.</li> <li>• DC Injection current is too high.</li> <li>• V/f setting needs to be adjusted.</li> <li>• Motor running during restart.</li> <li>• ASD or the motor is improperly matched to the application.</li> </ul>
<b>Autotuning Err</b>	<ul style="list-style-type: none"> <li>• <b>Autotune</b> readings that are significantly inconsistent with the configuration information.</li> <li>• A non-3-phase motor is being used.</li> <li>• Incorrect settings at parameter <a href="#">F400</a>, <a href="#">F413</a>, or <a href="#">F414</a>.</li> <li>• Using a motor that has a significantly smaller rating than the ASD.</li> <li>• ASD output cabling is too small, too long, or is being housed in a cable tray with other cables that are producing an interfering EMF.</li> <li>• Motor is running during the <b>Autotune</b> function.</li> </ul>
<b>Comm Error</b>	<ul style="list-style-type: none"> <li>• Communication malfunction.</li> <li>• Improper or loose connection.</li> <li>• Improper system settings.</li> </ul>
<b>Ctrl Undervolts</b>	<ul style="list-style-type: none"> <li>• This fault is caused by an undervoltage condition at the 5, 15, or the 24 VDC supply.</li> <li>• 3-phase input voltage low.</li> </ul>
<b>CPU Error</b>	<ul style="list-style-type: none"> <li>• CPU malfunction.</li> </ul>
<b>Main Undervolts</b>	<ul style="list-style-type: none"> <li>• 3-phase input voltage low.</li> <li>• Defective control board.</li> <li>• Excessive load on the power supply.</li> <li>• Undervoltage/Ridethrough settings require adjustment.</li> </ul>
<b>Fuse</b>	<ul style="list-style-type: none"> <li>• Internal DC bus fuse is open.</li> </ul>
<p><b>Note:</b> <i>The event that caused the Trip(s) must be corrected or must decrease to less than the threshold value required to cause the trip to allow for a Reset to be recognized. In the event of multiple active trips, the trip displayed will remain until all faults are corrected and all trips are cleared.</i></p>	

Fault Screen Display	Possible Causes
<b>DBR Overcurrent</b>	<ul style="list-style-type: none"> <li>• ASD inability to discharge the bus voltage during regeneration.</li> <li>• No dynamic braking resistor (DBR) installed.</li> <li>• Deceleration time is too short.</li> <li>• Improper DBR setup information.</li> <li>• Defective IGBT7 (or IGBT7 ckt.).</li> <li>• 3-phase input voltage is above specification.</li> </ul>
<b>DBR Overload</b>	<ul style="list-style-type: none"> <li>• Deceleration time is too short.</li> <li>• DBR setting adjustment required.</li> <li>• Overvoltage Stall setting adjustment required.</li> </ul>
<b>GND Fault</b>	<ul style="list-style-type: none"> <li>• Ground fault at the motor.</li> <li>• Ground fault at the output of the ASD.</li> <li>• Current leakage to <b>Earth Ground</b>.</li> </ul>
<b>Ctrl EEPROM Err</b>	<ul style="list-style-type: none"> <li>• Internal EEPROM malfunction.</li> </ul>
<b>EEPROM Write Err</b>	<ul style="list-style-type: none"> <li>• EEPROM write malfunction.</li> </ul>
<b>E-Off</b>	<ul style="list-style-type: none"> <li>• Emergency Off command received via EOI or remotely.</li> </ul>
<b>Encoder Loss</b>	<ul style="list-style-type: none"> <li>• Encoder signal missing while running during closed-loop operation.</li> </ul>
<b>Flash Error</b>	<ul style="list-style-type: none"> <li>• Flash memory malfunction.</li> </ul>
<b>Gate Array Error</b>	<ul style="list-style-type: none"> <li>• Defective Gate Array or Gate Array malfunction.</li> </ul>
<b>In(put) Phase Loss</b>	<ul style="list-style-type: none"> <li>• 3-phase input to the ASD is low or missing.</li> </ul>
<b>Load Drooping</b>	<ul style="list-style-type: none"> <li>• Load requirement is in excess of the capabilities of the motor.</li> </ul>
<b>Load End OC</b>	<ul style="list-style-type: none"> <li>• Improper wiring at the ASD output to the motor.</li> </ul>
<b>Under Curr(ent) Trip</b>	<ul style="list-style-type: none"> <li>• Improper Low Current detection level setting.</li> </ul>
<b>Main EEPROM Err</b>	<ul style="list-style-type: none"> <li>• Internal EEPROM malfunction.</li> </ul>
<b>Motor Overload</b>	<ul style="list-style-type: none"> <li>• V/f setting needs to be adjusted.</li> <li>• Motor is locked.</li> <li>• Continuous operation at low speed.</li> <li>• Load requirement exceeds ability of the motor.</li> <li>• Startup frequency setting adjustment required.</li> </ul>
<b>Option PCB Error</b>	<ul style="list-style-type: none"> <li>• Optional device malfunction.</li> <li>• Improper system settings (at ASD or optional device).</li> <li>• Loose or improper connection.</li> </ul>
<b>Out(put) Phase Loss</b>	<ul style="list-style-type: none"> <li>• 3-phase output from the ASD is low or missing.</li> </ul>
<p><i><b>Note:</b> The event that caused the Trip(s) must be corrected or must decrease to less than the threshold value required to cause the trip to allow for a Reset to be recognized. In the event of multiple active trips, the trip displayed will remain until all faults are corrected and all trips are cleared.</i></p>	

Fault Screen Display	Possible Causes
<b>Overcurrent Acc</b>	<ul style="list-style-type: none"> <li>• V/f setting needs to be adjusted.</li> <li>• Restart from a momentary power outage.</li> <li>• The ASD is starting into a rotating motor.</li> <li>• ASD/Motor not properly matched.</li> <li>• Phase-to-phase short (<b>U, V, or W</b>).</li> <li>• <b>Accel</b> time too short.</li> <li>• <b>Voltage Boost</b> setting is too high.</li> <li>• Motor/machine jammed.</li> <li>• Mechanical brake engaged while the ASD is running.</li> <li>• ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during acceleration. On ASDs that are greater than 100 HP, this fault occurs when the ASD current exceeds 320% of the rated FLA during acceleration.</li> </ul>
<b>Overcurrent Dec</b>	<ul style="list-style-type: none"> <li>• Phase-to-phase short (<b>U, V, or W</b>).</li> <li>• Deceleration time is too short.</li> <li>• Motor/machine jammed.</li> <li>• Mechanical brake engaged while the ASD is running.</li> <li>• ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during deceleration. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA during deceleration.</li> </ul>
<b>Overcurrent Run</b>	<ul style="list-style-type: none"> <li>• Load fluctuations.</li> <li>• ASD is operating at an elevated temperature.</li> <li>• ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during a fixed-speed run or if during a fixed-speed run the ASD overheats. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA on a fixed-speed run.</li> </ul>
<b>Overheat</b>	<ul style="list-style-type: none"> <li>• Cooling fan inoperative.</li> <li>• Ventilation openings are obstructed.</li> <li>• Internal thermistor is disconnected.</li> </ul>
<b>Speed Error</b>	<ul style="list-style-type: none"> <li>• Result of a motor speed that is greater than the commanded speed when using an encoder for speed control.</li> <li>• Improper encoder connection or setup information.</li> <li>• Defective encoder.</li> </ul>
<p><b>Note:</b> <i>The event that caused the Trip(s) must be corrected or must decrease to less than the threshold value required to cause the trip to allow for a Reset to be recognized. In the event of multiple active trips, the trip displayed will remain until all faults are corrected and all trips are cleared.</i></p>	

Fault Screen Display	Possible Causes
<b>Overtorque</b>	<ul style="list-style-type: none"> <li>• A torque requirement by the load in excess of the setting of parameter <b>F616</b> or <b>F617</b> for a time longer than the setting of parameter <b>F618</b>.</li> <li>• The ASD is improperly matched to the application.</li> <li>• The load is obstructed.</li> </ul>
<b>Overvolt Accel</b>	<ul style="list-style-type: none"> <li>• Motor running during restart.</li> </ul>
<b>Overvolt Decel</b>	<ul style="list-style-type: none"> <li>• Deceleration time is too short.</li> <li>• DBR value is too high.</li> <li>• DBR required (DBR setup required).</li> <li>• Stall protection is disabled.</li> <li>• 3-phase input voltage is out of specification.</li> <li>• Input reactance required.</li> </ul>
<b>Overvolt Run</b>	<ul style="list-style-type: none"> <li>• Load fluctuations.</li> <li>• 3-Phase input voltage out of specification.</li> </ul>
<b>Positional Err</b>	<ul style="list-style-type: none"> <li>• Operating in the <b>Position Control</b> mode and the resulting position exceeds the limits of the <b>Position Control</b> setting.</li> </ul>
<b>RAM Err</b>	<ul style="list-style-type: none"> <li>• Internal RAM malfunction.</li> </ul>
<b>ROM Err</b>	<ul style="list-style-type: none"> <li>• Internal ROM malfunction.</li> </ul>
<b>Sink/Source Error</b>	<ul style="list-style-type: none"> <li>• Improperly positioned <b>Sink/Source</b> jumper on the control board or on an option device.</li> <li>• <b>Sink/Source</b> configuration of an option device is incorrect.</li> </ul>
<b>Type(form) Error</b>	<ul style="list-style-type: none"> <li>• Firmware information (typeform) loaded into the <b>Gate Driver</b> board is inconsistent with the device in which the firmware is being used.</li> <li>• The <b>Gate Driver</b> board has been replaced.</li> <li>• The <b>Gate Driver</b> board is defective.</li> </ul>
<b>U Phase OC</b>	<ul style="list-style-type: none"> <li>• Low impedance at the U lead of the ASD output.</li> </ul>
<b>V Phase OC</b>	<ul style="list-style-type: none"> <li>• Low impedance at the V lead of the ASD output.</li> </ul>
<b>W Phase OC</b>	<ul style="list-style-type: none"> <li>• Low impedance at the W lead of the ASD output.</li> </ul>
<p><b>Note:</b> <i>The event that caused the Trip(s) must be corrected or must decrease to less than the threshold value required to cause the trip to allow for a Reset to be recognized. In the event of multiple active trips, the trip displayed will remain until all faults are corrected and all trips are cleared.</i></p>	

# Viewing Trip Information

In the event that the condition causing an **Alarm** does not return to the normal operating level within a specified time a **Trip** is incurred.

When a trip occurs, the resultant error information may be viewed either from the **Trip History** screen (Program ⇒ System Information and Setup ⇒ **Trip History**) or from the **Monitor** screen.

## Trip History

The **Trip History** screen records the system parameters for up to 24 trips. The recorded trips are numbered from zero to 23. Once the **Trip History** record reaches trip number 23, the oldest recorded trip will be deleted with each new record stored (first-in first-out). The **Trip #** field may be selected and scrolled through to view the recorded trip information for a given trip number. The monitored parameters are listed in **Table 14** as **At-trip Recorded Parameters** (parameter readings at the time that the trip occurred).

**Table 14. Trip History Record Parameters.**

At-trip Recorded Parameters			
1) Trip Number	9) Bus Voltage	17) Torque Reference	25) ASD Load
2) Trip Type	10) Discrete Input Status	18) Torque Current	26) DBR Load
3) Time and Date	11) OUT1/OUT2/FL Status	19) Excitation Current	27) Input Power
4) Frequency at Trip	12) Timer	20) PID Value	28) Output Power
5) Output Current	13) Post Compensation Frequency	21) Motor Overload	29) Peak Current
6) Output Voltage	14) Feedback (inst.)	22) ASD Overload	30) Peak Voltage
7) Direction	15) Feedback (1 sec.)	23) DBR Overload	31) PG Speed
8) Frequency Reference	16) Torque	24) Motor Load	32) PG Position

## Trip Record at Monitor Screen

The **Monitor** screen records and displays the trip name of up to four trips and catalogs each trip as **Past Trip #1**, **Past Trip #2**, **Past Trip #3**, and **Past Trip #4**. Once reset (**Clear Trip**), the trip records are erased. If no trips have occurred since the last reset, **No Error** is displayed for each trip record.

*Note:* An improper ASD setup may cause some trips — reset the ASD to the factory default settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Resets ⇒ **Restore Factory Defaults**).

The at-trip frequency of the last incurred trip may be viewed at the **Monitor** screen (see pg. 36). The **Monitor** screen at-trip record is erased when the ASD is reset and may be viewed without the use of the RTC option. The current output frequency is displayed here when no trip is active.

## Clearing a Trip

Once the cause of the trip has been corrected, performing a **Reset** re-enables the ASD for normal operation (clears the fault screen).

The fault screen may also be cleared using either of the following methods:

- Cycling power (trip info may be saved via parameter F602 if desired),
- Pressing the **Stop|Reset** key twice,
- Remotely via the communications channel,
- Momentarily connecting terminal **RES** to **CC** of the **Control Terminal Strip**, or
- Via Program ⇒ Utilities ⇒ Type Resets ⇒ **Clear Past Trips**.

# Cable/Terminal Specifications

Installation should conform to the 2005 National Electrical Code Article 110 (NEC) (Requirements for Electrical Installations), all regulations of the Occupational Safety and Health Administration, and any other applicable national, regional, or industry codes and standards.

**Note:** The following ratings are guidelines and shall not be the sole determining factor of the lug or wire size used with the W7 ASD. Application-specific applicables, wire insulation type, conductor material, and local and regional regulations are but a few of the considerations when selecting the actual lug and wire type to be used with the W7 ASD.

**Note:** Cable/Terminal specifications are based on the rated current of the ASD.

**Note:** Use only 75° C copper wire/cable for motor and power connections.

Model	MCCB Rating (Amps)	Typical Wire/Cable Size (AWG or kcmil)			Lug Size Range		
		AM, FM, and II Terminals	Control Terminals	Input/Output Power	Wire-Size/Lug-Capacity for <b>Input</b> Power	Wire-Size/Lug-Capacity for <b>Output</b> Power	
				Recommended			
W74600	100	20 (3-core shield)	18 (2-core shield)	3	8 to 3/0	16 to 1	
W74750	225			1	3/0 to 350	10 to 1/0	
W7410K	225			2/0		12 to 4/0	
W7412K	225			3/0			
W7415K	400				*1/0	2 to 500	*(6 to 250)
W7420K	400				*3/0		
W7425K	600				*250		
W7430K	600				*350	** (3/0 to 500)	*(1/0 to 500)
W7440K	800				*500		

**Note:** Input and Output power wires require shielding for CE compliance.

**Note:** (\*) Indicates that the item is one of a set of two parallel cables.

**Note:** (\*\*) Indicates that the item is one of a set of three parallel cables.

# Current/Voltage Specifications

Table 15. W7 ASD 60 – 800 HP 460 Volt NEMA Type-1 Chassis standard ratings table.

Model	Rated KVA	Motor HP/Kw	Input Voltage 3-Ph 50/60 ± 2 Hz	Output Voltage 3-Ph Variable Frequency	Output Current 100% Continuous	Overload Current 120% for 60 Secs.
W74600	60.0	60.0/45.0	380 – 480 VAC (±10%)	Input Voltage Level (Max.)	77.0 A	92.4 A
W74750	75.0	75.0/55.0			96.0 A	115.2 A
W7410K	100	100/75.0			124.0 A	148.8 A
W7412K	125	125/90.0			156.0 A	187.2 A
W7415K	150	150/110			190.0 A	228.0 A
W7420K	200	200/150			240.0 A	288.0 A
W7425K	250	250/185			302.0 A	362.4 A
W7430K	300	300/220			370.0 A	444.0 A
W7440K	400	400/298			480.0 A	576.0 A



# W7 ASD Spare Parts Listing

Table 16. 460 Volt 60 – 400 HP Spare Parts Listing.

Model Number W7	MOV	System Overcurrent Protection				Control Power Transformer	Contactor	Rectifier	Caps	DCL	FAN	IGBT
		MCCB	1-3FU	12FU, 13FU	14FU	CPT1	MS1-2	REC.	C1-C2 (C)	DCL	A	
4600	49047	56274	42371	PC26143P180	PC26130P015	PC33400P200	45678	45239	50855 (2)	36366	54140	54969
4750		56275	42140				PC26143P250	PC26130P019	PC33400P300			42337
410K				42338	34835 (6)	42769				47970 (3)		
412K	03672 (3)	56282	42372	PC26143P450	PC26130P024	PC33400P500	42767	45241 (6)	48020 (6)	41442	55383	50000 (3)
415K			42768				45242 (6)	48019 (8)	41443			
420K		48020 (8)	41444									
425K		56276	46112	PC26143P450	PC26130P024	PC33400P500	51973-37698	45241 (12)	48020 (8)	41442		
430K							51968-37698		37568 (6)	41443		
440K	51958-37698						37568 (8)		41444			

The above listed model numbers identify the power unit of the W7 System. Power Unit subassembly part numbers use the VT130W7U prefix.

The following items are common to the above-listed typeforms.

**EOI** — 58363-W.

**Rectifier** — 45242.

**Fan B** (where used) — 43480.

Parenthesized are the total quantities per model for the part immediately above the parenthesized quantity only. Toshiba recommends a spare parts inventory of 2 minimum for the parts listed. If the total quantity per unit is 3 or more then the suggested spare parts inventory is one third of the total unit quantity (2 minimum).

**Table 17. W7 460 Volt 60 – 400 HP PCB Spare Parts Listing.**

Model Number VT130W7U	PCB Part Numbers								
	48605	48776	52266 (Assy)	53288	53300	53390	56000	56222	56223
A, B, C, etc. PCB Typeform									
<b>4600</b>	K						E1		D
<b>4750</b>		B	(Assy)			A	E2	C	
<b>410K</b>		B	(Assy)			A	E2	C	
<b>412K</b>		B	(Assy)			A	E2	E	
<b>415K</b>		B	(Assy)	A	A (3)		E2	E	
<b>420K</b>		B	(Assy)	A	A (3)		E2	F	
<b>425K</b>		B	(Assy)	A	B (3)		E2	G	
<b>430K</b>		B	(Assy)	A	B (3)		E2	G	
<b>440K</b>		B	(Assy)	A	B (3)		E2	G	
<p>The following items are common to the above-listed typeforms.</p> <p><b>Control Terminal Strip PCB — 48570A.</b></p> <p><b>4-20 mA PCB — 48576A.</b></p> <p>Parenthesized are the total quantities per unit. Toshiba recommends a spare parts inventory of 2 minimum for the parts listed. If the total quantity per unit is 3 or more then the suggested spare parts inventory is one third of the total unit quantity (2 minimum)</p>									

# Index

## Symbols

0 Hz Command Function, 57  
0 Hz Dead Band Signal, 57

## A

Acc/Dec Base Frequency Adjustment, 58  
Accel #3 Time, 62  
Accel #4 Time, 62  
Accel/Decel Display Resolution, 58  
Accel/Decel Lower Limit Time, 61  
Accel/Decel Pattern #3, 60  
Accel/Decel Pattern #4, 60  
Accel/Decel Switching Frequency #1, 60  
Accel/Decel Switching Frequency #2, 61  
Accel/Decel Switching Frequency #3, 61  
Acceleration Time Adjustment, 62  
Alarms, 177  
AM, 17, 20, 37  
AM Terminal Assignment, 63  
AM, FM, FP, and Analog 1&2 settings, 172  
Analog 1 Terminal Adjustment, 64  
Analog 1 Terminal Assignment, 64  
Analog 2 Terminal Adjustment, 64  
Analog 2 Terminal Assignment, 64  
ASD Capacity, 12  
ASD Load, 37  
ASD Overload, 36  
ASD-NANOCOM, 23  
At-trip Recorded Parameters, 184  
Auto Restart, 70  
Automatic Accel/Decel #1, 65  
Autotuning Err, 180

## B

Bezel Mounting Dimensions, 32  
Bezel Mounting Hardware, 30  
BIN Speed Frequency Setpoint #1, 67  
BIN Speed Frequency Setpoint #2, 68  
BIN Speed Reference Setpoint #1, 68  
BIN Speed Reference Setpoint #2, 68  
BIN Torque Reference Setpoint #1, 69  
BIN Torque Reference Setpoint #2, 69  
Brake Fault Internal Time, 70  
Break/Make Auto Restart, 70  
Bus Voltage, 36

## C

Cable/Terminal Specifications, 185  
CC, 17, 20  
Changed From Default screen, 34  
Clearing a Trip, 184  
CM1, 177  
CM2, 177  
CN7 Pinout, 24  
CNU1/1A and CNU2/2A Pinout, 25  
CNU3 Pinout, 24  
Comm Error, 180  
Commercial Power Wait Time, 71  
Common Serial (TTL), 23  
Communication Interval (TTL), 70  
Communications Reference Point Selection, 71  
Communications Speed Frequency Setpoint #1, 73  
Communications Speed Frequency Setpoint #2, 73  
Communications Speed Reference #1, 72  
Communications Speed Reference #2, 72  
Compensation Coefficient for Iron Loss, 73  
concerns about this publication, 1  
Conduit Plate Information, 173  
Connecting the ASD, 15  
Constant Vector Control, 73  
Control Board, 23  
Control Terminal Strip, 17  
CPU Error, 180  
Ctrl EEPROM Err, 181  
Ctrl Undervolts, 180  
Current Control Integral Gain, 75  
Current Control Proportional Gain, 75  
Current Differential Gain, 75  
Current/Voltage Control Switching Frequency, 74  
Current/Voltage Specifications, 186

## D

DBR Load, 37  
DBR Overcurrent, 181  
DBR Overload, 37, 181  
DC Injection At Direction Change, 76  
Dead Time Compensation (Enable), 76  
Dead-time Compensation Bias, 76  
Decel #3 Time, 77  
Decel #4 Time, 77  
Deceleration Time Adjustment, 78  
Default Setting Changes, 33  
Default Term. Setting, 17  
Direction, 37

- Discrete Input, 17
- Discrete Output, 17
- Disposal, 4
- Down Key, 28
- Drive Characteristics, 12
- Driving Torque Limit #1, 78
- Driving Torque Limit #2, 79
- Driving Torque Limit #3, 79
- Driving Torque Limit #4, 79
- Drooping, 79
- Drooping Gain, 79
- Drooping Insensitive Torque Band, 80
- Drooping Reference, 80
- Dynamic Braking Enable, 81
- Dynamic Braking Resistance, 81
- Dynamic Braking Resistance Capacity, 81

## E

- Earth Fault Alarm Time, 82
- Earth Fault Trip Level, 82
- Earth Fault Trip Time, 82
- EEPROM Write Err, 181
- Electronic Gear Setting, 82
- Electronic Operator Interface, 27
- Electronic Thermal Protection #1, 83
- Electronic Thermal Protection #2, 83
- Electronic Thermal Protection #3, 83
- Electronic Thermal Protection #4, 83
- EMG, 177
- Enclosure Dimensions, 173
- Enclosure Dimensions/Weight, 174
- Encoder Loss, 181
- Enter Key, 27
- E-Off, 181
- EOI Bezel Mounting Dimensions, 32
- EOI Bezel Plate Dimensions (mounting), 32
- EOI Features, 27
- EOI Installation Precautions, 31
- EOI Operation, 28
- EOI Remote Mounting, 30
- EOI Remote Mounting using the ASD-MTG-KIT, 32
- EOI Remote Mounting w/o the ASD-MTG-KIT, 31
- Equipment Inspection, 3
- Escape Key, 27
- Excitation Current, 36
- Excitation Starting Rate, 85
- Exciting Strengthening Coefficient, 85
- Extended Terminal Function, 85
- Extender Cables, 30

## F

- F, 17, 19
- Fan Control Mode Selection, 85
- Fault, 176
- Fault Detect Station Number, 86
- Faults, 176
- Feedback 1-Second, 36
- Feedback Input Selection, 86
- Feedback Instantaneous, 36
- Feedback Source, 114
- Fire Speed, 142
- FLA, 17, 20
- FLA, B, and C switching relationship, 21
- Flash Error, 181
- FLB, 17, 20
- FLC, 17, 20
- FM, 17, 20, 37
- Forward Speed Limit Input, 88
- Forward Speed Limit Level, 88
- FP, 17, 20
- FP Terminal Assignment, 88
- Frequency for Automatic High-Speed Operation at Light-Load, 89
- Frequency Limit at Position, 89
- Frequency Mode #1, 89
- Frequency Reference, 36
- Frequency Setting, 35
- Fuse, 180

## G

- Gate Array Error, 181
- General Safety Information, 1
- GND Fault, 181

## H

- Handling and Storage, 3
- Heavy-Load Torque During Forward Acceleration, 91
- Heavy-Load Torque During Forward Deceleration, 91
- Heavy-Load Torque During Reverse Acceleration, 91
- Hz Per User-defined Unit, 91

## I

- I/O and Control, 17
- I/O Circuit Configurations, 25
- ICCDISIGNS, 23
- II, 17, 20
- Important Notice, 4
- In(put) Phase Loss, 181

- Input Feedback Selection, 86
- Input Power, 37
- Input Terminal Priority, 92
- Input Terminals, 36
- Inrush Current Time, 92
- Installation and Connections, 13
- Installation Notes, 13
- Installation Precautions, 5
- Interlock Inrush Relay With ST, 92
- Introduction, 4
- Inverter (ASD) OL, 180

## J

- Jump Frequency #1, 93
- Jump Frequency #1 Bandwidth, 93, 94
- Jump Frequency #3, 94
- Jump Frequency Processing, 95

## L

- LCD Display, 27
- Lead Length Specifications, 16
- Light Load Conditions, 11
- Light-Load High-Speed Operation Heavy-Load Detection Time, 95
- Light-Load High-Speed Operation Load Detection Time, 95
- Light-Load High-Speed Operation Load Wait Time, 95
- Light-load High-speed Operation Selection, 96
- Light-Load High-Speed Operation Switching Lower-Limit Frequency, 96
- Load Drooping, 181
- Load End OC, 181
- Load Inertia (Acc/Dec Torque), 96
- Load Sharing Gain Input, 97
- Load Torque Filter (Acc/Dec Torque), 97
- Load-produced Negative Torque, 11
- Local|Remote Key, 27
- Low Current Trip Threshold Time, 98
- Low Output Disable Start Time, 99

## M

- Main EEPROM Err, 181
- Main Undervolts, 180
- Menu Options, 35
- Mode 1/2 Switching Frequency, 101
- MOFF, 177
- MON/PRG, 28
- Motor 150% Overload Time Limit, 102

- Motor Braking, 12
- Motor Characteristics, 11
- Motor connection diagram, 15
- Motor Counter Data, 103
- Motor Load, 37
- Motor Overload, 36, 181
- Mounting the ASD, 14
- MS1 AUX, 13
- Multiplying Input Selection, 104

## O

- OC, 177
- OH, 177
- OJ, 177
- OLI, 178
- OLM, 178
- OLR, 178
- OP, 178
- Operation (Local), 33
- Operational and Maintenance Precautions, 10
- Option PCB Error, 181
- OT, 178
- Out(put) Phase Loss, 181
- OUT1, 17, 20
- OUT2, 17, 20
- Output Current, 36
- Output Power, 37
- Output Terminal Assignments, 171
- Output terminal selections, 172
- Output Terminals, 36
- Output Voltage, 36
- Over Exciting Cooperation, 110
- Overcurrent Acc, 182
- Overcurrent Dec, 182
- Over-current Protection, 12
- Overcurrent Run, 182
- Overcurrent Stall, 110
- Overheat, 182
- Overload Protection, 11
- Overload Reduction Starting Frequency, 110
- Overspeed Detection Frequency Range, 110
- Overtorque, 183
- Overtorque Detection Time, 110
- Overtorque Trip/Alarm Level (negative torque), 111
- Overtorque Trip/Alarm Level (positive torque), 111
- Overvolt Accel, 183
- Overvolt Decel, 183
- Overvolt Run, 183
- Overvoltage Stall, 111
- Overvoltage Stall Level, 112
- Overvoltage Stall Level (fast), 112

## P

- P24, 17, 20
- PA, 15
- Panel Menu, 35
- Panel Reset Selection, 112
- Panel V/f Group Selection, 113
- Peak Current, 37
- Peak Voltage, 37
- PG Position, 37
- PG Speed, 37
- PG Speed Frequency Setpoint #1, 115
- PG Speed Frequency Setpoint #2, 115
- PG Speed Reference #2, 116
- PG Speed Reference Setpoint #1, 116
- PID, 104
- PID feedback, 86, 114
- PID Value, 36
- PO, 15
- POFF, 178
- Position Completion Range, 116
- Position Loop Gain, 116
- Positional Err, 183
- Post Compensation Frequency, 36
- Power Connections, 15
- Power Factor Correction, 11
- Power Running Torque Limit #1, 118
- Power-Line Switching ASD Wait Time, 65
- Power-Line Switching At-Trip Selection, 117
- PP, 17, 20
- Priority Selection, 118
- Program Menu, 38
- Program Screen, 38
- Prohibit Initializing User Parameters During Typeform Initialization, 118
- Proportional-Integral-Derivative (PID), 104, 114
- PtSt, 178
- Pulse Width Modulation, 11

## Q

- Q7 Part Numbering Convention, 173
- Qualified Personnel, 3

## R

- R, 17, 19
- RAM Err, 183
- Ramped PWM Enable, 123
- Regeneration Torque Limit #1, 124
- Regeneration Torque Limit #2, 125
- Regeneration Torque Limit #3, 125
- Regeneration Torque Limit #4, 125

- Regeneration Torque Limit Setting #1, 125
- Remote EOI Required Hardware, 30
- RES, 17, 19
- Reverse Speed Limit Input, 126
- Reverse Speed Limit Level, 126
- ROM Err, 183
- Root Menus, 35
- Rotary Encoder, 28
- RR, 17, 19, 37
- RR Bias Adjust, 127
- RR Gain Adjust, 127
- RS232, 23
- RS232/485 Baud Rate, 131
- RS232/RS485 Wire Count, 132
- RS485, 23
- Run Frequency, 36
- Run Key, 27
- Run Key Status LED, 27
- RX, 17, 19, 37
- RX Bias Adjust, 137
- RX Gain Adjust, 137
- RX2, 37
- RX2 Bias Adjust, 133
- RX2 Gain Adjust, 133

## S

- S1, 17, 19
- S2, 17, 19
- S3, 17, 19
- S4, 17, 19
- Search (Changed From Default Parameters), 145
- Service Life Information, 10
- Shipping Weight, 174
- Shipping Weight (lbs.), 174
- Short Circuit Pulse Duration, 146
- Short Circuit Test, 109
- Sink/Source Error, 183
- Slip Frequency Gain, 162
- Spare Parts Listing, 187
- Speed at Drooping Gain 0%, 147
- Speed at Drooping Gain 100%, 147
- Speed Error, 182
- Speed Limit (torque) Reference, 148
- Speed Limit Torque Band, 148
- Speed Limit Torque Level, 148
- Speed Limit Torque Recovery, 148
- Speed Loop Integral Gain, 149
- Speed Loop Parameter Ratio, 149
- Speed Loop Proportional Gain, 149
- Speed Reach Bandwidth, 149
- Speed Reach Frequency, 149
- ST, 17, 19

- ST Signal Selection, 151, 167
- ST1, 13
- Stall Cooperation Gain at Field Weakening Zone, 150
- Stall Prevention During Regeneration, 150
- Startup and Test, 16
- Stop Key, 27
- Supply Voltage Compensation, 152
- SW1, 22
- SW2, 22
- Switching Load Torque During Forward-Run, 152
- Switching Load Torque During Reverse-Run, 152
- Synchronized Torque Bias Input, 153
- System Configuration, 35
- System Grounding, 15
- System Integration Precautions, 8
- System Operation, 33

## T

- Tension, 153
- Tension Torque Bias Input, 153
- Terminal Descriptions, 19
- Timer, 36
- Torque, 36
- Torque Boost Adjustment, 155
- Torque Command, 155
- Torque Command Filter, 155
- Torque Command Mode, 155
- Torque Current, 36
- Torque Limit Mode, 156
- Torque Limit Mode (Speed Dependent), 156
- Torque Reference, 36
- Trip History, 184
- Trip Record at Monitor Screen, 184
- Trip Save at Power Down Enable, 156
- Trips, 176
- Trouble Shooting, 176
- Type(form) Error, 183

## U

- U Phase OC, 183
- UC, 179
- Under Curr(ent) Trip, 181
- Up Key, 28
- Upper Limit Frequency Adjustment, 159
- User Notification codes, 176

## V

- V Phase OC, 183
- V/f Adjustment Coefficient, 159
- V/f Five-Point Setting #1 Frequency, 160
- V/f Five-Point Setting #1 Voltage, 160
- V/f Five-Point Setting #2 Frequency, 160
- V/f Five-Point Setting #2 Voltage, 161
- V/f Five-Point Setting #3 Frequency, 161
- V/f Five-Point Setting #3 Voltage, 161
- V/f Five-Point Setting #4 Frequency, 161
- V/f Five-Point Setting #4 Voltage, 161
- V/f Five-Point Setting #5 Frequency, 162
- V/f Five-Point Setting #5 Voltage, 162
- Vector Motor Model Slip Frequency Gain, 162
- VI, 17, 20
- VI/II, 37
- VI/II Bias Adjust, 162
- VI/II Gain Adjust, 163
- VI/II Speed Frequency Setpoint #2, 164
- VI/II Speed Reference Setpoint #2, 164
- Viewing Trip Information, 184
- Voltage Compensation Coefficient for Dead Time, 165
- Voltage Vector Control, 166

## W

- W Phase OC, 183